

# THE BMW 6 SERIES COUPE. OWNER'S MANUAL.

#### BMW EfficientDynamics Less emissions. More driving pleasure.

# امداد خودرو فارما

تلفن شبانه روزى: ۱-۸۸۸۶۲ ۲۸ الفن شبانه روزى: ۱-۸۸۸۶۲ م

FarmaSOS.com

#### 6 Series

#### **Owner's Manual for Vehicle**

Thank you for choosing a BMW.

The more familiar you are with your vehicle, the better control you will have on the road. We therefore strongly suggest:

Read this Owner's Manual before starting off in your new BMW. Also use the Integrated Owner's Manual in your vehicle. It contains important information on vehicle operation that will help you make full use of the technical features available in your BMW. The manual also contains information designed to enhance operating reliability and road safety, and to contribute to maintaining the value of your BMW.

Any updates made after the editorial deadline for the printed or Integrated Owner's Manual are located in the appendix of the printed quick reference for the vehicle.

Supplementary information can be found in the additional brochures in the onboard literature.

We wish you a safe and enjoyable drive.

تلفن شيانه روزي: ۵۸+۲۹۸۸۸ تلفن شيانه روزي:

FarmaSOS.com





تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۸۸ تلفن

FarmaSOS.com

© 2013 Bayerische Motoren Werke Aktiengesellschaft Munich, Germany Reprinting, including excerpts, only with the written consent of BMW AG, Munich. US English VI/13, 13 07 490 Printed on environmentally friendly paper, bleached without chlorine, suitable for recycling.

#### Contents

The fastest way to find information on a particular topic or item is by using the index, refer to page 226.

6 Notes

#### At a glance

- 12 Cockpit
- 16 iDrive
- 22 Voice activation system
- 25 Integrated Owner's Manual in the vehicle

#### **Controls**

- 30 Opening and closing
- 45 Adiustina
- 54 Transporting children safely
- 58 Driving
- 71 Displays
- 86 Lamps
- 91 Safety
- 116 Driving stability control systems FarmaSOS.com
- 124 Driving comfort
- 151 Climate control
- 157 Interior equipment 162 Storage compartments

#### **Driving tips**

- 168 Things to remember when driving
- 171 Loading
- 173 Saving fuel

#### **Mobility**

- 182 Refueling
- **184** Fuel
- 185 Wheels and tires
- 197 **Engine compartment**
- 199 Engine oil
- 201 Coolant
- 202 Maintenance
- Replacing components 204
- 210 Breakdown assistance
- 215 Care

#### Reference

- 222 Technical data
- Everything from A to Z

#### **Notes**

#### **Using this Owner's Manual**

The fastest way to find information on a particular topic is by using the index.

An initial overview of the vehicle is provided in the first chapter.

# Updates made after the editorial deadline

Any updates made after the editorial deadline for the Owner's Manuals are located in the appendix of the printed quick reference for the vehicle.

# User's manual for Navigation, Entertainment, Communication

The topics of Navigation, Entertainment, Communication and the short commands of the voice activation system are described in a separate user's manual, which is also included with the onboard literature.

#### Additional sources of information

Should you have any questions, your service center will be glad to advise you at any time. Information on BMW, e.g., on technology, is available on the Internet: bmwusa.com.

# Symbols in the Owner's Manual

- ⚠ Indicates precautions that must be followed precisely in order to avoid the possibility of personal injury and serious damage to the vehicle.
- → Marks the end of a specific item of information.
- "..." Identifies Control Display texts used to select individual functions.

- >.... Verbal instructions to use with the voice activation system.
- »...« Identifies the answers generated by the voice activation system.
- Refers to measures that can be taken to help protect the environment.

#### Symbols on vehicle components

Indicates that you should consult the relevant section of this Owner's Manual for information on a particular part or assembly.

#### Vehicle equipment

This Owner's Manual describes all models and all standard, country-specific and optional equipment that is offered in the model series. Therefore, in this Owner's Manual, equipment is also described and illustrated that is not available in your vehicle, e.g., because of the selected optional equipment or the country-specific variants.

This also applies for safety-related functions and systems.

For options and equipment not described in this Owner's Manual, please refer to the Supplementary Owner's Manuals.

On right-hand drive vehicles, some controls are arranged differently than shown in the illustrations.

# Status of the Owner's Manual

The manufacturer of your vehicle pursues a policy of constant development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards. In rare cases, therefore, the features de-

scribed in this Owner's Manual may differ from those in your vehicle.

# Updates made after the editorial deadline

Any updates made after the editorial deadline for the Owner's Manuals are located in the appendix of the printed quick reference for the vehicle.

#### For your own safety

#### Maintenance and repairs

Advanced technology, e.g., the use of modern materials and high-performance electronics, requires suitable maintenance and repair methods.

Therefore, have this work performed only by a BMW center or a workshop that works according to BMW repair procedures with appropriately trained personnel.

If this work is not carried out properly, there is the danger of subsequent damage and related safety hazards.

#### **Parts and Accessories**

For your own safety, use genuine parts and accessories approved by BMW. When you purchase accessories tested and approved by BMW and Genuine BMW Parts, you simultaneously acquire the assurance that they have been thoroughly tested by BMW to ensure optimum performance when installed on your vehicle. BMW warrants these parts to be free from defects in material and workmanship. BMW will not accept any liability for damage resulting from installation of parts and accessories not approved by BMW. BMW cannot test every product made by other manufacturers to verify if it can be used on a BMW safely and without risk to either the vehicle, its operation, or its occupants. Genuine BMW Parts, BMW Accessories and other products approved by BMW, together with professional

advice on using these items, are available from all BMW centers. Installation and operation of non-BMW approved accessories such as alarms, radios, amplifiers, radar detectors, wheels, suspension components, brake dust shields, telephones, including operation of any mobile phone from within the vehicle without using an externally mounted antenna, or transceiver equipment, for instance, CBs, walkietalkies, ham radios or similar accessories, may cause extensive damage to the vehicle, compromise its safety, interfere with the vehicle's electrical system or affect the validity of the BMW Limited Warranty. See your BMW center for additional information. Maintenance, replacement, or repair of the emission control devices and systems may be performed by any automotive repair establishment or individual using any certified automotive part.

#### **California Proposition 65 Warning**

California laws require us to state the following warning:

Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle. contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Battery posts, terminals and related accessories contain lead and lead compounds. Wash your hands after handling. Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water.

#### Service and warranty

We recommend that you read this publication thoroughly. Your vehicle is covered by the following warranties:

- New Vehicle Limited Warranty.
- Rust Perforation Limited Warranty.
- Federal Emissions System Defect Warranty.
- Federal Emissions Performance Warranty.
- California Emission Control System Limited Warranty.

Detailed information about these warranties is listed in the Service and Warranty Information Booklet for US models or in the Warranty and Service Guide Booklet for Canadian models.

Your vehicle has been specifically adapted and designed to meet the particular operating conditions and homologation requirements in your country and continental region in order to deliver the full driving pleasure while the vehicle is operated under those conditions. If you wish to operate your vehicle in another country or region, you may be required to adapt your vehicle to meet different prevailing operating conditions and homologation requirements. You should also be aware of any applicable warranty limitations or exclusions for such country or region. In such case, please contact Customer Relations for further information.

#### Maintenance

Maintain the vehicle regularly to sustain the road safety, operational reliability and the New Vehicle Limited Warranty.

Specifications for required maintenance measures:

- BMW Maintenance system
- Service and Warranty Information Booklet for US models
- Warranty and Service Guide Booklet for Canadian models

If the vehicle is not maintained according to these specifications, this could result in serious damage to the vehicle. Such damage is not covered by the BMW New Vehicle Limited Warranty.

#### **Data memory**

Many electronic components on your vehicle are equipped with data memories that temporarily or permanently store technical information about the condition of the vehicle, events and faults. This technical information generally documents the state of a component, a module, a system or the environment:

- Operating states of system components, fill levels for instance.
- Status messages for the vehicle and from its individual components, e.g., wheel rotation speed/ vehicle speed, deceleration, transverse acceleration.
- Malfunctions and faults in important system components, e.g., lights and brakes.
- Responses by the vehicle to special situations, e.g., deployment of an airbag, engagement of stability control systems.
- Ambient conditions, such as temperature.

This data is purely technical in nature and is used to detect and correct faults and to optimize vehicle functions. Motion profiles over routes traveled cannot be created from this data. When service offerings are used, e.g., repair services, service processes, warranty claims, quality assurance, this technical information can be read out from the event and fault memories by the service personnel, including the manufacturer, using special diagnostic tools. You can obtain further information there if it is needed. After a fault is corrected, the information in the fault memory is deleted or overwritten on a continuous basis.

When the vehicle is in use, situations are conceivable in which it might be possible to associate this technical data with individuals if it is combined with other information, e.g., an accident report, damage to the vehicle, eye witness accounts — possibly with the assistance of an expert.

Additional functions that are contractually agreed with the customer, such as vehicle lo-

cating in an emergency, enable certain vehicle data to be transmitted from the vehicle.

#### **Event Data Recorder EDR**

This vehicle is equipped with an event data recorder EDR. The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating.
- Whether or not the driver and passenger safety belts were fastened.
- How far, if at all, the driver was depressing the accelerator and/or brake pedal.
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

EDR data are recorded by your vehicle only if a nontrivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data, e.g., name, gender, age, and crash location, are recorded.

However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

#### **Reporting safety defects**

#### For US customers

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA, in addition to notifying BMW of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 1-800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign.

However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov

#### For Canadian customers

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls, may telephone the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from http://www.tc.gc.ca/roadsafety.



مداد مح درو فارما

. 77-111-

FarmaSOS.com



These overviews of buttons, switches and displays are intended to familiarize you with your vehicle. You will also become quickly acquainted with the available control concepts and options.

 $^{ullet}$  تلفن شبانه روزی: ۱–۸۸۸ $^{ullet}$   $^{ullet}$ 

FarmaSOS com


### **Cockpit**

#### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e.g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### All around the steering wheel



- 1 Roller sunblind 42
- 2 Power windows 41
- 3 Exterior mirror operation 51
- 4 Driver assistance systems



Active Blind Spot Detection 112



Intelligent Safety 99



Lane departure warning 110



Night Vision with pedestrian detection 107



Head-up Display 148





Front fog lamps 89



Parking lamps 86



Low beams 86



Automatic headlamp control 87

Daytime running lights 87

Adaptive Light Control 87

High-beam Assistant 88



Instrument lighting 89

6 Steering column stalk, left



Turn signal 64



High beams, headlamp flasher 64



High-beam Assistant 88



Roadside parking lamps 87



Computer 82

- 7 Shift paddles 69
- 8 Steering wheel buttons, left



Store speed 133, 124



Resume speed 135, 127



Cruise control on/off, interrupting 125



Cruise control on/off, interrupting 133



Reduce distance 127



Increase distance 127



Congestion Assistant ON/OFF, Pause 130



Congestion Assistant: setting cruise control distance 124

Cruise control rocker switch 135, 126

- 9 Instrument cluster 71
- 10 Steering wheel buttons, right



Entertainment source



Volume



Voice activation 22



Telephone, see user's manual for Navigation, Entertainment and Communication

Thumbwheel for selection lists 82

11 Steering column stalk, right



Windshield wipers 65



Rain sensor 66



Clean the windshields and headlamps 66



Start/stop the engine and switch the ignition on/off 59



Automatic Engine Start/Stop Function 60

14 Horn



Steering wheel heating 53



Adjust the steering wheel 53

17 Unlocking the hood

18



Open the trunk lid 36

#### All around the center console



- All around the interior rearview mirror 15
- 2 Control Display 16
- 3 Glove compartment 162
- Air vent 154
- 5

Hazard warning system 210



Central locking system 36

- Radio/CD/Multimedia, see user's manual for Navigation, Entertainment and Communication
- 7 Automatic climate control 151
- Controller with buttons 16





Parking brake 62



Automatic Hold 63



PDC Park Distance Control 136

Top View 140

Side View 142

Rearview camera 138

Parking assistant 144





HDC Hill Descent Control 118

SPORT A


COMFORT 11

Driving Dynamics Control 120 12 Transmission selector lever



DSC Dynamic Stability Control 116

#### All around the headliner





Intelligent Emergency Request 210



Reading lamps 90

2

Glass sunroof, powered 42

5

Interior lamps 89

3

Indicator lamp, front passenger airbag 93

#### **iDrive**

#### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### The concept

The iDrive combines the functions of a multitude of switches. Thus, these functions can be operated from a central location.

Using the

Using the iDrive during a trip

To avoid becoming distracted and posing an unnecessary hazard to your vehicle's occupants and to other road users, never attempt to use the controls or enter information unless traffic and road conditions allow this.

#### **Control Display**

#### Hints


- ▶ To clean the Control Display, follow the care instructions.
- Do not place objects close to the Control Display; otherwise, the Control Display can be damaged.

#### **Switching off**



Press the button.

"Switch off control display"



Press the controller again to switch the screen

#### Controls at a glance arma Switching om

#### **Controls**



- Control Display
- 2 Controller with buttons

The buttons can be used to open the menus directly. The controller can be used to select menu items and create the settings.

#### Controller

Select menu items and create settings.

1. Turn.


back on.



#### 2. Press.



Move in four directions.



#### **Buttons on controller**


	<u> </u>
Press the but- ton	Function
MENU	Open the main menu.
RADIO	Opens the Radio menu.
MEDIA	Opens the CD/Multimedia menu.
NAV	Opens the Navigation menu.
TEL	Opens the Telephone menu.
BACK	Displays the previous panel.
OPTION	Opens the Options menu.

#### **Operating concept**

#### Opening the main menu



Press the button.




The main menu is displayed.

All iDrive functions can be called up via the main menu.

#### **Selecting menu items**

Menu items shown in white can be selected.

1. Turn the controller until the desired menu item is highlighted.



Press the controller.

#### Menu items in the Owner's Manual

In the Owner's Manual, menu items that can be selected are set in quotation marks, e.g., "Settings".

#### Changing between panels

After a menu item is selected, e.g., "Radio", a new panel is displayed. Panels can overlap.


▶ Move the controller to the left.

The current panel is closed and the previous panel is displayed.

The previous panel is opened again by pressing the BACK button. In this case, the current panel is not closed.

▶ Move the controller to the right.

A new panel is opened on top of the previous display.



White arrows pointing to the left or right indicate that additional panels can be opened.

#### View of an opened menu

When a menu is opened, it generally opens with the panel that was last selected in that menu. To display the first panel of a menu:


- Move the controller to the left repeatedly until the first panel is displayed.
- Press the menu button on the controller twice.

#### **Opening the Options menu**

OPTION

Press the button.

The "Options" menu is displayed



Additional options: move the controller to the right repeatedly until the "Options" menu is displayed.

#### **Options menu**


The "Options" menu consists of various areas:

▶ Screen settings, e.g., "Split screen".

- This area remains unchanged.
- ▶ Control options for the selected main menu, e.g., for "Radio".
- ▶ If applicable, further operating options for the selected menu, e.g., "Store station".

#### **Changing settings**

- 1. Select a field.
- Turn the controller until the desired setting is displayed.



3. Press the controller.

#### **Activating/deactivating the functions**


Several menu items are preceded by a checkbox. It indicates whether the function is activated or deactivated. Selecting the menu item activates or deactivates the function.

- The function is activated.
- The function is deactivated.

#### **Example: setting the clock**

#### **Setting the clock**

- Press the button. The main menu is displayed.
- 2. Turn the controller until "Settings" is highlighted, and then press the controller.



- If necessary, move the controller to the left to display "Time/Date".
- Turn the controller until "Time/Date" is highlighted, and then press the controller.



Turn the controller until "Time:" is highlighted, and then press the controller.



- 6. Turn the controller to set the hours and press the controller.
- 7. Turn the controller to set the minutes and press the controller.

#### Status information

#### Status field

The following information is displayed in the status field at the top right:

- Time.
- Current entertainment source.
- Sound output, on/off.
- Wireless network reception strength.
- Telephone status.
- Traffic bulletin reception.

#### Status field symbols

The symbols are grouped as follows.

#### Radio symbols

	Symbol	Meaning
)	Ю	HD Radio™ is switched on.
	1.	Satellite radio is switched on.

#### **Telephone symbols**

Symbol	Meaning
~	Incoming or outgoing call.
X	Missed call.
atl	Wireless network reception strength Symbol flashes: searching for network.
atl	Wireless network is not available.
8	Bluetooth is switched on.
<b>A</b>	Roaming is active.

Symbol	Meaning
$\bowtie$	Text message was received.
<b></b> €Ĉ	Check the SIM card.
<b>■</b>	SIM card is blocked.
<b>/</b>	SIM card is missing.
Ü	Enter the PIN.

#### **Entertainment symbols**

Meaning			
CD/DVD player.			
Music collection.			
Gracenote® data	abase.	1	
AUX-IN port.	5/	9	9
	CD/DVD player.  Music collection.  Gracenote® data	CD/DVD player.  Music collection.  Gracenote® database.	CD/DVD player.  Music collection.  Gracenote® database.

#### **Additional symbols**

Symbol	Meaning + Y \ _ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
刈	Spoken instructions are switched off.

#### **Split screen**

#### **General information**

Additional information can be displayed on the right side of the split screen, e.g., information from the computer.


In the divided screen view, the so-called split screen, this information remains visible even when you change to another menu.

#### Switching the split screen on and off

- 1. Press the button.
- "Split screen"

#### Selecting the display

- 1. Press the button.
- 2. "Split screen"
- Move the controller until the split screen is selected.
- Press the controller or select "Split screen content".
- Select the desired menu item.



# Programmable memory buttons الفن شبانه روزي:

#### **General information**

The iDrive functions can be stored on the programmable memory buttons and called up directly, e.g., radio stations, navigation destinations, phone numbers and entry points into the menu.

The settings are stored for the remote control currently in use.

#### Saving a function

- 1. Highlight the function via the iDrive.
- 2. Press the desired button for more than 2 seconds.

#### Running a function



Press the button.

The function will run immediately. This means, for example, that the number is dialed when a phone number is selected.

#### Displaying the button assignment

Use a finger to touch the buttons. Do not wear gloves or use objects.

The key assignment is displayed at the top edge of the screen.



- To display short information: touch the button.
- ➤ To display detailed information: touch the button for an extended period.

#### **Deleting the button assignments**

- Press buttons 1 and 8 simultaneously for approx. five seconds.
- 2. "OK"

#### **Entering letters and numbers**

#### **General information**

- Turn the controller: select letters or numbers.
- Select additional letters or numbers if needed.
- 3. "OK": confirm the entry.

Depending on the menu, you can switch between entering upper and lower case, letters and numbers:

Symbol	Function
l←	Press the controller: delete the letter or number.
l←	Press the controller for an extended period: delete all letters or numbers.

# Switching between cases, letters and numbers

Depending on the menu, you can switch between entering upper and lower case, letters and numbers:

Symbol	Function
A <sup>B</sup> C	Enter the letters.
1 <sup>@</sup> +	Enter the numbers.
abc or ABC	Move the controller up.

#### Without navigation system

#### Entry comparison

Entry of names and addresses: the selection is narrowed down every time a letter is entered and letters may be added automatically.

The entries are continuously compared to the data stored in the vehicle.

- Only those letters are offered during the entry for which data is available.
- Destination search: town/city names can be entered using the spelling of language available on the Control Display.

### Voice activation system

#### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### The concept

- Most functions that are displayed on the Control Display can be operated by spoken commands via the voice activation system. The system prompts you to make your entries.
- Functions that can only be used when the vehicle is stationary cannot be operated using the voice activation system.
- The system uses a special microphone on the driver's side.
- .... Verbal instructions in the Owner's Manual to use with the voice activation system.

#### Requirements

Via the Control Display, set a language that is also supported by the voice activation system so that the spoken commands can be identified.

Set the language, refer to page 85.

#### **Using voice activation**

#### Activating the voice activation system

- 1. Press the button on the steering wheel.
- 2. Wait for the signal.
- Say the command.The command is displayed in the instrument cluster.

This symbol in the instrument cluster indicates that the voice activation system is active. If no other commands are available, operate the function in this case via iDrive.

#### Terminating the voice activation system



Briefly press the button on the steering wheel or Cancel.

#### **Possible commands**

Most menu items on the Control Display can be voiced as commands.

The available commands depend on which menu is currently displayed on the Control Display.

Short commands exist for many functions.

Some list entries, e.g., Phone book entries, can also be selected via the voice activation system. Speak these list entries exactly as they are displayed in the respective list.

#### Having possible commands read aloud

You can have the available commands read out loud for you: >Voice commands

For example, if the "Settings" menu is displayed, the commands for the settings are read out loud.

# **Executing functions using short commands**

Functions on the main menu can be performed directly by means of short commands, nearly irrespective of which menu item is currently selected, e.g., Vehicle status.

List of short commands of the voice activation system, see Navigation, Entertainment, Communication Owner's Manual.

# Help dialog for the voice activation system

Calling up help dialog: >Help«

Additional commands for the help dialog:

- Help with examples: information about the current operating options and the most important commands for them are announced.
- Help with voice activations information about the principle of operation for the voice activation system is announced.

#### **Example: playing back a CD**

#### Via the main menu

The commands of the menu items are spoken just as they are selected via the controller.

- 1. Switch on the Entertainment sound output if necessary.
- 2. Press the button on the steering wheel.
- Multimedia
   The medium last played is played back.
- 4. →C D<
- 5. →C D drive
- 6. →Track ..., e.g., CD track 4.

#### Via short command

Playback of the CD can also be started via a short command.

- 1. Switch on the Entertainment sound output if necessary.
- 2. Press the button on the steering wheel.
- 3. →C D drive track ..., e.g., CD track 4.


#### **Setting the voice dialog**

You can set whether the system should use the standard dialog or a shorter version.

In the shorter variant of the voice dialog, the announcements from the system are issued in an abbreviated form.

On the Control Display:

- 1. "Settings"
- 2. "Language/Units"
- "Speech mode:"
- 4. Select the setting.



#### Adjusting the volume

Turn the volume button while giving an instruction until the desired volume is set.

- The volume remains constant even if the volume of other audio sources is changed.
- The volume is stored for the remote control currently in use.

# Notes on Emergency Requests

Do not use the voice activation system to initiate an Emergency Request. In stressful situations, the voice and vocal pitch can change. This can unnecessarily delay the establishment of a telephone connection.

Instead, use the SOS button, refer to page 210, in the vicinity of the interior mirror.

#### **Environmental conditions**

- Say the commands, numbers, and letters smoothly and with normal volume, emphasis, and speed.
- Always say commands in the language of the voice activation system.
- Keep the doors, windows, and glass sunroof closed to prevent noise interference.
- Avoid making other noise in the vehicle while speaking.

تلفن شبانه روزی: ۱۲۰۸۸۶۲۰۸۵ تلفن شبانه روزی: ۱۲۰۵۸۸۶۲۰۸

FarmaSOS.com

# **Integrated Owner's Manual in the vehicle**

#### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# Integrated Owner's Manual in the vehicle

The Integrated Owner's Manual can be displayed on the Control Display. The equipment and functions that are in the vehicle are described therein.

#### Components of the integrated Owner's Manual

The integrated Owner's Manual consists of three parts, which offer various levels of information or access possibilities.

#### Quick Reference Guide armas

Located in the Quick Reference is important information for the operation of the vehicle, the operation of basic vehicle functions or for what to do in the event of a flat tire. This information can also be displayed during driving.

#### **Search by pictures**


Information and descriptions based on illustrations can be searched via search by pictures. This is helpful, for example, if the description of an outfitting package that cannot be named is needed.

#### Owner's Manual

Information and descriptions can be searched by direct entry of a search term via the index.

#### **Select components**

- Press the button.
- 2. Turn the controller: open "Vehicle Info".
- Press the controller.
- 4. Selecting desired range:
  - "Quick reference"
  - "Search by pictures"
  - "Owner's Manual"



#### Leafing through the Owner's Manual

#### Page by page with link access

Turn the controller until the next or previous page is displayed.

#### Page by page without link access

Leaf through the pages directly while skipping the links.

Highlight the symbol once. Now simply press the controller to leaf from page to page.



Leaf back.



Leaf forward.

# Context help - Owner's Manual to the temporarily selected function

The relevant information can be opened directly.

#### Opening via the iDrive

To move directly from the application on the Control Display to the options menu:

- 1. Press the button or move the controller to the right repeatedly until the "Options" menu is displayed.
- 2. "Display Owner's Manual"

# Opening when a Check Control message is displayed

Directly from the Check Control message on the Control Display:

"Display Owner's Manual"

#### **Programmable memory buttons**

#### **General information**

The Owner's Manual can be stored on the programmable memory buttons and called up directly.

#### **Storing**

- 1. "Owner's Manual" Select via the iDrive.
- 2. Press the desired button for more than 2 seconds.

#### **Executing**

Press the button.
The Owner's Manual is displayed immediately.

#### Changing between a function and the Owner's Manual

To change from a function, e.g., radio, to the ۲۰۰۸ فرزی: ۵۰۰ Owner's Manual on the Control Display and to switch between the two displays:

- Press the button or move the controller to the right repeatedly until the "Options" menu is displayed.
- 2. "Display Owner's Manual"
- Select the desired page in the Owner's Manual.
- 4. Press the button again to return to the function displayed last.
- 5. Press the button to return to the page of the Owner's Manual displayed last.

To switch back and forth repeatedly between the function displayed last and the page of the Owner's Manual displayed last, repeat steps 4 and 5. This opens a new panel every time.



تلفن شبانه روزی: ۱۳۵۸ ۲۹ ۲۸ ۱۳۸۰ ۲۲۰

FarmaSOS.com



امداد تودرو فارما

نلفن شبانه روزی: ۱-۸۸۸۶۲۰۸۵ ۲۱-۲۰

FarmaSOS.com




# **Opening and closing**

#### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### Remote control/key

#### **Buttons on the remote control**



- 1 Unlocking
- 2 Locking
- 3 Trunk lid
- 4 Panic mode, headl. courtesy delay feat.

#### General information


The vehicle is supplied with two remote controls with keys.

Every remote control contains a replaceable battery.

The settings called up and implemented when the car is unlocked depend on which remote control is used to unlock the car. Personal Profile, refer to page 31.

Information on the required maintenance is stored in the remote control as well. Service data in the remote control, refer to page 202

#### **Integrated key**



Press the button on the back of the remote control, arrow 1, and pull out the key, arrow 2.

The integrated key fits the following locks:

- Driver's door.
- Storage compartment in the center armrest.

The storage compartment contains a switch for separately securing the trunk lid, refer to page 37. منانه منانه على المنان المنا

#### Replacing the battery



- Take the integrated key out of the remote control.
- 2. Push in the catch with the key, arrow 1.
- 3. Remove the cover of the battery compartment; see arrow 2.
- 4. Insert a battery of the same type with the positive side facing upwards.
- Press the cover closed.



Take the used battery to a recycling center or to your service center.

#### **New remote controls**

You can obtain new remote controls from your service center.

#### Loss of the remote controls

Lost remote controls can be blocked by your service center.

# Emergency detection of remote control

It is possible to switch on the ignition or start the engine in situations such as the following:

- Interference of radio transmission to remote control by external sources.
- Discharged battery in the remote control.
- Interference of radio transmission by mobile devices in close proximity to the remote control.
- Interference of radio transmission by charger while charging items such as mobile devices in the vehicle.

A Check Control message is displayed if an attempt is made to switch on the ignition or start the engine.

# Starting the engine with emergency detection of the remote control



Automatic transmission: if a corresponding Check Control message appears, hold the remote control, as shown, against the marked area on the steering column and press the Start/Stop button within 10 seconds while pressing the brake.

#### **Personal Profile**

#### The concept

You can set several of your vehicle's functions to suit your personal needs and preferences.

- The settings are automatically saved in the profile currently activated.
- The remote control used is detected when the vehicle is unlocked and the stored profile is called up.
- Your personal settings will be recognized and called up again even if the vehicle has been used in the meantime by someone else with another remote control.

The individual settings are stored for three Personal Profiles and one quest profile.

#### Transmitting the settings

Your personal settings can be taken with you to another vehicle equipped with the Personal Profile function. For more information, contact your service center.

Transmission takes place via:

- ▶ The USB interface in the center armrest onto a USB device.
- BMW Online.

#### **Profile management**

#### Opening the profiles

A different profile can be called up than the one associated with the remote control currently in use.

- 1. "Settings"
- "Profiles"
- Select a profile.

Called up profile is assigned to the remote control being used at the time.

#### **Renaming profiles**

- "Settings"
- 2. "Profiles"

The current profile is selected.

- 3. Open "Options".
- 4. "Rename current profile"

#### **Resetting profiles**

The settings of the active profile are reset to their default values.

- 1. "Settings"
- 2. "Profiles"

The current profile is selected.

- 3. Open "Options".
- 4. "Reset current profile"

#### **Importing profiles**

Existing settings and contacts are overwritten with the imported profile.

- 1. "Settings"
- "Profiles"
- "Import profile"
- BMW Online: "BMW Online"
   USB interface, refer to page 162: "USB device"

#### **Exporting profiles**

Most settings of the active profile and the saved contacts can be exported.

This can be helpful for securing and retrieving personal settings, before delivering the vehicle to a workshop for example.

- 1. "Settings"
- 2. "Profiles"
- "Export profile"
- BMW Online: "BMW Online"
   USB interface, refer to page 162: "USB device"

#### Using the guest profile

The guest profile can be used to make individual settings without affecting the three Personal Profiles.

This can be useful for drivers who are using the vehicle temporarily and do not have their own profile.

- 1. "Settings"
- "Profiles"
  The current profile is selected.
- 3. Open "Guest".
- 4. Create the settings.

Note: the guest profile cannot be renamed.

#### Display profile list during start

The profile list can be displayed during each start for selecting the desired profile.

- "Settings"
- "Profiles"
- 3. Open "Options".
- 4. O'Display user list at startup"

#### Personal Profile settings

The following functions and settings can be stored in a profile.

- Collision warning: warning time.
- Exterior mirror position.
- CD/Multimedia: audio source listened to last.
- Unlocking/locking of the vehicle: settings.
- Driving Dynamics Control: sport program.
- Driver's seat position: automatic retrieval after unlocking.
- Programmable memory buttons: assignment.
- ▶ Head-up Display: selection, brightness, position and rotation of the display.
- Headlamp courtesy delay feature: time setting.

- Tone: tone settings.
- Automatic climate control: settings.
- Steering wheel position.
- Navigation: map views, route criteria, voice output on/off.
- Night Vision with pedestrian detection.
- Intelligent Safety: individual settings.
- Park Distance Control PDC: adjusting the signal tone volume.
- Radio: stored stations, station listened to last, special settings.
- Rearview camera: selection of functions and type of display.
- Side View: selection of the display type.
- Language on the Control Display.
- Lane departure warning: last setting, on/ off.
- Active Blind Spot Detection: last setting, on/off.
- Daytime running lights: current setting.
- Locking the vehicle: after a brief period or after starting to drive.

# FarmaS Central locking system

### The concept

The central locking system becomes active when the driver's door is closed.

The system simultaneously engages and releases the locks on the following:

- Doors.
- Trunk lid.
- Fuel filler flap.

#### **Operating from the outside**

- Via the remote control.
- Via the driver's door lock.
- Via the door handles.

Via the button in the trunk lid.

The following takes place simultaneously when locking/unlocking the vehicle via the remote control:

- Depending on how the vehicle is equipped, the theft protection is activated/deactivated. Theft protection prevents the doors from being unlocked using the lock buttons or the door opener.
- The welcome lamps, interior lamps and courtesy lamps are switched on and off.
- ▶ The alarm system, refer to page 40, is armed or disarmed.

#### **Operating from the inside**



Via the button for the central locking system.

If the vehicle has been locked from inside, the fuel filler flap remains unlocked.

If an accident of a certain severity occurs, the central locking system unlocks automatically.

The hazard warning system and interior lamps come on.

# Opening and closing: from the outside

#### Using the remote control

#### **General information**

Take the remote control with you People or animals left unattended in a

People or animals left unattended in a parked vehicle can lock the doors from the inside. Always take the remote control with you when leaving the vehicle so that the vehicle can then be opened from the outside. ◄

#### **Unlocking**



Press the button on the remote con-

The vehicle is unlocked.

Welcome lamps, interior lamp and courtesy lamps are switched on.

You can set how the vehicle is to be unlocked. Create the settings, refer to page 39.

#### **Convenient opening**

The remote control can be used to simultaneously open the windows and the glass sunroof.



Press and hold the button on the remote control.

The windows are opened, the glass sunroof is tilted and the sliding visor moves back.

Releasing the button stops the motion.

#### Locking



Press the button on the remote control.

Locking from the outside

Do not lock the vehicle from the outside if there are people in it, as the vehicle cannot be unlocked from inside without special knowledge.

# Switching on interior lamps and courtesy lamps



Press the button on the remote control with the vehicle locked.

#### Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.



Press the button on the remote control for at least 3 seconds.

To switch off the alarm: press any button.

# Switching on the headlamp courtesy delay feature



Briefly press the button on the remote control.

The duration can be set in the Control Display.

#### Opening the trunk lid



Press the button on the remote control for approx. 1 second.

The trunk lid opens, regardless of whether it was previously locked or unlocked.

During opening, the trunk lid pivots back and up. Ensure that adequate clearance is available before opening.

In some vehicle equipment variants, the trunk lid can only be opened using the remote control if the vehicle has been unlocked.



Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the trunk lid is closed.◀

The trunk lid is locked again as soon as it is pushed closed.

#### Malfunction

If the vehicle can no longer be locked or unlocked with the remote control, the battery may be discharged or there may be interference from external sources such as mobile phones, metal objects, overhead power lines, transmission towers, etc.

If this occurs, lock or unlock the driver's door at the door lock using the integrated key.

#### For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

#### FCC ID:

- I X8766S.
- ▶ LX8766E.
- I X8CAS.
- LX8CAS2.
- MYTCAS4.

#### Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

#### Using the door lock

#### **General information**



Locking from the outside

Do not lock the vehicle from the outside if there are people in it, as the vehicle cannot be unlocked from inside without special knowledge.



Remove the key before pulling the door handle

Before pulling the outside door handle, remove the key to avoid damaging the paintwork and the key.◀

In some country-specific versions, the alarm system is triggered if the vehicle is unlocked via the door lock.

In order to terminate this alarm, unlock vehicle with the remote control or switch on the ignition, if necessary, by emergency detection of the remote control.

In some vehicle equipment versions, only the driver's door can be unlocked or locked via the door lock

# Locking the doors and trunk lid at once

To lock all doors and the trunk lid at once:

- With the doors closed, lock the vehicle using the button for the central locking system in the interior.
- 2. Unlock and open the driver's or front passenger door.
- 3. Lock the vehicle.

- Lock the driver's door using the integrated key in the door lock, or
- Press down the lock button of the front passenger door and close the door from the outside.

The fuel filler flap can only be locked using the remote control.

#### **Manual operation**

If an electrical malfunction occurs, lock or unlock the vehicle using the integrated key via the door lock on the driver's door.

# Opening and closing: from the inside

#### Locking and unlocking



Pressing the buttons locks and unlocks the doors and the trunk lid when the doors are closed, but they are not secured against theft.

The fuel filler flap remains unlocked.

#### **Unlocking and opening**

- Either unlock the doors together using the button for the central locking system and then pull the door handle above the armrest or
- Pull the door opener twice individually on each door: the first time unlocks the door, the second time opens it.

#### **Doors**

#### **Automatic Soft Closing**

To close the doors, push lightly. It is closed automatically.



Danger of pinching

Make sure that the closing path of the doors is clear; otherwise, injuries may result. ◄

#### **Trunk lid**

#### **Opening**

During opening, the trunk lid pivots back and up.

Ensure that adequate clearance is available before opening.

#### **Opening from the outside**



- Press on the top half of the BMW emblem.
- Press the button on the remote control for approx. 1 second.

#### **Opening from the inside**



Push the button in the driver's footwell

If the vehicle is stationary, the trunk lid opens if it is not locked.

### Closing



Recessed grips in the interior trim of the trunk lid make it easier to pull down the lid.

Make sure that the closing path of the trunk lid is clear; otherwise, injuries may result. ◄

 $oldsymbol{\Lambda}$ 

Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the trunk lid is closed. ◀

### Locking the vehicle




Press the button on the inside of the trunk lid. When the driver's door is closed, the vehicle is completely locked.

### **Locking separately**

The trunk lid can be locked separately with the switch in the front passenger glove compartment.

- Trunk lid secured, arrow 1.
- Trunk lid not secured, arrow 2.



If the center arm rest is locked, the trunk lid cannot be opened.

This is beneficial when the vehicle is parked using valet service. The infrared remote control can be handed out without the key.

### **Emergency unlocking**



Pull the handle inside the cargo area.

The trunk lid unlocks.

### **Comfort Access**

### The concept

The vehicle can be accessed without activating the remote control.

All you need to do is to have the remote control with you, e.g., in your jacket pocket.

The vehicle automatically detects the remote control when it is nearby or in the passenger compartment.

Comfort Access supports the following functions:

- Unlocking/locking of the vehicle.
- Convenient closing.

- Unlocking of the trunk lid separately.
- Start the engine.

### **Functional requirements**

- There are no external sources of interference nearby.
- ➤ To lock the vehicle, the remote control must be located outside of the vehicle.
- ▶ The next unlocking and locking cycle is not possible until after approx. 2 seconds.
- ➤ The engine can only be started if the remote control is inside the vehicle.

## Comparison with ordinary remote control

The functions can be controlled by pressing the buttons of the remote control or Comfort Access.

### **Unlocking**



Fully grasp a door handle, arrow 1.

This corresponds to pressing the  $\mathbf{n}$  button on the remote control.

### Locking



Press the area on the door handle, arrow 2, with your finger for approx. 1 second.

This corresponds to pressing the **3** button on the remote control.

To save battery power, ensure that the ignition and all electronic systems and/or power consumers are switched off before locking the vehicle.

### **Convenient closing**

Press the area on the door handle, arrow 2, with the finger and hold it down.

In addition to locking, the windows and the glass sunroof are closed.

Monitor the closing process

Monitor the closing process to ensure
that no one becomes trapped.

✓

### Unlocking the trunk lid separately

Press on the top half of the BMW emblem on the trunk lid.

This corresponds to pressing the button on the remote control.



Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the trunk lid is closed.◀

### Malfunction

Comfort Access may not function properly if it experiences interference from external sources such as mobile phones, metal objects, overhead power lines, transmission towers, etc.

In this case, open or close the vehicle using the buttons on the remote control or use the integrated key in the door lock.

### **Adjusting**

### **Unlocking**

The setting is stored for the remote control currently in use.

- 1. "Settings"
- 2. "Doors/key"
- 3. f Select symbol or "Unlock button:"
- 4. Select the desired function:
  - "Driver's door only"
     Only the driver's door and the fuel filler flap are unlocked. Pressing again unlocks the entire vehicle.
  - "All doors"The entire vehicle is unlocked.

Depending on how the vehicle is equipped or the country-specific variant, you can set whether the doors are also unlocked with the button on the remote control.

### Confirmation signals from the vehicle

- 1. "Settings"
- 2. "Doors/key"
- Deactivate or activate the desired confirmation signals.
  - "Acoustic sig. lock/unlock"
  - ▶ "Flash when lock/unlock"

### **Automatic locking**

The setting is stored for the remote control currently in use.

- 1. "Settings"
- 2. "Doors/key"
- 3. Select the desired function:
  - "Lock if no door opened"
    The vehicle locks automatically after a short period of time if a door is not opened.
  - "Lock after start driving"
     The vehicle locks automatically after you drive away.

# Retrieving the seat, mirror, and steering wheel settings

The driver's seat, exterior mirror, and steering wheel positions selected last are stored for the currently used remote control.

When the vehicle is unlocked, these positions are automatically retrieved if this function was activated.

Pinch hazard when moving back the seat
If this function is used, first make sure
that the footwell behind the driver's seat is
empty. Otherwise, people can be injured or objects damaged when the seat is moved back.

The adjustment procedure is interrupted:

- ▶ When a seat position switch is pressed.
- When a button of the seat, mirror, and steering wheel memory is pressed briefly.

### **Activating the setting**

- 1. "Settings"
- 2. "Doors/key"
- 3. "Last seat position autom."

### **Alarm system**

### The concept

The vehicle alarm system responds to:

- Opening of a door, the hood or the trunk lid.
- Movements in the vehicle.
- Changes in the vehicle tilt, e.g., during attempts to steal a wheel or when towing the car.
- Interruptions in battery voltage.

The alarm system briefly indicates tampering:

- By sounding an acoustic alarm.
- By switching on the hazard warning system.
- By flashing the high beams.

# Arming and disarming the alarm system

### **General information**

When you lock or unlock the vehicle, either with the remote control, Comfort Access or at the door lock the alarm system is armed or disarmed at the same time.

### Door lock and armed alarm system

Unlocking via the door lock will trigger the alarm on some country-specific versions.

In order to terminate this alarm, unlock vehicle with the remote control or switch on the ignition, if necessary, by emergency detection of the remote control.

### Trunk lid and armed alarm system

The trunk lid can be opened even when the alarm system is armed.



Press the button on the remote control for approx. 1 second.

After the trunk lid is closed, it is locked and monitored again if the doors are locked. The hazard warning system flashes once.

In some vehicle equipment variants, the trunk lid can only be opened using the remote control if the vehicle was unlocked first.

### Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.




Press the button on the remote control for at least 3 seconds.

To switch off the alarm: press any button.

### Switching off the alarm

- Unlock the vehicle using the remote control.
- With Comfort Access: If you are carrying the remote control with you, pull on the driver side or front passenger side door handle.

# Indicator lamp on the interior rearview mirror



The indicator lamp flashes briefly every 2 seconds:

The system is armed.

The indicator lamp flashes after locking: The doors, hood or trunk lid is not closed properly, but the rest of the vehicle is secured. After 10 seconds, the indicator lamp flashes continuously. Interior motion sensor and tilt alarm sensor are not active.

The indicator lamp goes out after unlocking:

The vehicle has not been tampered with.

The indicator lamp flashes after unlocking until the engine ignition is switched on, but no longer than approx. 5 minutes:
An alarm has been triggered.

#### Tilt alarm sensor

The tilt of the vehicle is monitored.

The alarm system responds in situations such as attempts to steal a wheel or when the car is towed.

### Interior motion sensor

The windows and glass sunroof must be closed for the system to function properly.

### Avoiding unintentional alarms

The tilt alarm sensor and interior motion sensor can be switched off together, such as in the following situations:

- In automatic car washes.
- In duplex garages.
- During transport on car-carrying trains, at sea or on a trailer.
- When animals are to remain in the vehicle.

## Switching off the tilt alarm sensor and interior motion sensor

Press the remote control button again within 10 seconds as soon as the vehicle is locked.

The indicator lamp lights up for approx. 2 seconds and then continues to flash.

The tilt alarm sensor and interior motion sensor are switched off until the vehicle is locked again.

### **Power windows**

### **General information**

Take the remote control with you Take the remote control with you when leaving the vehicle so that children, for example, cannot operate the power windows and injure themselves.



### **Opening**

Press the switch to the resistance point.

The window opens while the switch is held.

Press the switch beyond the resistance point.

The window opens automatically.

Pressing the switch again stops the motion. Convenient opening, refer to page 34, via the remote control.

### Closing

Monitor the closing path clear
Monitor the closing process and make
sure that the closing path of the window is
clear; otherwise, injuries may result.◄

> Pull the switch to the resistance point.

The window closes while the switch is held.

Pull the switch beyond the resistance point.

The window closes automatically. Pressing the switch stops the motion.

Convenient closing, refer to page 38, with Comfort Access.

### Pinch protection system

If the closing force exceeds a specific value as a window closes, the closing action is interrupted.

The window reopens slightly.



Danger of pinching even with pinch protection

Even with the pinch protection system, check that the window's closing path is clear; otherwise, the closing action may not stop in certain situations, e.g., if thin objects are present.

No window accessories

Do not install any accessories in the range of movement of the windows; otherwise, the pinch protection system will be impaired.

✓

The window closes without pinch protection.

### Roller sunblind

### **General information**

If you are no longer able to move the roller sunblind for the rear window after having activated it a number of times in a row, the system is blocked for a limited time to prevent overheating. Let the system cool.

The roller sunblind for the rear window cannot be moved at low interior temperatures.

### **Driver's door controls**



# Closing without the pinch protection system

Keep the closing path clear

Monitor the closing process and make
sure that the closing path of the window is
clear; otherwise, injuries may result.

✓

For example, if there is an external danger or if ice on the windows prevents a window from closing normally, proceed as follows:

- 1. Pull the switch past the resistance point and hold it there.
  - The pinch protection is limited and the window reopens slightly if the closing force exceeds a certain value.
- Pull the switch past the resistance point again within approx. 4 seconds and hold it there.

### Roller blind for rear window



Press the button.

# Glass sunroof, powered with tilt function

### **General information**

The glass sunroof is operational when the ignition is switched on.

Keep the closing path clear

Monitor the closing process and make
sure that the closing path of the glass sunroof
is clear; otherwise, injuries may result.

✓

Take the remote control with you when leaving the vehicle so that children, for example, cannot operate the roof and injure themselves.



### Tilting up and closing glass sunroof



 Push switch upward briefly.
 The closed roof is tilted and the sliding visor opens slightly.



 Briefly press out the switch twice in succession toward the rear past the resistance point.

Closed roof is raised and the sliding visor moves all the way back.

➤ To close the switch, press upward briefly or twice forward past the resistance point.

Convenient operation, refer to page 34, via the remote control.

Convenient closing, refer to page 38, with Comfort Access.

### Opening/closing the sliding visor



 Press the switch in the desired direction to the resistance point and hold it there.

The sliding visor moves while the switch is being held.

Press the switch in the desired direction past the resistance point.

The sliding visor moves automatically. Pressing the switch again stops the motion.

### **Pinch protection system**

If the closing force exceeds a specific value as a glass sunroof closes, the closing action is interrupted.

The sunroof is tilted again.



Danger of pinching even with pinch protection

Despite the pinch protection system, check that the roof's closing path is clear; otherwise, the closing action may not be interrupted in certain extreme situations, such as when thin objects are present. ◀

# Closing without the pinch protection system

If there is an external danger or if, e. g., icing of the glass sunroof prevents automatic closing, push the switch forward past the resistance point and hold it.

The roof closes without pinch protection.

### Initializing after a power failure

After a power failure during the opening or closing process, the roof can only be operated to a limited extent.

### **Initializing the system**

The system can be initialized when the vehicle is stationary and the engine is running.

During the initialization, the roof closes without pinch protection.

Keep the closing path clear

Monitor the closing process and make
sure that the closing path of the glass sunroof
is clear; otherwise, injuries may result.

✓



Press the switch up and hold it until the initialization is complete:

- Initialization begins within 15 seconds and is completed when the sunroof and sliding visor are completely closed.
- ▶ The roof closes without pinch protection.



تلفن شبانه روزی: ۱۳۰۸۸۸۶۲ ۲۸ ا

FarmaSOS.com

### **Adjusting**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### Sitting safely

The ideal seating position can make a vital contribution to relaxed, fatigue-free driving.

The seating position plays an important role in an accident in combination with:

- Safety belts, refer to page 48.
- Head restraints, refer to page 49.
- Airbags, refer to page 91.

### **Seats**

### **Adjusting**

### **General information**

Do not adjust the seat while driving
Do not adjust the driver's seat while driving, or the seat could respond with unexpected
movement and the ensuing loss of vehicle
control could lead to an accident.

✓




Do not incline the backrest too far to the rear

Farmas

Also on the front passenger side, do not incline the backrest on the front passenger side too far to the rear during driving, or there is a risk of slipping under the safety belt in the event of an accident. This would eliminate the protection normally provided by the belt.

### At a glance




- 1 Active seat
- 2 Seat, mirror, and steering wheel memory
- 3 Backrest width
- 4 Lumbar support
- 5 Backrest, head restraint
- 6 Shoulder support
- 7 Forward/back, height, tilt

### Note


The seat setting for the driver's seat is stored for the remote control currently in use. When the vehicle is unlocked via the remote control, the position is automatically retrieved if the Function, refer to page 39, for this is activated.

### Adjustments in detail


1. Forward/back.



### 2. Height.



### Seat tilt.




### Backrest tilt.



### **Thigh support**

### Multifunctional seat



Adjust the position using the lever.

### **Lumbar support**

The curvature of the seat backrest can be adjusted in such a way that it supports the lumbar region of the spine. The lower back and the spine are supported for upright posture.



- Press the front/rear section of the switch.
  - The curvature is increased/
- Press the upper/lower section of the switch.
- The curvature is shifted up/down.

### **Backrest width**



Change the width of the backrest using the side wings to adjust the lateral support.

To make it easier to enter and exit the vehicle, the backrest width temporarily opens fully.

### **Shoulder support**



Also supports the back in the shoulder area:

- Results in a relaxed seating position.
- Reduces strain on the shoulder muscles.

### **Active seat**

Active adjustment of the seat cushion's contours reduces muscular tension and fatigue to help prevent lower back pain.



Press the button. The LED lights up.

### Front seat heating



### **Switching on**



Press the button once for each temperature level.

The maximum temperature is reached when three LEDs are lit.

If the drive is continued within approx. 15 minutes, the seat heating is activated automatically with the temperature selected last.

When ECO PRO, refer to page 174, is activated, the heater output is reduced.

### Switching off



Press the button longer.

The LEDs go out.

### Temperature distribution

The heating action in the seat cushion and backrest can be distributed in different ways.

- 1. "Climate"
- "Front seat heating"
- 3. Select the required seat.
- Turn the controller to set the temperature distribution.

### Active seat ventilation, front

The seat cushion and backrest surfaces are cooled by means of integrated fans.

The ventilation cools the seat, e. g., if the vehicle interior is overheated or for continuous cooling at high temperatures.



### Switching on



Press the button once for each ventilation level.

The highest level is active when three LEDs are lit.

After a short time, the system automatically moves down one level in order to prevent excessive cooling.

### **Switching off**



Press the button longer.

The LEDs go out.

### Safety belts

### Seats with safety belt

The vehicle has four seats, each of which is equipped with a safety belt.

### **Hints**

Always make sure that safety belts are being worn by all occupants before driving away.

Although airbags enhance safety by providing added protection, they are not a substitute for safety belts.

One person per safety belt

Never allow more than one person to
wear a single safety belt. Never allow infants or
small children to ride on a passenger's lap.


Putting on the belt
Lay the belt, without twisting, snugly
across the lap and shoulders, as close to the
body as possible. Make sure that the belt lies
low around the hips in the lap area and does
not press on the abdomen. Otherwise, the belt
can slip over the hips in the lap area in a frontal
impact and injure the abdomen.

The safety belt must not lie across the neck, rub on sharp edges, be routed over solid or breakable objects, or be pinched.◀

Reduction of restraining effect

Avoid wearing clothing that prevents the belt from fitting properly, and pull the shoulder belt periodically to readjust the tension across your lap; otherwise, the retention effect of the safety belt may be reduced.

### **Buckling the belt**



Make sure you hear the latch plate engage in the belt buckle.

### Unbuckling the belt

- 1. Hold the belt firmly.
- 2. Press the red button in the belt buckle.
- Guide the belt back into its reel.

# Safety belt reminder for driver's and passenger's seat



The indicator lamp flashes or lights up and a signal sounds. Make sure that the safety belts are positioned cor-

rectly. The safety belt reminder is active at speeds above approx. 5 mph/8 km/h. It can also be activated if objects are placed on the front passenger seat.

### Damage to safety belts

In the case of strain caused by accidents or damage:

Have the safety belts, including the safety belt tensioners, replaced and have the belt anchors checked.

Checking and replacing safety belts
Have the work performed only by your
service center; otherwise, it cannot be ensured
that this safety feature will function properly.

### Front Head restraints

### **Correctly adjusted head restraint**

A correctly adjusted head restraint reduces the risk of injury to cervical vertebrae in the event of an accident.

Adjusting the head restraint

Correctly adjust the head restraints of all occupied seats; otherwise, there is an increased risk of injury in an accident.

### Height

Adjust the head restraint so that its center is approximately at ear level.

### **Distance**

Adjust the distance so that the head restraint is as close as possible to the back of the head.

### **Active head restraint**

In the event of a rear-end collision with a certain severity, the active head restraint automatically reduces the distance from the head.



Reduced protective function


- Do not use seat or head restraint covers.
- Do not hang objects, e.g., clothes hangers, on the head restraints.
- Only attach accessories approved by BMW to the seat or head restraint.

Otherwise, the protective function of the active head restraint will be impaired and the personal safety of the occupants will be endangered.◀

In the case of strain caused by accidents or damage:

Have the active headrest checked and if necessary replaced.

### Adjusting the height



Adjusting electrically.

### Distance to the back of the head



- Forward: pull.
- Back: press the button and push the head restraint toward the rear.

### Adjusting the side extensions



Fold forward for increased lateral support in the resting position.

### Removing

The head restraints cannot be removed.

### **Entering the rear**

### Note


Folding back and locking the backrest Before driving away, fold back and lock the backrests; otherwise, an unexpected seat movement may cause an accident. ◄

### Unlocking the backrest



- Pull lever up to the stop.
- Fold backrest forward.

### **Controls**



- Press and hold the button until the seat has moved to the desired position. Releasing the button stops the motion.
- Press the button briefly. The seat automatically moves to the respective end position. Pressing again stops the motion.

### Folding back and locking the backrest

After entering the rear, fold the backrest back and lock it.

Press the button. The seat moves to its original position. Pressing again stops the motion.

# Changing the seat position arma Seat, mirror, and steering

### Requirements

- Vehicle at a standstill.
- When the door is open, the seat is accessible from the side on which the door is open.

# wheel memory

### General information



Two different driver's seat, exterior mirror, and steering wheel positions can be stored and retrieved for each remote control. The adjustment of the lumbar support is not stored.

### **Storing**

- 1. Switch on the ignition.
- 2. Set the desired position.
- 3. Press the button. The LED in the button lights up.
- 4. Press the desired button 1 or 2. The LED goes out.

If the M button is pressed accidentally:



Press the button again.

The LED goes out.

### **Calling up settings**

Do not retrieve the memory while driving Do not retrieve the memory setting while driving, as an unexpected movement of the seat or steering wheel could result in an accident.

### **Comfort function**

- 2. Switch off the ignition.
- 3. Briefly press the desired button 1 or 2.

The corresponding seat position is performed automatically.

The procedure stops when a switch for adjusting the seat or one of the buttons is pressed.

### Safety mode

- Close the driver's door or switch on the ignition.
- Press and hold the desired button 1 or 2 until the adjustment procedure is completed.

### Calling up of a seat position deactivated

After a brief period, the calling up of stored seat positions is deactivated to save battery power.

To reactivate calling up of a seat position:

- Open or close the door or trunk lid.
- Press a button on the remote control.
- Press the Start/Stop button.

### **Mirrors**

### **Exterior mirrors**

### At a glance



- 1 Adjusting
- 2 Left/right, Automatic Curb Monitor
- 3 Fold in and out

### 

### **General information**

The mirror on the passenger side is more curved than the driver's side mirror.

Estimating distances correctly

Objects reflected in the mirror are closer than they appear. Do not estimate the distance to the traffic behind you based on what you see in the mirror, as this will increase your risk of an accident.◀

Depending on how the vehicle is equipped, the mirror setting is stored for the remote control in use. When the vehicle is unlocked via the remote control, the position is automatically retrieved if the setting for this function is active.

### Selecting a mirror



To change over to the other mirror: Slide the mirror changeover switch.

### Adjusting electrically



The setting corresponds to the direction in which the button is pressed.

### **Saving positions**

Seat, mirror, and steering wheel memory, refer to page 50.

### **Adjusting manually**

If an electrical malfunction occurs, for example, press the edges of the mirror glass.

### **Automatic Curb Monitor**

When the reverse gear is engaged, the mirror glass tilts downward slightly on the front passenger side. This improves your view of the curb and other low-lying obstacles when parking, for example.

### **Activating**

- 1. Slide the mirror changeover switch to the driver's side mirror position.
- 2. Engage transmission position R.

### **Deactivating**

Slide the mirror changeover switch to the passenger's side mirror position.

#### Fold in and out



Press the button.

Possible up to approx. 15 mph/20 km/h.

For example, this is advantageous

- In car washes.
- In narrow streets.
- For folding back mirrors that were folded away manually.

Mirrors that were folded in are folded out automatically at a speed of approx. 25 mph/40 km/h.

Fold in the mirror in a car wash

Before washing the car in an automatic car wash, fold in the exterior mirrors by hand or with the button; otherwise, the mirrors could be damaged, depending on the width of the vehicle.

### **Automatic heating**


Both exterior mirrors are automatically heated whenever the engine is running.

### **Automatic dimming feature**

Both exterior mirrors are automatically dimmed. Photocells are used for control in the Interior rear view mirror, refer to page 52.

Interior rearview mirror, automatic dimming feature

The concept



Photocells are used for control:

- In the mirror glass.
- On the back of the mirror.

### **Functional requirement**

For proper operation:

- Keep the photocells clean.
- Do not cover the area between the inside rearview mirror and the windshield.

### Steering wheel

### **General information**

Do not adjust while driving
Do not adjust the steering wheel while
driving; otherwise, an unexpected movement
could result in an accident.

✓

### Switching on/off



Press the button.

- ▶ On: the LED lights up.
- Off: the LED goes out.

### **Adjusting**



The steering wheel can be adjusted in four directions.

# امدادحود

### تلفن شبانه روزی: ۵۸ ۲ ۲ ۸۸۸ ۲ ۲ ۸۸۸ تلفن شبانه روزی:

Seat, mirror, and steering wheel memory, refer to page 50.

### Assistance getting in and out masos.com

The steering wheel temporarily moves into the highest position to make it easier to enter and exit the vehicle.

### Steering wheel heating



### **Transporting children safely**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### The right place for children

### **Note**

Children in the vehicle

Do not leave children unattended in the vehicle; otherwise, they could endanger themselves and other persons, e.g., by opening the doors.

### Children should always be in the rear

Accident research shows that the safest place for children is in the back seat.

Transporting children in the rear

Only transport children younger than
13 years of age or shorter than 5 ft/150 cm in
the rear in child restraint fixing systems provided in accordance with the age, weight and
size of the child; otherwise, there is an increased risk of injury in an accident.

Children 13 years of age or older must wear a safety belt as soon as a suitable child restraint fixing system can no longer be used, due to their age, weight and size.◀

### Children on the front passenger seat

Should it ever be necessary to use a child restraint fixing system in the front passenger seat, make sure that the front, knee and side airbags on the front passenger side are deactivated. Automatic deactivation of front passenger side airbags, refer to page 93.

### Note

Deactivated front passenger airbags
If a child restraint fixing system is used in
the front passenger seat, the front passenger
airbags must be deactivated; otherwise, there
is an increased risk of injury to the child when
the airbags are triggered, even with a child restraint fixing system.

# Installing child restraint fixing systems

### **Hints**



Manufacturer's information for child restraint fixing systems

To select, mount and use child restraint fixing systems, observe the information provided by the system manufacturer; otherwise, the protective effect can be impaired. ◄

Lock the rear seat backrests in position
Before installing a child restraint system,
make sure that the rear seat backrests are
locked; otherwise, the protective effect is not
guaranteed and there is an increased risk of injury for the child in the event of an accident.

### On the front passenger seat

### **Deactivating airbags**

After installing a child restraint fixing system in the front passenger seat, make sure that the front, knee and side airbags on the front passenger side are deactivated.

Deactivate the front passenger airbags automatically, refer to page 93.

Deactivating the front passenger airbags If a child restraint fixing system is used in the front passenger seat, the front passenger airbags must be deactivated; otherwise, there is an increased risk of injury to the child when the airbags are triggered, even with a child restraint fixing system.

### Seat position and height

Before installing a child restraint fixing system, move the front passenger seat as far back as possible and adjust its height to the highest position to obtain the best possible position for the belt and to offer optimal protection in the event of an accident.

Do not change the seat position and height after this.

### **Backrest width**

Adjustable backrest width: before installing a child restraint fixing system in the front passenger seat, open the backrest width completely. Do not change the backrest width again and do not call up a memory position.

Backrest width for the child seat
Before installing a child restraint fixing
system in the front passenger seat, the backrest width must be opened completely. Do not
change the adjustment after this; otherwise,
the stability of the child seat will be reduced.

### **Child seat security**



The rear safety belts and the front passenger safety belt can be locked against pulling out for mounting the child restraint fixing systems.

### Locking the safety belt

- 1. Pull out the belt webbing completely.
- Secure the child restraint fixing system with the belt.
- Allow the belt webbing to be pulled in and pull it taut against the child restraint fixing system. The safety belt is locked.

### Unlocking the safety belt

- 1. Unbuckle the belt buckle.
- 2. Remove the child restraint fixing system.
- Allow the belt webbing to be pulled in completely.

# **LATCH** child restraint fixing system

LATCH: Lower Anchors and Tether for CHildren.

### Note



Manufacturer's information for LATCH child restraint fixing systems

To mount and use the LATCH child restraint fixing systems, observe the operating and safety information from the system manufacturer; otherwise, the level of protection may be reduced.◀

### Mounts for the lower LATCH anchors

The lower anchors may be used to attach the CRS to the vehicle seat up to a combined child and CRS weight of 65 lb/30 kg when the child is restr- ained by the internal harnesses.



Correctly engage the lower LATCH anchors

Make sure that the lower LATCH anchors have properly engaged and that the child restraint fixing system is resting snugly against the backrest; otherwise, the degree of protection offered may be reduced. ◀

Before mounting the LATCH child restraint fixing system, pull the belt away from the child restraint fixing system.




Mounts for the lower LATCH anchors are located in the gap between the seat and backrest.

# Mounting ISOFIX child restraint fixing systems

- Mount the child restraint fixing system; refer to the user's manual of the system.
- Ensure that both LATCH anchors are properly connected.

# Child restraint fixing system with a tether strap

### **Mounting points**



There are two mounting points for child restraint fixing systems with a tether strap.

### Note


Mounting eyes

Only use the mounting eyes for the upper retaining strap to secure child restraint fixing systems; otherwise, the mounting eyes could be damaged.

# تلفن شبانه روزی: Retaining strap quide

Retaining strap

Make sure the upper retaining strap does not run over sharp edges and is not twisted as it passes to the top anchor. Otherwise, the strap will not properly secure the child restraint fixing system in the event of an accident.



- Direction of travel
- 2 Upper retaining strap

- 3 Head restraint.
- 4 Rear window shelf
- 5 Mounting point/eye
- 6 Hook for upper retaining strap

# Attaching the upper retaining strap to the mounting point

- 1. Lift the cover over the mounting point.
- Guide the upper retaining strap over the head restraint.
- 3. Attach the hooks of the retaining strap to the mounting eyes.
- 4. Tighten the retaining strap by pulling it down.



تلفن شبانه روزی: ۱۳۰۸۸۸۶۲ ۲۸ ا

FarmaSOS.com

### **Driving**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **Start/Stop button**

### The concept



Pressing the Start/Stop button switches the ignition on or off and starts the engine.

Automatic transmission: The engine starts if the brake is de-

pressed while pressing the Start/Stop button.

### **Ignition on**

Automatic transmission: Press the Start/Stop button but do not depress the brake.

All vehicle systems are ready for operation.

Most of the indicator and warning lamps in the instrument cluster light up for varying lengths of time.

To save battery power when the engine is off, switch off the ignition and any unnecessary electronic systems/power consumers.

The ignition switches off automatically:

- When locking the vehicle, even if the low beams are switched on.
- Shortly before the battery is discharged completely, so that the engine can still be started.

### Note

If the engine is switched off and the ignition is switched on, the system automatically switches to the radio ready state when the door is opened if the lights are switched off or the daytime running lights are switched on.

### Ignition off

Automatic transmission: Press the Start/Stop button again, but do not depress the brake.

All indicator lamps in the instrument cluster go out.

To save battery power when the engine is off, switch off the ignition and any unnecessary electronic systems/power consumers.



Transmission position P with the ignition off

When the ignition is switched off, position P is engaged automatically. When in an automatic car wash, for example, ensure that the ignition is not switched off accidentally. ◀

The ignition automatically cuts off while the vehicle is stationary and the engine is stopped:

- When locking the vehicle, and when the low beams are activated.
- Shortly before the battery is discharged completely, so that the engine can still be started. This function is only available when the low beams are switched off.
- When opening or closing the driver door, if the driver's seat belt is unbuckled and the low beams are switched off.
- While the driver's seat belt is unbuckled, if the driver's door is open and the low beams are switched off.

When the ignition is switched off, by opening or closing the driver's door or unbuckling the driver's seat belt, the radio ready state remains active.

### Radio ready state

Activate radio ready state:

When the engine is running: press the Start/Stop button.

Some electronic systems/power consumers remain ready for operation.

The radio ready state switches off automatically:

- After approx. 8 minutes.
- When the vehicle is locked using the central locking system.
- Shortly before the battery is discharged completely, so that the engine can still be started.

### Starting the engine

### **Hints**

Enclosed areas

Do not let the engine run in enclosed areas; otherwise, breathing of exhaust fumes may lead to loss of consciousness and death. The exhaust gases contain carbon monoxide, an odorless and colorless but highly toxic gas.

Unattended vehicle

Do not leave the vehicle unattended with the engine running; doing so poses a risk of danger.

Before leaving the vehicle with the engine running, set the parking brake and place the transmission in position P or neutral to prevent the vehicle from moving. ◄

Repeated starting in quick succession
Avoid repeated unsuccessful attempts to
start the vehicle or starting the vehicle several
times in quick succession. Otherwise, the fuel
is not burned or is inadequately burned, posing
a risk of overheating and damage to the catalytic converter.

Do not wait for the engine to warm-up while the vehicle remains stationary. Start driving at moderate engine speeds.

### **Automatic transmission**

### Starting the engine

- Depress the brake pedal.
- Press the Start/Stop button.

The ignition is activated automatically for a certain time and is stopped as soon as the engine starts.

### **Engine stop**

### **Hints**

Take the remote control with you when leaving the vehicle so that children, for example, cannot start the engine.



Set the parking brake and further secure the vehicle as required

Set the parking brake firmly when parking; otherwise, the vehicle could roll. On steep upward and downward inclines, further secure the vehicle, for example, by turning the steering wheel in the direction of the curb. ◀

### Before driving into a car wash

In order for the vehicle to be able to roll into a car wash, heed the information regarding Washing in automatic car washes, refer to page 215.

### **Automatic transmission**

### Switching off the engine

- Engage transmission position P with the vehicle stopped.
- Press the Start/Stop button. The engine is switched off.

The radio ready state is switched on.

3. Set the parking brake.

# **Automatic Engine Start/Stop Function**

### The concept

The Auto Start/Stop function helps save fuel. The system switches off the engine during a stop, e.g., in a traffic congestion or at traffic lights. The ignition remains switched on. The engine starts again automatically for driving off.

Certain vehicle components may experience additional wear as a result of this system.

### **Automatic mode**

The Auto Start/Stop function is operational after each engine start.

This function is activated at speeds faster than about 3 mph, approx. 5 km/h.

### **Engine stop**

The engine is switched off automatically during a stop under the following conditions:

Automatic transmission:

- The selector lever is in transmission position D.
- The brake pedal remains pressed while the vehicle is stationary or the vehicle is held by Automatic Hold.
- The driver's seat belt is buckled or the driver's door is closed.

The air volume of the air conditioner is reduced when the engine is switched off.

### Displays in the instrument cluster



The display indicates that the automatic engine start-stop function is ready for an automatic engine start.



The display indicates that the conditions for an automatic engine stop have not been satisfied.

#### Note

The engine is not switched off automatically in the following situations:

- External temperature too low.
- ➤ The external temperature is high and automatic climate control is running.
- The passenger compartment has not yet been heated or cooled to the required level.
- The engine is not yet at operating temperature.
- The wheels are at a sharp angle or the steering wheel is being turned.
- After driving in reverse.
- Fogging of the windows when the automatic climate control is switched on.
- Vehicle battery is heavily discharged.
- ▶ The engine compartment lid is unlocked.
- ▶ HDC Hill Descent Control is activated.
- The parking assistant is activated.
- Stop-and-go traffic.
- The transmission selector lever is in position N or M/S.
- Use of fuel with high ethanol content.

### Starting the engine

The engine starts automatically under the following conditions:

Automatic transmission:
 By releasing the brake pedal.
 When Automatic Hold is activated: press

the accelerator.

After the engine starts, accelerate as usual.

### Safety mode

After the engine switches off automatically, it will not start again automatically if any one of the following conditions are met.

- ▶ The driver's safety belt is unbuckled and the driver's door is open.
- The hood was unlocked.

Some indicator lamps light up for varying lengths of time.

The engine can only be started via the Start/Stop button.

### Note

Even if driving away was not intended, the deactivated engine starts up automatically in the following situations:

- Excessive warming of the passenger compartment when the cooling function is switched on.
- The steering wheel is turned.
- Automatic transmission: the transmission position is changed from D to N, R, or M/S.
- Automatic transmission: the transmission position is changed from P to N, D, R or M/S.
- Fogging of the windows when the automatic climate control is switched on.
- Vehicle battery is heavily discharged.
- Excessive cooling of the passenger compartment when the heating is switched on.

# Activating/deactivating the system manually

### Using the button





Press the button.

- LED comes on: Auto Start Stop function is deactivated.
  - The engine is started during an automatic engine stop.
  - The engine can only be stopped or started via the Start/Stop button.
- LED goes out: Auto Start Stop function is
   activated, تلفر

# Switching off the vehicle during an automatic engine stop

During an automatic engine stop, the vehicle can be switched off permanently, e.g., when leaving it.

- Press the Start/Stop button. The ignition is switched off. The Auto Start/Stop function is deactivated.
  - Transmission position P is engaged automatically.
- Set the parking brake.

Engine start as usual via Start/Stop button.

### **Automatic deactivation**

In certain situations, the Auto Start/Stop function is deactivated automatically for safety reasons, such as when the driver is detected to be absent.

### Malfunction

The Auto Start/Stop function no longer switches of the engine automatically. A Check Control message is displayed. It is possible to continue driving. Have the system checked.

### **Parking brake**

### The concept

The parking brake is used to prevent the vehicle from rolling when it is parked.



### **Setting**



Pull the switch.

The LED lights up.



The indicator lamp lights up red. The parking brake is set.



Lower lamp: indicator lamp in Canadian models



Set the parking brake and further secure the vehicle as required

Set the parking brake firmly when parking; otherwise, the vehicle could roll. On steep upward and downward inclines, further secure the vehicle, for example, by turning the steering wheel in the direction of the curb. ◀

### While driving

Use while driving serves as an emergency braking function:

Pull the switch and hold it. The vehicle brakes hard while the switch is being pulled.



The indicator lamp lights up red, a signal sounds and the brake lamps light up.



Lower lamp: indicator lamp in Canadian models.

If the vehicle is braked to a speed of approx. 2 mph/3 km/h, the parking brake remains set.

### Releasing

With the ignition switched on:



Automatic transmission: Press the switch while the brake is pressed or

transmission position P is engaged.

The LED and indicator lamp go out.

The parking brake is released.

## Automatic Release in cars with automatic transmission

The LED and indicator lamp go out.

Subject to the following requirements, the parking brake is automatically released by operation of the accelerator pedal:

- Engine on.
- Drive position engaged.
- Driver buckled in and doors closed.



Inadvertent operation of the accelerator pedal

Make sure that the accelerator pedal is not operated unintentionally; otherwise, the vehicle is set in motion and there is a risk of an accident.◀

### **Automatic Hold**

### The concept

This system assists the driver by automatically setting and releasing the brake, such as when moving in stop-and-go traffic.

The vehicle is automatically held in place when it is stationary.

On inclines, the system prevents the vehicle from rolling backward when driving away.



### For your safety

Under the following conditions, Automatic Hold is automatically deactivated and the parking brake is set:

- The engine is switched off.
- A door is opened and driver's safety belt is unbuckled while the vehicle is stationary.
- The moving vehicle is brought to a standstill using the parking brake.



The indicator lamp switches from green to red and the letters AUTO H go out.



Lower lamp: indicator lamp in Canadian models.



Leaving the vehicle with the engine running

Before leaving the vehicle with the engine running, engage position P of the automatic transmission and ensure that the parking brake is set. Otherwise, the vehicle may begin to roll. ◀

### **Activating**

This function can be activated when the driver's door is closed and the safety belt is fastened, and while driving.



Press the button.

The LED and the letters AUTO H light

up.



The indicator lamp lights up.

Automatic Hold is activated.

### **Deactivating**



Press the button again.

The LED and the letters AUTO H go

Automatic Hold is deactivated.

If the vehicle is being held by Automatic Hold, press on the brake pedal to deactivate it.

When the parking brake is set manually, Automatic Hold is deactivated automatically.

#### لفن شبانه روزي: ال **Driving**

Automatic Hold is activated: the vehicle is automatically secured against rolling after braking to a standstill.

PARK

The indicator lamp lights up green.

Step on the accelerator pedal to drive off.



The brake is released automatically.

The indicator lamp goes out.

Lower lamp: indicator lamp in Canadian models

Before driving into a car wash
Before driving into the car wash, deactivate Automatic Hold; otherwise, the parking brake will be set when the vehicle is stationary and the vehicle will no longer be able to roll.

### **Parking**

The parking brake is automatically set if the engine is switched off while the vehicle is being held by Automatic Hold.



The indicator lamp changes from green to red.



The parking brake is not set if the engine is switched off while the vehicle is coasting to a halt. Automatic Hold is

deactivated.

Lower lamp: indicator lamp in Canadian models

Automatic Hold remains activated during the engine stop brought about by the Auto Start/Stop function.

Take the remote control with you when leaving the vehicle so that children, for example, cannot release the parking brake. ◄

### Malfunction

In the event of a failure or malfunction of the parking brake, secure the vehicle against rolling using a wheel chock, for example, when leaving it.

### After a power failure



Only put the parking brake into operation after a power failure

The parking brake should only be put into operation again if it was manually released due to an interruption in the supply of electrical power. Otherwise, it cannot be ensured that the parking brake will function properly.◀

# Putting the parking brake into operation

1. Switch on the ignition.

 Press the switch while the brake is depressed or transmission position P is engaged. It may take several seconds for the brake to be put into operation. Any sounds associated with this are normal.



The indicator lamp in the instrument cluster goes out as soon as the parking brake is ready for operation.




Lower lamp: indicator lamp in Canadian models.

# Turn signal, high beams, headlamp flasher

### **Turn signal**

### **Using turn signals**



Press the lever beyond the resistance point. To switch off manually, press the lever to the resistance point.

Unusually rapid flashing of the indicator lamp indicates that a turn signal bulb has failed.

### Triple turn signal activation

Press the lever to the resistance point.

The turn signal flashes three times.


The function can be activated or deactivated:

- "Settings"
- 2. "Lighting"
- 3. "Triple turn signal"

### Signaling briefly

Press the lever to the resistance point and hold it there for as long as you want the turn signal to flash.

### High beams, headlamp flasher



- High beams, arrow 1.
- ▶ Headlamp flasher, arrow 2.

### Washer/wiper system

# Switching the wipers on/off and brief wipe

Do not switch on the wipers if frozen
Do not switch on the wipers if they are
frozen onto the windshield; otherwise, the
wiper blades and the windshield wiper motor
may be damaged.

✓

No wiper operation on dry windshield Do not use the windshield wipers if the windshield is dry, as this may damage the wiper blades or cause them to become worn more quickly.◀

### Switching on




Press the wiper levers up.

The lever automatically returns to its initial position when released.

- Normal wiping speed: press up once.
- The wipers switch to intermittent operation when the vehicle is stationary.
- Fast wiping speed: press up twice or press once beyond the resistance point.

The wipers switch to normal speed when the vehicle is stationary.

### Switching off and brief wipe



Press the wiper levers down.

The lever automatically returns to its initial position when released.


- Brief wipe: press down once.
- To switch off normal wipe: press down once.
- ▶ To switch off fast wipe: press down twice.

### Rain sensor

### The concept

The rain sensor automatically controls the time between wipes depending on the intensity of the rainfall. The sensor is located on the windshield, directly behind the interior rearview mirror.

### Activating/deactivating




Press the button on the wiper lever.

The LED in the wiper lever lights up and a wiping operation is started. At temperatures below 32 °F/0 °C, a wiping operation is not started.


Deactivate the rain sensor in car washes Deactivate the rain sensor when passing through an automatic car wash; otherwise, damage could be caused by undesired wiper activation.◀

### Rain sensor, sensitivity



Turn the thumbwheel.

### Clean the windshield, headlamps



Pull the wiper lever.

The system sprays washer fluid on the windshield and activates the wipers briefly.

In addition, the headlamps are cleaned at regular intervals when the vehicle lights are switched on.



Do not use the washer system at freezing temperatures

Do not use the washers if there is any danger that the fluid will freeze on the windshield: otherwise, your vision could be obscured. For this reason, use antifreeze.

Avoid using the washer when the reservoir is empty; otherwise, you could damage the pump.∢

### Windshield washer nozzles

The windshield washer nozzles are automatically heated while the ignition is switched on.

### Fold-out position of the wipers

Required when changing the wiper blades or under frosty conditions, for example.

- Switch the ignition on and off again.
- 2. Under frosty conditions, ensure that the wiper blades are not frozen onto the windshield.
- 3. Press the wiper lever up beyond the point of resistance and hold it for approx. 3 seconds, until the wiper remains in a nearly vertical position.

After the wipers are folded back down, the wiper system must be reactivated.

Fold the wipers back down

Before switching the ignition on, fold the wipers back down to the windshield; otherwise, the wipers may become damaged when they are switched on.

- 1. Switch on the ignition.
- Press the wiper levers down. The wipers move to their resting position and are ready for operation.

### Washer fluid

### **General information**

Antifreeze for washer fluid
Antifreeze is flammable and can cause injury if it is used incorrectly.

Therefore, keep it away from sources of ignition.

Only keep it in the closed original container and inaccessible to children.

Follow the notes and instructions on the container.

United States: The washer fluid mixture ratio is regulated by the U.S. EPA and many individual states; do not exceed the allowable washer fluid dilution ratios limits that apply. Follow the usage instructions on the washer fluid container. Use BMW's Windshield Washer Concentrate or the equivalent.◀

### Washer fluid reservoir

Adding washer fluid
Only add washer fluid when the engine is cool, and then close the cover completely to avoid contact between the washer fluid and hot engine parts.

Otherwise, there is the danger of fire and a risk to personal safety if the fluid is spilled. ◀



All washer nozzles are supplied from one reservoir.

Fill with a mixture of windshield washer concentrate and tap water and – if required – with a washer antifreeze, according to the manufacturer's recommendations.

Mix the washer fluid before adding to maintain the correct mixing ratio.

Do not add windshield washer concentrate and antifreeze undiluted and do not fill with pure water; this could damage the wiper system.

Do not mix window washer concentrates of different manufacturers, because otherwise it can result in clogging of the windshield washer nozzles.

For the capacity, refer to technical data.

### Automatic transmission with Steptronic

### **Transmission positions**

### D Drive, automatic position

Position for normal vehicle operation. All forward gears are available.

#### R is Reverse

Select only when the vehicle is stationary.

#### N is Neutral

Use in automatic car washes, for example. The vehicle can roll.

When the ignition is switched off, refer to page 58, position P is engaged automatically.

#### P Park

Select only when the vehicle is stationary. The drive wheels are blocked.

P is engaged automatically:

- After the engine is switched off when the vehicle is in radio ready state, refer to page 59, or when the ignition is switched off, refer to page 58, and when position R or D is engaged.
- With the ignition is off, if position N is engaged.
- If the safety belt is unbuckled, the driver's door is opened, and the brake pedal is not pressed while the vehicle is stationary and transmission position R or D is engaged.

Before exiting the vehicle, make sure that position P of the automatic transmission is engaged. Otherwise, the vehicle may begin to roll.

### **Kickdown**

Kickdown is used to achieve maximum driving performance. Press on the gas pedal beyond the resistance point at the full throttle position.

### **Engaging the transmission position**

- Transmission position P can only be disengaged if the engine is running and the brake pedal is pressed.
- With the vehicle stationary, press on the brake pedal before shifting out of P or N; otherwise, the shift command will not be executed: shift lock.



Depress the brake until you start driving

To prevent the vehicle from creeping after you select a driving position, maintain pressure on the brake pedal until you are ready to start. ◀

### **Engaging D, R and N**



Briefly push the selector lever in the desired direction, beyond a resistance point if necessary.

After releasing the selector lever, it returns to its center position.



Press unlock button, in order to:

- Engage R.
  - Shift out of P.

### **Engaging P**



Press button P.

### Sport program and manual mode

### **Activating the sport program**



Push the selector lever to the left out of transmission position D.

In the instrument cluster, DS is displayed, or the engaged gear, e.g., S1 with the Sport automatic transmission.

The sport program of the transmission is activated

### Activating the M/S manual mode

- Push the selector lever to the left out of transmission position D.
- Push the selector lever forward or pull it backward.

Manual mode becomes active and the gear is changed.

The engaged gear is displayed in the instrument cluster, e.g., M1.

Once maximum engine speed is attained, or if the engine is getting too hot, M/S manual mode is automatically upshifted as needed.

### Switching to manual mode

- To shift down: press the selector lever forward.
- To shift up: pull the selector lever rearwards.

Gears will only be shifted at appropriate engine and road speeds and when necessary due to the temperature of the drivetrain, e.g., downshifting is not possible if the engine speed is too high.

The selected gear is briefly displayed in the instrument cluster, followed by the current gear.

# Sport automatic transmission: prevent automatic upshifting in M/S manual mode

For vehicles with Sport automatic transmissions, automatic shift operations are not performed, at maximum engine speed for example, if one of the following conditions is met:

- DSC deactivated.
- TRACTION activated.
- SPORT+ activated.

In addition, the kickdown is deactivated.

# Ending the sport program/manual mode

Push the selector lever to the right.

D is displayed in the instrument cluster.

### Shift paddles



The shift paddles on the steering wheel allow you to shift gears quickly while keeping both hands on the steering wheel.

If the shift paddles on the steering wheel are used to shift gears in automatic mode, the transmission temporarily switches to manual mode.

If the shift paddles are not used and the vehicle is not accelerated for a certain time, the system switches back into automatic mode if the selector lever is in transmission position D.

- Shift up: pull right shift paddle.
- Shift down: pull left shift paddle.

Gears will only be shifted at appropriate engine and road speeds, e.g., downshifting is not possible if the engine speed is too high.

The selected gear is briefly displayed in the instrument cluster, followed by the current gear.

### Displays in the instrument cluster



The transmission position is displayed, e.g.: P.

### Shift lights in the instrument display

### The concept

Shift lights display the optimum shift point for sport displays in the multifunction instrument display. Thus, with a sporty driving style, the best possible vehicle acceleration is achieved.

### Display in the instrument display



ىلقن سبانە رورى**. ١٠٠٠** 

- Current engine speed is displayed in the tachometer.
- Arrow 1: successive yellow illuminated fields indicate the upcoming upshift moment.
- Arrow 2: fields are illuminated in red. Do not wait any further to shift.

When the maximum possible speed is reached, the entire display flashes. When the maximum speed is exceeded, the supply of fuel is interrupted in order to protect the engine. Speeds in this range must be avoided.

### **Displays**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### Instrument cluster




- 1 Fuel gauge 77
- 2 Speedometer
- 3 Indicator/warning lamps 75
- 4 Tachometer 77

- 5 Oil temperature 77
- 6 Electronic displays 72
- 7 Reset miles 78

### **Electronic displays**

### **Overview, instrument cluster**



- Messages, e.g. Check Control 75
  Time 78
- 2 Range 78
- 3 Computer 82
- 4 Navigation display, see user's manual for Navigation, Entertainment and Communication.

Service requirements 79

- Miles/trip miles 78
- 5 Selection list, e.g., radio 82 Current fuel consumption 79

Energy recovery 79

External temperature 78

Transmission display 70

# **Multifunctional instrument display**


### The concept

The instrument dispaly is a variable display. When the driving mode is changed, the ap-

pearance is changed to reflect the new driving mode. The change of appearance can be deactivated in the Control Display.

Some of the displays in the instrument display may differ from the way they are shown in this owner's manual.

### At a glance



- 1 Fuel gauge 77
- 2 Indicator/warning lamps 75
- 3 Speedometer
- 4 Variable displays
- 5 Tachometer 77

Selection lists 82

ECO PRO displays 174

- 6 Oil temperature 77
  - 7 Computer 82
- 8 Reset miles 78

## FarmaSOS.com

### Switching the change of display on and off

You can set whether the instrument display automatically changes to the ECO PRO or SPORT in the display when you switch driving modes.


- 1. "Settings"
- 2. "Info display"
- "ECO PRO Info" or "Driving mode view"

# With Professional Navigation System: switching zoom function on/off Switching

You can program whether the current speed is to appear enlarged in the speedometer.

- 1. "Settings"
- 2. "Info display"
- 3. "Magnifier function"

### **ECO PRO displays**




- 1 Speedometer
- Variable displays: ECO PRO Tips, Deceleration assistant instructions, Driver assist system displays
- 3 Efficiency display 174

- 4 Transmission display 70
- **5** ▶ Blue: bonus range
  - Gray: range

In ECO PRO driving mode, the instrument display switches to the ECO PRO displays. These displays support a driving style that saves on

fuel consumption with more prominent representation of the efficiency display and various ECO PRO tips.

### **Sport displays**



- Speedometer
- 2 Tachometer
- 3 Transmission display 70

- 4 Shift lights, when appropriately equipped
- 5 Performance display

In the Sport and Sport+ modes, the instrument display switches to the sport displays. This display supports a sporty driving style with more prominent representation of the tachometer, the transmission displays, and the vehicle speed.

Check Control

### The concept

The Check Control system monitors functions in the vehicle and notifies you of malfunctions in the monitored systems.

A Check Control message is displayed as a combination of indicator or warning lamps and text messages in the instrument cluster and in the Head-up Display.

In addition, an acoustic signal may be output and a text message may appear on the Control Display.

### **Indicator/warning lamps**

The indicator and warning lamps in the instrument cluster can light up in a variety of combinations and colors.

Several of the lamps are checked for proper functioning and light up temporarily when the engine is started or the ignition is switched on.

### **Overview: indicator/warning lamps**

### Symbol Function or system



Turn signal.



Parking brake.



Parking brake in Canadian models.



Automatic hold.



Front fog lamps.



High beams.



High-beam Assistant.



Parking lamps, headlamp control.



Active Cruise Control. 2



Vehicle detection, Active Cruise Control: collision warning.



Cruise control.



Lane departure warning.



DSC Dynamic Stability Control.



DSC Dynamic Stability Control or DTC Dynamic Traction Control

### Symbol Function or system



Tire Pressure Monitor.

Flat Tire Monitor.



Safety belts.



Airbag system.



Steering system.



Engine functions.



Engine functions in Canadian models.



Brake system.



Brake system in Canadian models.



ABS Antilock Brake System.



ABS Antilock Brake System in Canadian models.



At least one Check Control message is displayed or is stored.

### **Text messages**

Text messages in combination with a symbol in the instrument cluster explain a Check Control message and the meaning of the indicator and warning lamps.

### Supplementary text messages

Additional information, such as on the cause of a fault or the required action, can be called up via Check Control.

The supplementary text of urgent messages is automatically displayed on the Control Display.

### **Symbols**

Depending on the Check Control message, the following functions can be selected.

- ▶ ☐i "Owner's Manual"
   Display additional information about the Check Control message in the Integrated Owner's Manual.
- "Service request"Contact the service partner.
- Roadside Assistance"Contact Roadside Assistance.

### **Hiding Check Control messages**



Press the computer button on the turn signal lever.

- Some Check Control messages are displayed continuously and are not cleared until the malfunction is eliminated. If several malfunctions occur at once, the messages are displayed consecutively.
  - These messages can be hidden for approx. 8 seconds. After this time, they are displayed again automatically.
- Other Check Control messages are hidden automatically after approx. 20 seconds.
   They are stored and can be displayed again later.

# **Displaying stored Check Control messages**

- 1. "Vehicle Info"
- "Vehicle status"
- ∴ Check Control
- 4. Select the text message.

### Messages after trip completion

Special messages that are displayed during driving are displayed again after the ignition is switched off.

### **Fuel gauge**



The vehicle inclination may cause the display to vary.

US models: the arrow beside the fuel pump symbol shows which side of the vehicle the fuel filler

flap is on.

Hints on refueling, refer to page 182.

 $\Lambda \Delta$ : تلفن شبانه روزی

### **Tachometer**

Always avoid engine speeds in the red warning field. In this range, the fuel supply is interrupted to protect the engine.

### **Engine oil temperature**



- Cold engine: the pointer is at the low temperature end.
   Drive at moderate engine and vehicle speeds.
- Normal operating temperature: the pointer is in the middle or in the left half of the temperature display.
- Hot engine: the pointer is at the high temperature end. A Check Control message is also displayed.

### **Coolant temperature**

If the coolant along with the engine becomes too hot, a Check Control message is displayed.

Check the coolant level, refer to page 201.

### Odometer and trip odometer



- Odometer, arrow 1.
- Trip odometer, arrow 2.

### Display/reset miles



Press the knob.

- When the ignition is switched off, the time, the external temperature and the odometer are displayed.
- When the ignition is switched on, the trip odometer is reset.

### **External temperature**

### **External temperature warning**



If the indicator drops to +37 °F/+3 °C or lower, a signal sounds.

A Check Control message is displayed.

There is the increased danger of ice.

Ice on roads Even at temperatures above +37 °F/+3 °C, there can be a risk of ice on roads.

Therefore, drive carefully on bridges and shaded roads, for example, to avoid the increased risk of an accident. ◀

### Time



The time is displayed at the bottom of the instrument cluster.

Setting the time and time format, refer to page 84.

### Date



The date is displayed in the computer.

Setting the date and date format, refer to page 85.

## Range



After the reserve range is reached:

- A Check Control message is displayed briefly.
- The remaining range is shown on the computer.
- When a dynamic driving style is used, such as when cornering quickly, operation of the engine is not always ensured.

The Check Control message appears continuously below a range of approx. 30 miles/50 km.

Refuel promptly

Refuel no later than at a range of 30 miles/50 km, or operation of the engine is not ensured and damage may occur. ◄

### Displaying the cruising range

- 1. "Settings"
- "Info display"
- "Additional indicators"

The range is displayed in the instrument cluster.

# Range when destination guidance is activated in the navigation system



When destination guidance is activated in the navigation system, the range up to the destination is displayed.

The current service requirements can be read out from the remote control by the service specialist.

With TeleService, data regarding the service status or legally mandated inspections of your vehicle are automatically transmitted to your service center before the service due date.

### **Current fuel consumption**



Displays the current fuel consumption. You can check whether you are currently driving in an efficient and environmentally-friendly manner.

# Detailed information on service requirements

More information on the scope of service required can be displayed on the Control Display.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. Service required"

Required maintenance procedures and legally mandated inspections are displayed.

Select an entry to call up detailed information.

# Displaying the current fuel consumption

- 1. "Settings"
- 2. "Info display"
- "Additional indicators"

The bar display for the current fuel consumption is displayed in the instrument cluster.

Energy recovery Farma

## **Exmbols**

## Symbols Description



No service is currently required.



The deadline for service or a legally mandated inspection is approaching.



The service deadline has already passed.

## **Service requirements**

### **Display**



The driving distance or the time to the next scheduled maintenance is displayed briefly after the ignition is switched on.

The kinetic energy of the vehicle

is converted to electrical energy while coasting. The vehicle bat-

tery is partially charged and fuel

consumption can be lowered.

### **Entering appointment dates**

Enter the dates for the required inspections. Ensure that the vehicle date and time are set correctly.

- "Vehicle Info"
- "Vehicle status"
- 3. Service required"

- 4. "§ Vehicle inspection"
- 5. "Date:"
- 6. Adjust the settings.
- Confirm.The entered date is stored.

### **Automatic Service Request**

Data regarding the service status or legally mandated inspections of the vehicle are automatically transmitted to your service center before a service due date.

You can check when your service center was notified.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. Open "Options".
- 4. "Last Service Request"

# و فارما

### Gear shift indicator

### The concept

The system recommends the most fuel efficient gear in the current driving situation.

Depending on how the vehicle is equipped and the country-specific version of the vehicle, the gear shift indicator is active in the manual mode of the automatic transmission and in the manual transmission.

Indicators to shift up or down are displayed in the instrument cluster.

On vehicles without a gear shift indicator, the engaged gear is displayed.

### **Automatic transmission: displays**

Example	Description
3	Fuel efficient gear is engaged.
3>4	Shift into fuel efficient gear.

# Speed limit detection with No Passing Information

### The concept

### **Speed limit detection**

Speed limit detection uses a symbol in the shape of a traffic sign to display the currently detected speed limit. The camera at the base of the interior rearview mirror detects traffic signs at the edge of the road as well as variable overhead sign posts. Traffic signs with extra symbols for wet road conditions, etc. are also detected and compared with vehicle interior data, such as for the rain sensor, and are displayed depending on the situation. The system takes into account the information stored in the navigation system and also displays speed limits present on routes without signs.

### **No Passing Information**

No Passing Information in the instrument cluster displays the beginnings and ends of no passing zones detected by the camera. The system accounts for only the beginnings and ends of No Passing zones marked by signs.

No display is shown:

- In countries where No Passing zones are primarily identified with road markings.
- On routes without signage.
- Where there are railroad crossings, highway markings or other situations where no

signage is present, but passing would not be permitted.

#### Hints


Personal judgment

The system cannot serve as a substitute for the driver's personal judgment of the traffic situation.

The system assists the driver and does not replace the human eye. ◀

### At a glance

#### Camera



The camera is located near the base of the mirror

Keep the windshield in the area behind the interior rear view mirror clean and clear.

### Switching on/off

- 1. "Settings"
- 2. "Info display"
- "Speed limit information"

If speed limit detection is switched on, it can be displayed on the info display in the instrument cluster via the onboard computer. No Passing Information is displayed together with the activated speed limit information.

### **Display**

The following is displayed in the instrument cluster.

### **Speed limit detection**



Current speed limit.



Speed limit detection is not available.

Speed limit detection can also be displayed in the Head-up Display.

### **No Passing Information**



- Start of No Passing zone.
- ▶ End of No Passing zone.
- No Passing Information not available.

No Passing Information can also be displayed in the Head-up Display.

### **System limits**

The system may not be fully functional and may provide incorrect information in the following situations:

- ▶ In heavy fog, rain or snowfall.
- When signs are concealed by objects.
- When driving very close to the vehicle in front of you.
- When driving toward bright lights.
- When the windshield behind the interior rearview mirror is fogged over, dirty or covered by a sticker, etc.
- In the event of incorrect detection by the camera.
- ▶ If the speed limits stored in the navigation system are incorrect.
- In areas not covered by the navigation system.

- When roads differ from the navigation, such as due to changes in the road network.
- When passing buses or trucks with a speed sticker.
- ▶ If the traffic signs are non-conforming.
- During calibration of the camera immediately after vehicle shipment.

# Selection lists in the instrument cluster


### The concept



The following can be operated using the buttons and the thumbwheel on the steering wheel:

- Current audio source.
- Redial on telephone.
- Activation of the voice activation system.

# Activating a list and creating the setting



On the right side of the steering wheel, turn the thumbwheel to activate the corresponding list.

Using the thumbwheel, select the desired setting and confirm it by pressing the thumbwheel.

## Computer

### Indication in the info display



The information from the onboard computer is shown in the info display in the instrument cluster.

# Calling up information on the info display



Press the onboard computer button on the turn signal lever.

Information is displayed on the info display of the instrument cluster.

### Information at a glance

Repeatedly pressing the button on the turn signal lever calls up the following information on the info display:

- Range.
- Average fuel consumption.
- Average speed.
- Date.
- Speed limit detection.
- Time of arrival.

When destination guidance is activated in the navigation system.

- Distance to destination.
  - When destination guidance is activated in the navigation system.
- Arrow view of navigation system.
   When destination guidance is activated in the navigation system.
  - When the arrow view in the Head-up Display is inactive.

### Adjusting the info display

You can select what information from the onboard computer is to be displayed on the info display of the instrument cluster.

- 1. "Settings"
- 2. "Info display"
- 3. Select the desired displays.

#### Information in detail

### Range

Displays the estimated cruising range available with the remaining fuel.

It is calculated based on your driving style over the last 20 miles/30 km. If there is only enough fuel left for less than 45 miles/80 km, the color of the display changes.

### Average fuel consumption

The average fuel consumption is calculated for the period during which the engine is running.

The average fuel consumption is calculated for the distance traveled since the last reset by the onboard computer.

### Average speed

Periods in which the vehicle is parked with the engine manually stopped do not enter into the calculation of the average speed.

### Resetting average values

Press and hold the computer button on the turn signal lever.

### Distance to destination

The distance remaining to the destination is displayed if a destination is entered in the navigation system before the trip is started.

The distance to the destination is adopted automatically.

### تلفن شبانه روزي: Time of arrival



The estimated time of arrival is displayed if a destination is entered in the navigation system before the trip is started.

The time must be correctly set.

### Speed limit detection

Description of the speed limit detection, refer to page 80, function.

### Speed limit

Display of a speed limit which, when reached, should cause a warning to be issued.

The warning is repeated if the vehicle speed drops below the set speed limit once by at least 3 mph/5 km/h.

# Displaying, setting or changing the limit

- 1. "Settings"
- 2. "Speed"
- 3. "Warning at:"
- 4. Turn the controller until the desired limit is displayed.
- 5. Press the controller.

The speed limit is stored.

### **Activating/deactivating the limit**

- 1. "Settings"
- 2. "Speed"
- 3. "Warning"
- 4. Press the controller.

### Setting your current speed as the limit

- 1. "Settings"
- 2. "Speed"
- "Select current speed"
- 4. Press the controller.

The current vehicle speed is stored as the limit.

### **Trip computer**

The vehicle features two types of computer.

- "Onboard info": the values can be reset as often as necessary.
- "Trip computer": the values provide an overview of the current trip.

### Resetting the trip computer

- 1. "Vehicle Info"
- 2. "Trip computer"
- 3. "Reset": all values are reset.

"Automatically reset": all values are reset approx. 4 hours after the vehicle comes to a standstill.

### **Display on the Control Display**

Display the onboard computer or trip computer on the Control Display.

- 1. "Vehicle Info"
- 2. "Onboard info" or "Trip computer"

# Resetting the fuel consumption or speed

- 1. "Vehicle Info"
- 2. "Onboard info"
- "Consumpt." or "Speed"
- 4. "Yes"

# Settings on the Control Display

Time

### Setting the time zone

- 1. "Settings"
- تلفن "Time/Date" 2.
- 3. "Time zone"
- 4. Select the desired time zone.

The time zone is stored.

### Setting the time

- 1. "Settings"
- 2. "Time/Date"
- 3. "Time:"
- 4. Turn the controller until the desired hours are displayed.
- Press the controller.
- Turn the controller until the desired minutes are displayed.
- 7. Press the controller.

The time is stored.

### **Setting the time format**

- "Settings"
- 2. "Time/Date"
- 3. "Format:"
- 4. Select the desired format.

The time format is stored.

### **Date**

### Setting the date

- 1. "Settings"
- 2. "Time/Date"
- 3. "Date:"
- 4. Turn the controller until the desired day is displayed.
- 5. Press the controller.
- 6. Make the necessary settings for the month and year.

The date is stored.

### **Setting the date format**

- 1. "Settings"
- 2. "Time/Date"
- 3. "Format:"
- Select the desired format.

The date format is stored.

### Language

### **Setting the language**

To set the language on the Control Display:

- 1. "Settings"
- 2. "Language/Units"
- 3. "Language:"
- 4. Select the desired language.

The setting is stored for the remote control currently in use.

### Setting the voice dialog

Voice dialog for the voice activation system, refer to page 23.

#### Units of measure

### Setting the units of measure

To set the units for fuel consumption, route/ distance and temperature:

- "Settings"
- "Language/Units"
- 3. Select the desired menu item.
- 4. Select the desired unit.

The setting is stored for the remote control currently in use.

### **Brightness**

### Setting the brightness

To set the brightness of the Control Display:

- "Settings"
- 2. "Control display"
- 3. "Brightness"
- 4. Turn the controller until the desired brightness is set.
- 5. Press the controller.

The setting is stored for the remote control currently in use.

Depending on the light conditions, the brightness control may not be clearly visible.

## **Lamps**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### At a glance



- Rear fog lamps
- 2 Front fog lamps
- 3 Automatic headlamp control, Adaptive Light Control, High-beam Assistant, Welcome lamps, Daytime running lights
- 4 Lamps off, daytime running lights
- 5 Parking lamps, daytime running lights
- 6 Low beams, welcome lamps, High-beam Assistant
- 7 Instrument lighting

# Parking lamps/low beams, headlamp control

### **General information**

Switch position: 0, **■D** , **■D** 

If the driver door is opened with the ignition switched off, the exterior lighting is automatically switched off at these switch settings.

### **Parking lamps**

Switch position **DQ**: the vehicle lamps light up on all sides, e.g., for parking.

Do not use the parking lamps for extended periods; otherwise, the battery may become discharged and it would then be impossible to start the engine.

When parking, it is preferable to switch on the one-sided roadside parking lamps, refer to page 87.

### Low beams

Switch position **D** with the ignition switched on: the low beams light up.

### Welcome lamps

When parking the vehicle, leave the switch in position 

□ or □ : the parking and interior lamps light up briefly when the vehicle is unlocked.

### **Activating/deactivating**

- 1. "Settings"
- 2. "Lighting"
- 3. "Welcome lights"

The setting is stored for the remote control currently in use.

### Headlamp courtesy delay feature

The low beams stay lit for a short while after the ignition is switched off, if the lamps are switched off and the headlamp flasher is switched on.

### **Setting the duration**

- "Settings"
- 2. "Lighting"
- 3. "Pathway lighting:"
- 4. Set the duration.

The setting is stored for the remote control currently in use.

### **Automatic headlamp control**

Switch position **ID**: the low beams are switched on and off automatically, e.g., in tunnels, in twilight or if there is precipitation. The indicator lamp in the instrument cluster lights up.

A blue sky with the sun low on the horizon can cause the lights to be switched on.

The low beams always stay on when the fog lamps are switched on.

Personal responsibility

The automatic headlamp control cannot serve as a substitute for your personal judgment in determining when the lamps should be switched on in response to ambient lighting conditions.

For example, the sensors are unable to detect fog or hazy weather. To avoid safety risks, you should always switch on the lamps manually under these conditions.

### **Daytime running lights**

With the ignition switched on, the daytime running lights light up in position 0,  $\Rightarrow D \subseteq O$  or  $\Rightarrow C$ . After the ignition is switched off, the parking lamps light up in position  $\Rightarrow D \subseteq O$ .

### **Activating/deactivating**


In some countries, daytime running lights are compulsory, so it may not be possible to deactivate the daytime running lights.

- 1. "Settings"
- 2. "Lighting"

### 3. "Daytime running lamps"

The setting is stored for the remote control currently in use.

### Roadside parking lamps



The vehicle can be illuminated on one side.

### **Switching on**

With the ignition switched off, press the lever either up or down past the resistance point for approx. 2 seconds.

### **Switching off**

Briefly press the lever to the resistance point in the opposite direction.

## **Adaptive light control**

### The concept

Adaptive Light Control is a variable headlamp control system that enables dynamic illumination of the road surface.

Depending on the steering angle and other parameters, the light from the headlamp follows the course of the road.

In tight curves, e.g., on mountainous roads or when turning, an additional, corner-illuminating lamp is switched on that lights up the inside of the curve when the vehicle is moving below a certain speed.

### **Activating**

Switch position **f** with the ignition switched on.

The turning lamps are automatically switched on depending on the steering angle or the use of turn signals.

To avoid blinding oncoming traffic, the Adaptive Light Control does not swivel to the driver's side when the vehicle is at a standstill.

When driving in reverse, only the turning lamp is active.

### **Self-leveling headlamps**

The self-leveling headlamps compensate for acceleration and braking operations in order not to blind the oncoming traffic and to achieve optimum illumination of the roadway.

#### Malfunction

A Check Control message is displayed.

Adaptive light control is malfunctioning or has failed. Have the system checked as soon as possible.

### **High-beam Assistant**

### The concept

When the low beams are switched on, this system automatically switches the high beams on and off. The procedure is controlled by a sensor on the front of the interior rearview mirror. The assistant ensures that the high beams are switched on whenever the traffic situation allows. The driver can intervene at any time and switch the high beams on and off as usual.

### **Activating**



- 2. Press the button on the turn signal lever, arrow.



The indicator lamp in the instrument cluster lights up.


When the lights are switched on, the high beams are switched on and off automatically.

The system responds to light from oncoming traffic and traffic driving ahead of you, and to adequate illumination, e.g., in towns and cities.



The blue indicator lamp in the instrument cluster lights up when the system switches on the high beams.

# Switching the high beams on and off manually



- ▶ High beams on, arrow 1.
- ▶ High beams off/headlamp flasher, arrow 2.

The High-beam Assistant can be switched off when manually adjusting the light. To reactivate the High-beam Assistant, press the button on the turn signal lever.

### **System limits**

Personal responsibility

The high-beam assistant cannot serve as a substitute for the driver's personal judgment of when to use the high beams. Therefore, manually switch off the high beams in situations where this is required to avoid a safety risk.

The system is not fully functional in situations such as the following, and driver intervention may be necessary:

- ▶ In very unfavorable weather conditions, such as fog or heavy precipitation.
- In detecting poorly-lit road users, such as pedestrians, cyclists, horseback riders and wagons; when driving close to train or ship traffic; and at animal crossings.
- In tight curves, on hilltops or in depressions, in cross traffic or half-obscured oncoming traffic on freeways.
- In poorly-lit towns and cities and in the presence of highly reflective signs. \( \)
- At low speeds.
- When the windshield in front of the interior rearview mirror is fogged over, dirty or covered with stickers, etc.

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rear view mirror clean and clear.

### Fog lamps

### Front fog lamps

The parking lamps or low beams must be switched on.



Press the button. The green indicator lamp lights up.

If the automatic headlamp control, refer to page 87, is activated, the low beams will come on automatically when you switch on the front fog lamps.

### **Instrument lighting**

### **Adjusting**



تلفن شبانه روزی: **۸۵ • ۲** 

The parking lamps or low beams must be switched on to adjust the brightness.

Adjust the brightness using the thumbwheel.

### **Interior lamps**

### **General information**

The interior lamps, footwell lamps, entry lamps and courtesy lamps are controlled automatically.

The brightness of some of these lamps is influenced by the thumbwheel for the instrument lighting.



- "Reduced": the speakers in the field of view are hidden while driving.
- "On": the speakers are always illuminated.

- Interior lamps
- 2 Reading lamp

# Switching the interior lamps on and off



Press the button.

To switch off permanently: press the button for approx. 3 seconds.

Switch back on: press button.

### Reading lamps



Press the button.

تلفن شبانه روزی: ۱۵۸۰۲۰۸۸ ۲۱–۲۲

Reading lamps are located at the front and rear next to the interior lamps.

When the interior lamps are switched off per SOS. COM manently, the reading lamps cannot be switched on.

# Bang & Olufsen High End Surround Sound System

### **Adjusting speaker lighting**

Some speakers in the vehicle are illuminated.

The lighting can be individually set.

- 1. "Settings"
- 2. "Lighting"
- 3. "B & O"
- 4. Select the desired lighting setting.
  - ▶ "Off": no lighting.


# **Safety**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e.g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## **Airbags**



- Front airbag, driver
- 2 Front airbag, front passenger
- 3 Head airbag

### Front airbags

Front airbags help protect the driver and front passenger by responding to frontal impacts in which safety belts alone cannot provide adequate restraint.

### Side airbags

In a lateral impact, the side airbag supports the side of the body in the chest and lap area.

- 4 Side airbag
- 5 Knee airbags

### **Head airbags**

In a lateral impact, the head airbag supports the head.

### **Knee airbag**

The knee airbag supports the legs in a frontal impact.

### Protective action

Airbags are not triggered in every impact situation, e.g., in less severe accidents or rear-end collisions.



Information on how to ensure the optimal protective effect of the airbags

- Keep at a distance from the airbags.
- Always grasp the steering wheel on the steering wheel rim, holding your hands at the 3 o'clock and 9 o'clock positions, to keep the danger of injury to your hands or arms as low as possible if the airbag is triggered.
- ▶ There should be no people, animals, or objects between an airbag and a person.
- Do not use the cover of the front airbag on the front passenger side as a storage area.
- Keep the dashboard and window on the front passenger side clear, i.e., do not cover with adhesive labels or coverings, and do not attach holders such as for navigation instruments and mobile phones.
- Make sure that the front passenger is sitting correctly, i.e., keeps his or her feet and legs in the footwell; otherwise, leg injuries can occur if the front airbag is triggered.
- Do not place slip covers, seat cushions or other objects on the front passenger seat that are not approved specifically for seats with integrated side airbags.
- Do not hang pieces of clothing, such as jackets, over the backrests.
- Make sure that occupants keep their heads away from the side airbag and do not rest against the head airbag; otherwise, injuries can occur if the airbags are triggered.
- Do not remove the airbag restraint system.
- Do not remove the steering wheel.
- Do not apply adhesive materials to the airbag cover panels, cover them or modify them in any way.

Never modify either the individual components or the wiring in the airbag system.
 This also applies to steering wheel covers, the dashboard, the seats, the roof pillars and the sides of the headliner.

Even when all instructions are followed closely, injury from contact with the airbags cannot be ruled out in certain situations.

The ignition and inflation noise may lead to short-term and, in most cases, temporary hearing impairment in sensitive individuals.



In the case of a malfunction, deactivation and after triggering of the airbags

Do not touch the individual components immediately after the system has been triggered; otherwise, there is the danger of burns.

Only have the airbags checked, repaired or dismantled and the airbag generator scrapped by your service center or a workshop that has the necessary authorization for handling explosives.

Non-professional attempts to service the system could lead to failure in an emergency or undesired triggering of the airbag, either of which could result in injury.

✓

Warnings and information on the airbags are also found on the sun visors.

# Functional readiness of the airbag system



When the ignition is switch on, the warning lamp in the instrument cluster lights up briefly and thereby indicates

the operational readiness of the entire airbag system and the belt tensioner.

### **Airbag system malfunctioning**

- Warning lamp does not come on when the ignition is turned on.
- The warning lamp lights up continuously.



When there is a malfunction, have the airbag system checked immediately

When there is a malfunction, have the airbag system checked immediately; otherwise, there is a risk that the system does not function as expected in the event of an accident despite corresponding severity of the accident. ◄

# Automatic deactivation of the front passenger airbags

The system determines whether the front passenger seat is occupied by measuring the resistance of the human body.

The front, knee, and side airbag on the front passenger side are activated or deactivated accordingly.

Leave feet in the footwell

Make sure that the front passenger
keeps his or her feet in the footwell; otherwise,
the front passenger airbags may not function
properly.



Child restraint fixing system in the front passenger seat

Before transporting a child on the front passenger seat, refer to the safety notes and instructions under Children on the front passenger seat. ◀

# Malfunction of the automatic deactivation system

When transporting older children and adults, the front passenger airbags may be deactivated in certain sitting positions. In this case, the indicator lamp for the front passenger airbags lights up.

In this case, change the sitting position so that the front passenger airbags are activated and the indicator lamp goes out.

If it is not possible to activate the airbags, have the person sit in the rear.

To make sure that the occupied seat cushion can be evaluated correctly

- Do not attach covers, cushions, ball mats or other items to the front passenger seat unless they are specifically recommended by the manufacturer of your vehicle.
- Do not place any electronic devices on the passenger seat if a child restraint system is to be installed on it.
- Do not place objects under the seat that could press against the seat from below.

# Indicator lamp for the front passenger airbags



The indicator lamp for the front passenger airbags indicates the operating state of the front passenger airbags.

The lamp indicates whether the airbags are activated or deactivated.



- The indicator lamp lights up when a child who is properly seated in a child restraint fixing system intended for that purpose is detected on the seat or the seat is empty. The airbags on the front passenger side are not activated.
- The indicator lamp does not light up when, for example, a correctly seated person of sufficient size is detected on the seat. The airbags on the front passenger side are activated.

### **Detected child seats**

The system generally detects children seated in a child seat, especially in the child seats that were required by NHTSA when the vehicle was manufactured. After installing a child seat, make sure that the indicator lamp for the front passenger airbags lights up. This indicates that the child seat has been detected and the front passenger airbags are not activated.

# Strength of the driver's and front passenger airbag

The strength with which the driver's and front passenger airbags are triggered depends on the position of the driver's and front passenger seats.

To maintain the accuracy of this function over the long-term, calibrate the front seats when a corresponding message appears on the Control Display.

### Calibrating the front seats

A corresponding message appears on the Control Display.

- Move the respective seat forward all the way.
- 2. Move the respective seat forward again. It moves forward briefly.
- Readjust the seat to the desired position.

The calibration procedure is completed when the message on the Control Display disappears.

If the message continues to be displayed, repeat the calibration.

If the message does not disappear after a repeat calibration, have the system checked as soon as possible.

Unobstructed area of movement
Ensure that the area of movement of the
seats is unobstructed to avoid personal injury
or damage to objects.

✓

### **Tire Pressure Monitor TPM**

### The concept

The system monitors tire pressure in the four mounted tires. The system warns you if there is a significant loss of pressure in one or more tires. For this purpose, sensors in the tire valves measure the tire pressure and tire temperature.

#### Hints

Tire damage due to external factors

Sudden tire damage caused by external influences cannot be indicated in advance.

Pay attention to the other information and indications under Tire inflation pressure, refer to page 185, as well when using the system.

### **Functional requirements**

The system must have been reset with the correct tire inflation pressure; otherwise, reliable signaling of tire pressure loss is not ensured. تلفن شبانه روزي

Reset the system again after each correction of the tire inflation pressure and after every tire or wheel change.

Always use wheels with TPM electronics to ensure that the system will operate properly.

### Status display

The current status of the Tire Pressure Monitor TPM can be displayed on the Control Display, e.g., whether or not the TPM is active.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. (!) "Tire Pressure Monitor"

The status is displayed.

### Status display

The tire and system status is indicated by the color of the wheels and a text message on the Control Display.

### All wheels green

System is active and will issue a warning relative to the tire inflation pressures stored during the last reset.

### One wheel is yellow

A flat tire or major drop in inflation pressure in the indicated tire.

### All wheels are yellow

A flat tire or major drop in inflation pressure in several tires.

### Wheels, gray

The system cannot detect a flat tire. Reasons for this may be:

- The system is being reset.
- Malfunction.

### Additional information

The status display additionally shows the current tire inflation pressures and tire temperatures. The values shown are current measurement values and may vary depending on driving style or weather conditions.

### **Carry out reset**

Reset the system after each correction of the tire inflation pressure and after every tire or wheel change.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. (!) "Perform reset"
- 4. Start the engine do not drive away.
- 5. Carry out the reset with "Perform reset".
- Drive away.

The tires are shown in gray and the status is displayed.

After driving faster than 19 mph/30 km/h for a short period, the tire inflation pressures set are accepted as reference values. The reset is completed automatically during driving.

After a successfully completed Reset, the wheels on the Control Display are shown in green and "Tire Pressure Monitor (TPM) active" is displayed.

The trip can be interrupted at any time. If you drive away again, the reset resumes automatically.

### Low tire pressure message



The yellow warning lamp lights up. A Check Control message is displayed.

- ► There is a flat tire or a major loss in tire inflation pressure.
- No reset was performed for the system.
   The system therefore issues a warning based on the tire pressures before the last reset.
- Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
- 2. Check whether the vehicle is fitted with regular tires or run-flat tires.

Run-flat tires, refer to page 195, are labeled with a circular symbol containing the letters RSC marked on the tire sidewall.



Do not continue driving without run-flat tires

Do not continue driving if the vehicle is not equipped with run-flat tires; continued driving may result in serious accidents.◀

When a low inflation pressure is indicated, DSC Dynamic Stability Control is switched on if necessary.

### Actions in the event of a flat tire

#### **Normal tires**

1. Identify the damaged tire.

Do this by checking the air pressure in all four tires.

If the tire inflation pressure in all four tires is correct, it is possible that a reset was not

carried out for the Tire Pressure Monitor. In that case, carry out a reset.

If an identification is not possible, please contact the service center.

Rectify the flat tire.

Use of tire sealant, e.g., the Mobility System, may damage the TPM wheel electronics. In this case, have the electronics checked at the next opportunity and have them replaced if necessary.

#### **Run-flat tires**

### Maximum speed

You can continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

### Continued driving with a flat tire

If continuing to drive with a damaged tire:

- Avoid sudden braking and steering maneuvers.
- Do not exceed a speed of 50 mph/80 km/h.
- 3. Check the air pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is correct, it is possible that a reset was not carried out for the Tire Pressure Monitor. In that case, carry out a reset.

Possible driving distance with complete loss of tire inflation pressure:

The possible driving distance after a loss of tire inflation pressure depends on the cargo load and the driving style and conditions.

For a vehicle containing an average load, the possible driving distance is approx. 50 miles/80 km.

When the vehicle is driven with a damaged tire, its handling characteristics change, e.g., reduced lane stability during braking, a longer braking distance, and altered self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering maneuvers or driving over obstacles, e.g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be smaller or greater depending on the driving speed, road conditions, external temperature, cargo load, etc.

Continued driving with a flat tire

Drive moderately and do not exceed a speed of 50 mph/80 km/h.

A loss of tire inflation pressure results in a change in the handling characteristics, e.g., reduced lane stability during braking, a longer braking distance and altered self-steering properties.

Final tire failure

Vibrations or loud noises while driving can indicate the final failure of the tire. Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident. Do not continue driving, and contact your service center.

# Required inflation pressure check message

A Check Control message is displayed.

Check the tire inflation pressure and carry out a reset of the system.

In some cases, a wheel was changed without having carried out a reset.

### **System limits**

The system does not function properly if a reset has not been carried out, e.g., a flat tire is reported even though the tire inflation pressures are correct.

The tire pressure depends on the temperature of the tire. If the tire temperature rises, e.g., due to driving or because of the heat of the Sun, the tire inflation pressure increases also. The tire pressure is reduced when the tire temperature falls again. This behavior may cause a warning to be issued if temperatures fall very sharply.

### Malfunction



The yellow warning lamp flashes and then lights up continuously. A Check Control message is displayed. No flat

tire or loss of tire pressure can be detected.

Display in the following situations:

- A wheel without TPM electronics is fitted: have the service center check it if necessary.
- Malfunction: have the system checked by your service center.
- TPM was unable to complete the reset. Reset the system again.
- Disturbance by systems or devices with the same radio frequency: after leaving the area of the disturbance, the system automatically becomes active again.

### Declaration according to NHTSA/ FMVSS 138 Tire Pressure Monitoring System

Each tire, including the spare (if provided) should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.) As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for

proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale. Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

### **FTM Flat Tire Monitor**

### The concept

The system does not measure the actual inflation pressure in the tires.

It detects a pressure loss in a tire by comparing the rotational speeds of the individual wheels while moving.

In the event of a pressure loss, the diameter and therefore the rotational speed of the corresponding wheel change. This is detected and reported as a flat tire.

### **Functional requirements**

The system must have been initialized when the tire inflation pressure was correct; otherwise, reliable signaling of a flat tire is not ensured. Initialize the system after each correction of the tire inflation pressure and after every tire or wheel change.

### Status display

The current status of the Flat Tire Monitor can be displayed on the Control Display, e.g., whether or not the FTM is active.

- "Vehicle Info"
- "Vehicle status"
- 3. (!) "Flat Tire Monitor (FTM)"

The status is displayed.

### Initialization

The initialization process adopts the set inflation tire pressures as reference values for the detection of a flat tire. Initialization is started by confirming the inflation pressures.

Do not initialize the system when driving with snow chains.

+ 7 1 - 1 1 1 4

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. (!) "Perform reset"
- 4. Start the engine do not drive away.
- 5. Start the initialization with "Perform reset"
- 6. Drive away.

The initialization is completed while driving, which can be interrupted at any time.

The initialization automatically continues when driving resumes.

### Indication of a flat tire



The yellow warning lamp lights up. A Check Control message is displayed.

There is a flat tire or a major loss in tire inflation pressure.

Reduce your speed and stop cautiously.
 Avoid sudden braking and steering maneuvers.

2. Check whether the vehicle is fitted with regular tires or run-flat tires.

Run-flat tires, refer to page 195, are labeled with a circular symbol containing the letters RSC marked on the tire sidewall.



Do not continue driving without run-flat tires

Do not continue driving if the vehicle is not equipped with run-flat tires; continued driving may result in serious accidents.◀

When a flat tire is indicated, DSC Dynamic Stability Control is switched on if necessary.

### **System limits**

Sudden tire damage

Sudden serious tire damage caused by external influences cannot be indicated in advance.

A natural, even pressure loss in all four tires cannot be detected. Therefore, check the tire inflation pressure regularly.

The system could be delayed or malfunction in the following situations:

- ▶ When the system has not been initialized.
- When driving on a snowy or slippery road surface.
- Sporty driving style: slip in the drive wheels, high lateral acceleration.
- When driving with snow chains.

#### Actions in the event of a flat tire

#### Normal tires

1. Identify the damaged tire.

Do this by checking the air pressure in all four tires.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

If an identification is not possible, please contact the service center.

2. Rectify the flat tire.

#### **Run-flat tires**

### **Maximum speed**

You can continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

### Continued driving with a flat tire

If continuing to drive with a damaged tire:

- Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- Check the air pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

Possible driving distance with complete loss of tire inflation pressure:

The possible driving distance after a loss of tire inflation pressure depends on the cargo load and the driving style and conditions.

For a vehicle containing an average load, the possible driving distance is approx. 50 miles/80 km.

When the vehicle is driven with a damaged tire, its handling characteristics change, e.g., reduced lane stability during braking, a longer braking distance, and altered self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering maneuvers or driving over obstacles, e.g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be smaller or greater depending on the driving speed, road conditions, external temperature, cargo load, etc.

Continued driving with a flat tire
Drive moderately and do not exceed a speed of 50 mph/80 km/h.

A loss of tire inflation pressure results in a change in the handling characteristics, e.g., reduced lane stability during braking, a longer braking distance and altered self-steering properties.

Final tire failure

Vibrations or loud noises while driving can indicate the final failure of the tire. Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident. Do not continue driving, and contact your service center.◀

## Intelligent Safety

### The concept

Depending on how the vehicle is equipped, Intelligent Safety consists of one or more of the following systems, which can help to avoid an imminent collision. These systems are active automatically every time the engine is started using the Start/Stop button:

- ▶ Collision warning, refer to page 100.
- Pedestrian warning, refer to page 105.

#### Note

Personal responsibility

The system does not serve as a substitute for the driver's personal judgment of the traffic situation.

Be aware of the traffic situation and the vehicle's surroundings at all times, otherwise an accident is still possible despite all warnings.◀

### At a glance

### **Button in the vehicle**





Intelligent Safety button

### Switching on/off

The Intelligent Safety systems are automatically active after each engine start via the start/stop button.



Press the button: the systems are switched off. The LED goes out.

Press the button: the systems are switched off. The LED lights up.

Settings can be made on the Control Display.

## **Collision warning**

Depending on how the equipment is equipped, the collision warning system consists of one of the two systems:

- Collision warning with City Braking function, refer to page 103;
- Collision warning with braking function, refer to page 100

# Collision warning with braking function

### The concept

The system issues a warning if there is imminent danger of a collision and also includes a braking function.

If the vehicle is equipped with Active Cruise Control with Stop & Go, the collision warning is controlled via the cruise control radar sensor in conjunction with a camera.


The collision warning is available even if cruise control has been deactivated.

When the vehicle is intentionally brought close to a vehicle, the collision warning is delayed to avoid false warnings.

### **General information**

The system issues a two-phase warning of a possible danger of collision with vehicles at speeds above approx. 3 mph/5 km/h. The time of these warnings may vary depending on the current driving situation.

### **Detection range**



It responds to stationary or moving objects that are within the detection range of the radar system.

### At a glance

### **Button** in the vehicle





Intelligent Safety button

#### Radar sensor



The radar sensor is located in the lower area of the front bumper.

Always keep radar sensor clean and unobstructed.

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rear view mirror clean and clear.

### Switching on/off

### Switching on automatically

The system is automatically active every time the engine is started using the Start/Stop button.

### **Switching off**

The system is only switched off until the next time the engine is started with the Start/Stop button.



Press the button.

The LED goes out.

### Display

### Warning stages

### Prewarning

This warning is issued, for example, when there is the impending danger of a collision or the distance to the vehicle ahead is too small.

### Acute warning with braking function

Warning of the imminent danger of a collision when the vehicle approaches another object at a relatively high differential speed.

The acute warning prompts the driver to intervene and, if there is the danger of a collision, is accompanied by a braking intervention.

The braking intervention may be executed with maximum braking force and for a brief period only as necessary.

The intervention can bring the vehicle to a complete stop.

The braking intervention is executed only if DSC Dynamic Stability Control is switched on and Dynamic Traction Control DTC is activated.

Above approx. 130 mph/210 km/h, the braking intervention occurs as a brief braking pressure. No automatic delay occurs.

Adapting your speed and driving style
The warning does not relieve the driver
of the responsibility to adapt his or her driving
speed and style to the traffic conditions.

The braking intervention can be interrupted by pressing on the accelerator or by actively moving the steering wheel.

When towing or tow-starting the vehicle, switch off the collision warning with braking function to prevent undesired interventions.

### Display in the instrument cluster

The collision warning can be issued in the instrument cluster, in the Head-up Display, and acoustically.

### **Warning stages**

### Symbol Measure



The vehicle lights up red: prewarning.

Increase distance.



The vehicle flashes red and an acoustic signal sounds: acute warning.

You are requested to intervene by braking or making an evasive maneuver.

Adapting your speed and driving style
The display does not relieve the driver of
the responsibility to adapt his or her driving
speed and style to the traffic conditions.

### **System limits**

A

Be alert

Due to system limitations, warnings may be not be issued at all, or may be issued late or improperly. Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◄

### **Detection range**

The system's detection capabilities are limited.

This may result in the warning not being issued or being issued late.

For example, the following situations may not be detected:

- Slow moving vehicles when you approach them at high speed.
- Vehicles that suddenly swerve in front of you or sharply decelerating vehicles.
- Vehicles with an unusual rear appearance.
- ▶ Two-wheeled vehicles ahead of you.
- Pedestrians.

### **Functional limitations**

The system may not be fully functional in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- If the driving stability control systems are limited or deactivated, for example, DSC OFF.
- ▶ If the camera in the mirror or the radar sensor is dirty or obscured.
- During calibration of the camera immediately after vehicle shipment.
- If there is constant dimming because of oncoming light, for example, from the sun low in the sky.

### **Prewarning sensitivity**

Depending on the set prewarning time, this may result in increased false warnings.

# Collision warning with City Braking function

### The concept

The system can help to prevent accidents. If an accident cannot be prevented, the system helps to reduce the collision speed.

The system issues a warning if there is imminent danger of a collision and if so brakes independently.

The automatic braking intervention is done with limited force and duration.

The system is controlled via a camera in the base of the mirror.

The collision warning is available even if cruise control has been deactivated.


When the vehicle is intentionally brought close to a vehicle, the collision warning is delayed to avoid false warnings.

### **General information**

The system issues a two-phase warning of a danger of collision with vehicles at speeds above approx. 3 mph/5 km/h. The time of these warnings may vary depending on the current driving situation.

Up to approx. 35 mph/60 km/h a braking intervention occurs when appropriate.

### **Detection range**



Vehicles are observed when they are traveling in the same direction of movement if they are located within the detection range of the system.

### At a glance

### **Button** in the vehicle





Intelligent Safety button

### Switching on/off

### Switching on automatically

The system is automatically active every time the engine is started using the Start/Stop button.

### **Switching off**

The system is only switched off until the next time the engine is started with the Start/Stop button.



Press the button.

The LED goes out.

### Warning with braking function

Adapting your speed and driving style
The warning does not relieve the driver
of the responsibility to adapt his or her driving
speed and style to the traffic conditions.

### **Display**

If a collision with a vehicle detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.

### Symbol Measure



The vehicle lights up red: prewarning.

Increase braking and distance.



The vehicle flashes red and an acoustic signal sounds: acute warning.

You are requested to intervene by braking or making an evasive maneuver.

### **Braking intervention**

The warning prompts the driver himself to intervene. During the warning, the maximum braking force is used, even with light pressure on the brake pedal. In addition, if there is a risk of collision, the system can assist with a slight braking intervention. The intervention can bring a vehicle traveling at slow speed to a complete stop.

The braking intervention is executed only if DSC Dynamic Stability Control is switched on and Dynamic Traction Control DTC is activated.

The braking intervention can be interrupted by pressing on the accelerator or by actively moving the steering wheel.

When towing or tow-starting the vehicle, switch off the collision warning with braking function to prevent undesired interventions.

### **System limits**

Due to system limitations, warnings may be not be issued at all, or may be issued late or improperly. Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◄

### **Detection range**

The system's detection capabilities are limited.

This may result in the warning not being issued or being issued late.

For example, the following situations may not be detected:

- Slow moving vehicles when you approach them at high speed.
- Vehicles that suddenly swerve in front of you or sharply decelerating vehicles.
- Vehicles with an unusual rear appearance.
- ▶ Two-wheeled vehicles ahead of you.
  - Pedestrians.

### **Functional limitations**

The system may not be fully functional in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- If the driving stability control systems are limited or deactivated, for example, DSC OFF.
- ▶ If the camera in the mirror or the radar sensor is dirty or obscured.
- During calibration of the camera immediately after vehicle shipment.

If there is constant dimming because of oncoming light, for example, from the sun low in the sky.

### **Prewarning sensitivity**

Depending on the set prewarning time, this may result in increased false warnings.

### **Pedestrian warning**

Depending on how the vehicle is equipped, the function warns of an imminent collision with pedestrians during daytime or nighttime.

The function is subdivided into the following systems:

- During daytime: Pedestrian warning with city braking function, refer to page 105
- At night: Night Vision with pedestrian detection, refer to page 107

# Pedestrian warning with city braking function

### The concept

The system can help to prevent accidents with pedestrians.

The system issues a warning in the city driving speed area if there is imminent danger of a collision with pedestrians and includes a braking function.


The system is controlled via the camera in the base of the interior mirror.

### **General information**

The system issues a warning with brightness staring at approx. 6 mph/10 km/h to approx. 35 mph/60 km/h regarding a possible risk of collision with pedestrians and assists with a brake intervention shortly before a collision.

It responds to persons that are within the detection range of the system.

### **Detection range**



The warning area in front of the vehicle is divided into two areas.

- Central area, arrow 1, directly in front of the vehicle.
- Expanded area, arrow 2, to the right and left.

A collision is imminent if pedestrians are located within the central area. A warning is issued about pedestrians who are located within the extended area only if they are moving in the direction of the central area.

### تلفرAt a glance

### **Button in the vehicle**





Intelligent Safety button

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rear view mirror clean and clear.

### Switching on/off

### Switching on automatically

The system is automatically active every time the engine is started using the Start/Stop button.

### **Switching off**



Press the button: the systems are switched off. The LED goes out.

Press the button: the systems are switched off.
The LED lights up.

### Warning with braking function

Adapting your speed and driving style
The warning does not relieve the driver
of the responsibility to adapt his or her driving
speed and style to the traffic conditions.

### **Display**

If a collision with a person detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.



The red symbol is displayed and a signal sounds.

Intervene immediately by braking or making an evasive maneuver.

### **Braking intervention**

The warning prompts the driver himself to intervene. During the warning, the maximum braking force is used, even with light pressure on the brake pedal. In addition, if there is a risk of collision, the system can assist with a slight braking intervention. The intervention can bring a vehicle traveling at slow speed to a complete stop.

The braking intervention is executed only if DSC Dynamic Stability Control is switched on and Dynamic Traction Control DTC is activated

The braking intervention can be interrupted by pressing on the accelerator or by actively moving the steering wheel.

When towing or tow-starting the vehicle, switch off the pedestrian warning to prevent undesired interventions.

### تلفن شائه روزيءَ System limits

Be alert

Due to system limitations, warnings may be not be issued at all, or may be issued late or improperly. Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◄

### **Detection range**

The detection capability of the camera is limited.

This may result in the warning not being issued or being issued late.

For example, the following situations may not be detected:

- Partially covered pedestrians.
- Pedestrians that are not detected as such because of the viewing angle or contour.
- Pedestrians outside of the detection range.

Pedestrians below a body size of approx.
 32 in/80 cm.

### **Functional limitations**

The system may not be fully functional or may not be available in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- ▶ If the camera view field or the front windshield are dirty or covered.
- When driving toward bright lights.
- ▶ Up to 10 seconds after the start of the engine, via the Start/Stop knob.
- During calibration of the camera immediately after vehicle shipment.

# Night Vision with Pedestrian and Animal Detection

### The concept

Night Vision with pedestrian and animal detection is a night vision system.

An infrared camera records the area in front of the vehicle and issues a warning if it detects pedestrians and animals on the street. Warm objects that are similar in shape to human beings or animals are detected by the system. If necessary, the heat image can be displayed on the Control Display.

### **Heat image**



The image shows the heat radiated by objects in the field of view of the camera.

Warm objects have a light appearance and cold objects, a dark appearance.

The ability to detect an object depends on the temperature difference between the object and the background and on the level of heat radiation emitted by the object. Objects that are similar in temperature to the environment or that radiate very little heat are difficult to detect.

For safety reasons, when driving at speeds above approx. 3 mph/5 km/h and in low ambient light, the image is only displayed when the low beams are switched on.

A still image is displayed at regular intervals for a fraction of a second.

### Pedestrian and animal detection



Object detection and warning only functions in darkness.

Warm objects that are similar in shape to human beings are detected by the system.

In addition, the system also detects animals above a certain minimum size, e.g., deer.

With heat image activated on the Control Display:

People detected by the system are displayed with a slight yellow hue.

Animals detected by the system are displayed in a darker yellow.

Under good ambient conditions, the object detection operates within the following distance ranges:

- Pedestrian detection: up to approx.330 ft/100 m
- Detection of large animals: up to approx.
   490 ft/150 m
- Detection of medium animals: up to approx. 230 ft/70 m

Environmental influences can limit the availability of object detection.

If the vehicle systems detect that the vehicle is located in a residential area, the animal detection is temporarily switched off:

#### **Notes**

Personal responsibility
Night Vision cannot replace the driver's
personal judgment of the visibility conditions
and the traffic situation. The view ahead and
the actual visibility conditions must always be
the basis on which the vehicle speed is adjusted; otherwise, there is a risk to road
safety.

### At a glance

### **Buttons in the vehicle**



圇

Intelligent Safety button



Switch on/switch off heat image

### Camera



The camera is automatically heated when the external temperatures are low.

The camera is automatically cleaned together with the headlamps.

### Switching on/off

### **Switching on automatically**

Every time the engine is started using the Start/Stop button, the system is automatically active at dark.

### Switching off

The system is only switched off until the next time the engine is started with the Start/Stop button.



Press the button.

The LED goes out.

#### Switching on heat image additionally

The heat image from the Night Vision camera can also be displayed on the Control Display. This function has no effect on object detection.



Press the button.

The image from the camera is displayed on the Control Display.

#### Adjustments via the iDrive

With heat image switched on:

- 1. Press the controller.
- 2. Select brightness or contrast.

  - Select the symbol.
- Turn the controller until the desired setting is reached, and press the controller.


## **Display**

# Warning of people or animals in danger

If a collision with a person or an animal detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.

Although both the shape and the heat radiation are analyzed, false warnings cannot be ruled out.

#### Warning area in front of the vehicle



The warning area for the pedestrian warning consists of two parts:

- Central area, arrow 1, directly in front of the vehicle.
- Expanded area, arrow 2, to the right and left.

In the animal warning, no distinction is made between the central or expanded area.

The entire area moves along with the vehicle in the direction of the steering angle and changes with the vehicle speed. As the vehicle speed increases, the area becomes longer and wider, for example.

#### **Prewarning**



The yellow symbol is displayed when a person is detected in the central area, arrow 1, immediately in front of the ve-

hicle.

The yellow symbol is displayed when a person in the extended area, arrow 2, is moving from the right or left towards the central area.

The displayed symbol can vary with the people detected.

Intervene actively by braking or making an evasive maneuver.



When animals are detected, an animal symbol is displayed. The symbol also shows the side of the road on which

the animal was detected. Intervene actively by braking or making an evasive maneuver.

#### **Acute warning**



The red symbol is displayed and a signal sounds.

Intervene immediately by braking or making an evasive maneuver.

With animals no acute warning occurs.

#### **Display in the Head-up Display**



The warning is displayed simultaneously in the Head-up Display and on the instrument cluster. The displayed

symbol can vary with the people detected.

When animals are detected, an animal symbol is displayed.

#### **System limits**

#### **Basic limits**

System operation is limited in situations such as the following:

- On steep hills, in steep depressions or in tight curves.
- When the camera is dirty or the protective glass is damaged.
- In heavy fog, rain or snowfall.
- At very high external temperatures.

# Limits of pedestrian and animal detection

In some situations, it may occur that pedestrians are detected as animals or animals as pedestrians.

Small animals are not detected by the object detection function, even if they are clearly visible in the image.

Limited detection:

- People or animals who are fully or partially covered, especially when their heads are covered.
- People who are not in an upright position, e.g., lying down.

- Cyclists on unconventional bicycles (e.g., recumbent bicycles).
- After physical damage to the system, e.g., after an accident.

# Lane departure warning

#### The concept

Starting at a specific speed, this system alerts you when the vehicle on streets with lane markings is about to leave the lane. Depending on the country-specific version of the vehicle, the speed is between 35 mph/55 km/h and 45 mph/70 km/h. If the system is switched on below this speed, a message appears in the instrument cluster.

The steering wheel begins vibrating gently in the event of warnings. The time of the warning may vary depending on the current driving situation.

The system does not provide a warning if the turn signal is set before leaving the lane.

تلفن شبانه روزی:

#### **Notes**

Personal responsibility

The system cannot serve as a substitute for the driver's personal judgment of the course of the road and the traffic situation.

In the event of a warning, do not jerk the steering wheel, as you may lose control of the vehicle. ◀

#### At a glance

#### **Button in the vehicle**





Lane departure warning

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rear view mirror clean and clear.

# Switching on/off



Press the button.

- On: the LED lights up.
- Off: the LED goes out.

The state is stored for the remote control currently in use.

# Display in the instrument cluster



▶ Lines: system is activated.

Arrows: at least one lane marking was detected and warnings can be issued.

## Display in the instrument display



- Symbol red: system is activated.
- Symbol green: at least one lane marking was detected and warnings can be issued.

#### **Issued warning**

If you leave the lane and if a lane marking has been detected, the steering wheel begins vibrating.

If the turn signal is set before changing the lane, a warning is not issued.

## End of warning

The warning ends:

- Automatically after approx. 3 seconds.
- When returning to your own lane.
- When braking hard.
- When using the turn signal.

# **System limits**


The system may not be fully functional in the following situations:

- ▶ In heavy fog, rain or snowfall.
- In the event of worn, poorly visible, merging, diverging, or multiple lane markings such as in construction areas.
- When lane markings are covered in snow, ice, dirt or water.
- ▶ In tight curves or on narrow lanes.
- When the lane markings are covered by objects.
- When driving very close to the vehicle in front of you.
- When driving toward bright lights.

- When the windshield in front of the interior rearview mirror is fogged over, dirty or covered with stickers, etc.
- During calibration of the camera immediately after vehicle shipment.

# **Active Blind Spot Detection**

#### The concept



Two radar sensors below the rear bumper monitor the area behind and next to the vehicle at speeds above approx. 30 mph/50 km/h.

The system indicates whether there are vehicles in the blind spot, arrow 1, or approaching from behind on the adjacent lane, arrow 2.

The lamp in the exterior mirror housing lights up dimly.

Before you change lanes after setting the turn signal, the system issues a warning in the situations described above.

The lamp in the housing of the exterior mirror flashes and the steering wheel vibrates.

#### **Notes**

The system does not serve as a substitute for the driver's personal judgment of the traffic situation.

Personal responsibility

Be aware of the traffic situation and the vehicle's surroundings at all times, otherwise an accident is still possible despite all warnings. ◄

#### At a glance

#### **Button in the vehicle**





Active Blind Spot Detection

#### Radar sensors



The radar sensors are located under the rear bumper.

## Switching on/off




Press the button.

- ▷ On: the LED lights up.
- Off: the LED goes out.

The system can issue warnings at speeds above approx. 30 mph/50 km/h.

The state is stored for the remote control currently in use.

#### **Display**



#### Information stage

The dimmed lamp in the mirror housing indicates when there are vehicles in the blind spot or approaching from behind.

#### Warning

If the turn signal is set while a vehicle is in the critical zone, the steering wheel vibrates briefly and the lamp in the mirror housing flashes brightly.

The warning stops when the turn signal is switched off, or the other vehicle leaves the critical zone.

## **System limits**

The system may not be fully functional in the following situations:

- When a vehicle is approaching at a speed much faster than your own.
- In heavy fog, rain or snowfall.
- In tight curves or on narrow lanes.
- If the bumper is dirty or iced up, or covered with stickers.

A Check Control message is displayed when the system is not fully functional.

# For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

FCC ID:

#### ▶ NBG009014A.

Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

# **Brake force display**

# The concept



- During normal brake application, the outer brake lamps light up.
- During heavy brake application, the inner brake lamps light up in addition.

# **Active Protection**

#### General information

The Active Protection safety package consists of systems that are independent of each other:

- Attentiveness assistant.
- > PreCrash
- PostCrash

#### Attentiveness assistant

#### The concept

The system can detect increasing lack of alertness or fatigue of the driver during long, monotonous journeys, for example, on highways. In this situation, it is recommended that the driver take a break.

#### Note

 $\Lambda$ 

Personal responsibility

The system cannot act as a substitute for the personal assessment of one's physical state and may not detect an increasing lack of alertness or fatigue or may not detect it correctly. Therefore, make sure that the driver is rested and alert; otherwise, risks may be detected too late and an accident be caused as a result.

#### **Function**

The system is activated each time the engine is started and cannot be switched off. A A A

After travel has begun, the system is trained about the driver, so that increasing lack of alertness or fatigue can be detected.

This procedure takes the following criteria into account:

- Personal driving style, for example, steering behavior.
- Driving conditions, for example, length of trip.

Starting at approximately 43 mph/70 km/h, the system is active and can display a recommendation to take a break.

#### **Break recommendation**

If the driver becomes increasingly less alert or fatigued, a message is displayed in the Control Display with the recommendation to take a break.

A recommendation to take a break is displayed only once during an uninterrupted trip.

After a break, another recommendation to take a break cannot be displayed until after approximately 45 minutes.

#### **System limits**

The function may be limited in the following situations, for instance, and will either output an incorrect warning or no warning at all:

- When the clock is set incorrectly.
- ▶ When the vehicle speed is mainly below about 43 mph/70 km/h.
- With a sporty driving style, such as during rapid acceleration or when cornering quickly.
- In active driving situations, such as when changing lanes frequently.
- When the road surface is poor.
- In the event of strong side winds.

#### **PreCrash**

#### The concept

With this system critical driving situations that might result in an accident can be detected above a speed of approx. 20 mph/30 km/h. In these situations, preventative protection measures are automatically undertaken to minimize the risk in the event of an accident as much as possible.

Critical driving situations may include:

Full brake applications.

If the vehicle includes the collision warning or collision warning with braking feature, impending collisions with vehicles driving ahead or stopped in front of you can also be detected within the system's range.

#### Note

Personal responsibility

The system cannot possibly serve as a substitute for the driver's personal judgment of the traffic situation. The system may not always detect critical situations reliably and in a timely manner. Adapt speed to traffic situation and drive alertly; otherwise, a risk to safety may result.

After coming to a halt, the brake is released automatically. Secure the vehicle against rolling.

#### **Function**

After the safety belt is buckled, the front belts are automatically pretensioned once after the vehicle is driven is away.

In critical driving situations, the following individual functions become active as needed:

- The front belts are automatically pretensioned.
- Automatic closing of the windows.
- Automatic closing of the glass sunroof.
- For vehicles equipped with Comfort Seats:
   automatic positioning of the backrest for \* ٨٨٠ :روزى:
   the front passenger seat.

After a critical driving situation without an accident, the front belts are loosened again. All other systems can be restored to the desired setting.

If the belt tension does not loosen automatically, stop the vehicle and unbuckle the belt using the red button in the buckle. Fasten the belt before continuing on your trip.

#### **PostCrash**

In the event of an accident, the system can bring the car to a halt automatically without intervention by the driver in certain situations. This can reduce the risk of a further collision and the consequences thereof.

Depressing the brake pedal can cause the vehicle to brake harder. This interrupts automatic braking. Depressing the accelerator pedal also interrupts automatic braking.

+ 71-111-17+

# **Driving stability control systems**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# **Antilock Brake System ABS**

ABS prevents locking of the wheels during braking.

The vehicle remains steerable even during full brake applications, thus increasing active safety.

ABS is operational every time you start the engine.

## **Brake assistant**

When you apply the brakes rapidly, this system automatically produces the maximum braking force boost. This then reduces braking distance to a minimum during full braking. This system utilizes all of the benefits provided by ABS.

Do not reduce the pressure on the brake pedal for the duration of the full braking.

When equipped with Driving Assistant Plus or with Active Cruise Control with Stop & Go function, ACC is supported by the braking intervention if there is a possible risk of collision. To do this, the braking force is automatically increased if the braking pressure is insufficient when the brakes are applied.

# Adaptive brake assistant

In combination with the Active Cruise Control, this system ensures that the brakes respond even more rapidly when braking in critical situations.

#### **Drive-off assistant**

This system supports driving away on gradients. The parking brake is not required.

- Hold the vehicle in place with the foot brake.
- 2. Release the foot brake and drive away without delay.

After the foot brake is released, the vehicle is held in place for approx. 2 seconds.

Depending on the vehicle load, the vehicle may roll back slightly.

Driving off without delay

After releasing the foot brake, start driving without delay, since the drive-off assistant will not hold the vehicle in place for more than approx. 2 seconds and the vehicle will begin rolling back.

# DSC Dynamic Stability Control

# The concept

DSC prevents traction loss in the driving wheels when driving away and accelerating.

DSC also recognizes unstable vehicle conditions, such as fishtailing or nose-diving. Subject to physical limits, DSC helps to keep the vehicle on a steady course by reducing engine speed and by applying brakes at individual wheels

Adjust your driving style to the situation An appropriate driving style is always the responsibility of the driver.

The laws of physics cannot be repealed, even with DSC.

Therefore, do not reduce the additional safety margin by driving in a risky manner. ◀

#### Indicator/warning lamps



The indicator lamp flashes: DSC controls the drive forces and brake forces.

The indicator lamp lights up: DSC has

failed.

## **Deactivating DSC: DSC OFF**

When DSC is deactivated, driving stability is reduced during acceleration and when driving in bends.

Stabilizing interventions by the Integral Active Steering system are only performed by the rear axle steering.

To increase vehicle stability, activate DSC again as soon as possible.

# **Deactivating DSC**



Press and hold the button, but not longer than approx. 10 seconds, until the

indicator lamp for DSC OFF lights up in the instrument cluster and DSC OFF is displayed.

The DSC system is switched off.

# **Activating DSC**



Press the button.

DSC OFF and the DSC OFF indicator

lamp go out.

# **Indicator/warning lamps**

When DSC is deactivated, DSC OFF is displayed in the instrument cluster.



The indicator lamp lights up: DSC is deactivated.

# **DTC Dynamic Traction Control**

#### The concept

The DTC system is a version of the DSC in which forward momentum is optimized.

The system ensures maximum forward momentum on special road conditions, e.g., unplowed snowy roads, but driving stability is limited.

It is therefore necessary to drive with appropriate caution.

You may find it useful to briefly activate DTC under the following special circumstances:

- When driving in slush or on uncleared, snow-covered roads.
- When rocking the vehicle or driving off in deep snow or on loose surfaces.
- When driving with snow chains.

# Deactivating/activating DTC Dynamic Traction Control

Activating the Dynamic Traction Control DTC provides maximum traction on loose ground. Driving stability is limited during acceleration and when driving in bends.

# **Activating DTC**



Press the button.

TRACTION is displayed in the instrument cluster and the indicator lamp for DSC OFF lights up.

# **Deactivating DTC**



Press the button again.

TRACTION and the DSC OFF indicator lamp go out.

#### **Indicator/warning lamps**

When DTC is activated, TRACTION is displayed in the tachometer.



The indicator lamp lights up: DTC Dynamic Traction Control is activated.

# **xDrive**

xDrive is the all-wheel-drive system of your vehicle. Concerted action by the xDrive and DSC further optimize traction and driving dynamics. The xDrive all-wheel-drive system variably distributes the drive forces to the front and rear axles as demanded by the driving situation and road surface.

# **HDC Hill Descent Control**

#### The concept

HDC is a downhill driving assistant that automatically controls vehicle speed on steep downhill gradients. Without applying the brakes, the vehicle moves at slightly more than walking speed.


Hill Descent Control can be activated at speeds below approx. 22 mph/35 km/h. When driving downhill, the vehicle reduces its speed to approx. walking speed and then keeps its speed constant.

As long as there is active braking, the system is on standby. The system does not brake the vehicle during this time.

Use HDC in low gears or in transmission position D or R only.

# Increasing or decreasing vehicle speed

Specify desired speed in the range from approx. 4 mph/6 km/h to approx. 15 mph/25 km/h using the rocker switch of the cruise control on the steering wheel. Vehicle speed can be changed by lightly accelerating.



- Press up the rocker switch to the point of resistance: the speed increases gradually.
- Press up the rocker switch past the point of resistance: the speed increases while the rocker switch is pressed.
- Press down the rocker switch to the point of resistance: the speed decreases gradually.
- Press down the rocker switch past the point of resistance: when driving forward, the speed decreases to approx.
   6 mph/10 km/h; when reversing, the speed decreases to approx. 4 mph/6 km/h.

# **Activating HDC**





Press the button; the LED above the button lights up.

## **Deactivating HDC**

F

Press the button again and the LED goes out. HDC is automatically deactivated

above approx. 37 mph/60 km/h.

#### Display in the instrument cluster



The selected speed is displayed in the speedometer.

- Green: the system is actively braking the vehicle.
- Orange: the system is on standby.

#### Malfunction

A message is displayed in the instrument cluster. HDC is not available, e.g., due to elevated brake temperatures.

# **Adaptive Drive**

## The concept

Adaptive Drive includes the following systems:

- Dynamic Drive, refer to page 119.
- Dynamic Damping Control, refer to page 119.

The system increases driving stability and driv- \ SPORT/SPORT+ ing comfort.

# The concept

Dynamic Drive reduces the lateral inclination of the vehicle that occurs during rapid driving in curves or during quick evasive maneuvers.

Driving stability and driving comfort are increased under all driving conditions. The system utilizes active stabilizer bars on the front and rear axles that react immediately to all driving situations.

## **Programs**

The system offers two different programs.

The programs can be selected via the Driving Dynamics Control, refer to page 120.

#### **SPORT**

Sporty tuning for greater driving agility.

#### COMFORT

Comfort-oriented tuning for optimal comfort.

# **Dynamic Damping Control**

#### The concept

This system reduces undesirable vehicle motion when using a dynamic driving style or traveling on uneven road surfaces.

The system enhances driving dynamics and comfort as required for the road surface and drivina style.

#### **Programs**

The system offers several different programs.

The programs can be selected via the Driving Dynamics Control, refer to page 120.

Consistently sporty control of the shock absorbers for greater driving agility.

# Dynamic Drive FarmaSOSMFORT/ECO PRO

Balanced tuning between the COMFORT+ and SPORT/SPORT+ programs.

#### COMFORT+

Comfort-oriented tuning of the shock absorbers for optimal traveling comfort.

# **Integral Active Steering**

## The concept

Integral Active Steering is a combination of Active Steering and rear axle steering.

Active Steering varies the steering angle of the wheels in relation to the steering wheel movement as a function of the speed.

At speeds up to approx. 37 mph/60 km/h, e.g., in curves, the steering angle is increased, i.e., steering becomes more direct.

The rear axle steering acts to increase maneuverability by turning the rear wheels slightly in a direction opposite to the front wheels.

At higher speeds, the steering angle is increasingly reduced.

The rear wheels are turned to the same angle as the front wheels.

In critical situations, Integral Active Steering can specifically steer the front and rear wheels to stabilize the vehicle before the driver intervenes, e.g., when braking where road conditions differ on the left and right sides of the vehicle.

#### **Initializing**

In rare cases, it may become necessary to initialize the Integral Active Steering.



The warning lamp lights up. A Check Control message is displayed.

- With the engine running, turn the steering wheel all the way to the left and right several times in a uniform manner until the warning lamp disappears.
- Have the system checked if the warning lamp does not go out after moving the steering wheel approx. 6 times or if the steering wheel is at an angle.

## Using snow chains

#### Note

When snow chains are in use, refer to page 196, rear wheel steering is deactivated.

#### **Programs**

The system offers several different programs.

The programs can be selected via the Driving Dynamics Control, refer to page 120.

#### **SPORT**

Consistently sporty tuning of the Integral Active Steering for greater driving agility.

#### **COMFORT**

Balanced tuning of the Integral Active Steering for optimal traveling comfort.

#### Malfunction

In the event of a malfunction, the steering wheel must be turned further, while the vehicle responds more sensitively to steering wheel movements in the higher speed range.

The stability-enhancing intervention may be deactivated.

Proceed cautiously and drive defensively.

Have the system checked.

# **Driving Dynamics Control**

#### The concept

The Driving Dynamics Control can be used to adjust the driving dynamics of the vehicle. For this purpose various programs are available for selection that are activated via the two buttons of the Driving Dynamics Control and the DSC OFF-button.

# **Operating the programs**

Press the button	Program
<b>₽</b> off	DSC OFF TRACTION
	SPORT+ SPORT
▽	COMFORT
	COMFORT+
	ECO PRO

#### **Automatic program change**

The system may automatically switch to COMFORT in the following situations:

- Failure of Integral Active Steering.
- Failure of Dynamic Damping Control.
- The vehicle has a flat tire.

#### **DSC OFF**

Driving stability is limited during acceleration and when driving in bends.

Stabilizing interventions by the Integral Active Steering system are only performed by the rear axle steering.

To increase vehicle stability, activate DSC again as soon as possible.

## **Deactivating DSC: DSC OFF**



Press and hold the button, but not longer than approx. 10 seconds, until the

indicator lamp for DSC OFF lights up in the instrument cluster and DSC OFF is displayed in the tachometer.

The DSC system is switched off.

## **Activating DSC**



Press the button.

DSC OFF and the DSC OFF indicator lamp go out.

## **Indicator/warning lamps**

When DSC OFF is activated, DSC OFF is displayed in the tachometer.



The indicator lamp lights up: DSC OFF is activated.

#### **TRACTION**

Maximum traction on loose road surfaces. DTC Dynamic Traction Control is switched on. Driving stability is limited during acceleration and when driving in bends.

#### **Activating TRACTION**



Press the button.

TRACTION is displayed in the tach-

ometer.

The DSC indicator lamp in the instrument cluster lights up.

#### **Deactivating TRACTION**



Press the button again.

TRACTION and the DSC indicator lamp go out.

#### **Indicator/warning lamps**

When TRACTION is activated, TRACTION is displayed in the tachometer.



The indicator lamp lights up: TRAC-TION is activated.


#### **SPORT+**

Sporty driving with optimized chassis and adapted engine control with limited driving stabilization.

Dynamic Traction Control is switched on.

The driver handles several of the stabilization tasks.

# **Activating SPORT+**



and the DSC OFF indicator lamp lights up in the instrument cluster.

# Automatic program change

When switching on the adjustable speed limit or activating cruise control, the program automatically switches to SPORT mode.

## **Indicator/warning lamps**

SPORT+ is displayed in the instrument cluster.



The DSC OFF indicator lamp lights up: Dynamic Traction Control is activated.

#### **SPORT**

Consistently sporty tuning of the suspension and engine control for greater driving agility with maximum driving stabilization.

The program can be configured to individual specifications.

The configuration is stored for the remote control currently in use.

## **Activating SPORT**



Press the button repeatedly until SPORT appears in the tachometer.

#### **Configuring SPORT**

When the display is activated on the Control Display, refer to page 123, the SPORT driving mode can be set.

After the SPORT driving mode is activated, select "Configure SPORT" on the displayed panel and configure the program.

SPORT can also be configured before it is activated:

- 1. "Settings"
- 2. "SPORT mode" or: "Driving mode"
- 3. Configure driving mode.

This configuration is retrieved when the SPORT driving mode is activated.

#### COMFORT

For a balanced tuning with maximum driving stabilization.

# **Activating COMFORT**

Press the button repeatedly until the program display in the tachometer

goes out.

In certain situations, the system automatically changes to the NORMAL program, automatic program change, refer to page 121.

#### **COMFORT+**

Comfort-oriented tuning of the shock absorbers and adapted engine control for optimal traveling comfort with maximum driving stabilization.

#### **Activating COMFORT+**



ter.

Press the button repeatedly until COMFORT+ appears in the tachome-

#### **ECO PRO**

ECO PRO, refer to page 174, provides consistent tuning to minimize fuel consumption for maximum range with maximum driving stabilization.

Comfort functions and the engine controller are adjusted.

The program can be configured to individual specifications.

# **Activating ECO PRO**



Press button repeatedly until ECO PRO is displayed in the instrument

cluster.

# **Configuring ECO PRO**

- Activate ECO PRO.
- 2. "Configure ECO PRO"

Make the desired settings.

# **Configure driving mode**

Settings can be made for the following driving modes in Driving mode:

- ⊳ SPORT mode, refer to page 122.
- ▶ ECO PRO mode, refer to page 174.

#### Displays in the instrument cluster

#### **Selected program**



The selected program is displayed in the tachometer.

#### **Program selection**



Pressing the button displays a list of the selectable programs.

# **Display on the Control Display**

Program changes can be displayed briefly on the Control Display.

To do so, make the following settings:

- 1. "Settings"
- "Control display""Driving mode"

تلفن شبانه روزی: ۱۵۸۰۲۰۸۵ الفن شبانه روزی: ۱۵۸۰۲۰۸۸ الفن

3. "Driving mode info"

FarmaSOS.com

# **Driving comfort**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# Active Cruise Control with Stop & Go function, ACC

#### The concept

This system can be used to select a desired speed that the vehicle will maintain automatically on clear roads.

To the extent possible, the system automatically adjusts the speed to a slower vehicle ahead of you.

The distance that the vehicle maintains to the vehicle ahead of you can be varied.

For safety reasons, it depends on the speed.

To maintain a certain distance, the system automatically decelerates, applies the brakes lightly, or accelerates again if the vehicle ahead begins moving faster.

If the vehicle ahead of you brakes to a halt, the system is able to detect this within the given system limits. If the vehicle ahead of your drives away again from a halt, your vehicle is able to accelerate if operated accordingly.

Even if some time passes before the vehicle drives away again, the BMW can still be accelerated automatically and simply.

As soon as the road is clear, it accelerates to the desired speed.

The speed is also maintained on downhill gradients, but may not be maintained on uphill slopes if engine power is insufficient.

#### **General information**

When ECO PRO is activated, cruise control is also set to a driving style that saves on fuel consumption.

#### **Notes**

Personal responsibility

The system does not relieve the driver of the responsibility to adapt his or her speed, distance and driving style to the traffic conditions. Drive attentively, and react to the current traffic events. Intervene actively when necessary, e.g., by braking, steering or making an evasive maneuver, otherwise, there is danger of an accident.

## At a glance

#### Buttons on the steering wheel

Press the button	Function
Fa.C	Cruise control on/off, interrupting, refer to page 125
SET	Store/maintain speed, refer to page 126
RES	Resume speed, refer to page 127
/ā\	Reduce distance, refer to page 127
<b>(\$\bar{\pi}\)</b>	Increase distance, refer to page 127
/ <del>‡</del> \	Adjust distance, refer to page 127

Press the button	Function
	Rocker switch: Change/maintain speed, refer to page 126
∠⊕∠	Congestion Assistant ON/OFF Pause, refer to page 130

The arrangement of the buttons varies according to the how the vehicle is equipped or country-specific variants.

#### Radar sensor

A radar sensor is located in the front bumper for detecting vehicles on the road ahead of the vehicle.



A dirty or covered sensor may hinder the detection of vehicles.

- If necessary, clean the radar sensor. Remove layers of snow and ice carefully.
- Do not cover the view field of the radar sensor.

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rearview mirror clean and clear.

# Switching on/off and interrupting cruise control

# Switching on



Press the button on the steering wheel.

The indicator lamps in the instrument cluster light up and the marking in the speedometer is set to the current speed.

Cruise control can be used.

# **Switching off**

Deactivated or interrupted system
If the system is deactivated or interrupted, actively intervene by braking, steering
and, if necessary, with evasive maneuvers; otherwise, there is the danger of an accident occurring.

If switching off the system while stationary, press on the brake pedal at the same time.



Press the button on the steering wheel.

- If active: press twice.
- If interrupted: press once.

The displays go out. The stored desired speed and distance are deleted.

#### Interrupting



Press the button on the steering wheel.

If interrupting the system while stationary, press on the brake pedal at the same time.

The system is automatically interrupted in the following situations:


- When the brakes are applied.
- When transmission position D is disengaged.
- When DTC Dynamic Traction Control is activated or DSC is deactivated.
- When DSC is actively controlling stability.
- ▶ If the safety belt and the driver's door are opened when the vehicle is standing still.
- If the system has not detected objects for an extended period, e.g., on a road with very little traffic without road edge line markings.
- ▶ If the detection range of the radar is disrupted, for example, by dirt or heavy fog.

# Maintaining/storing the speed



Press the button.

Or:



Press the rocker switch while the system is interrupted.

When the system is switched on, the current speed is maintained and stored as the desired speed.

It is displayed in the speedometer and briefly displayed in the instrument cluster, Displays in the instrument cluster, refer to page 128.

When cruise control is maintained or stored, DSC Dynamic Stability Control is switched on, if necessary.

# Changing, maintaining, and storing the speed

The rocker switch can be pressed while the system is interrupted to maintain and store the current speed. DSC Dynamic Stability Control is switched on, if necessary.


Adapting the desired speed

Adapt the desired speed to the road conditions and be ready to brake at all times; otherwise, there is the danger of an accident occurring.

Speed differences

Large differences in speed relative to other vehicles cannot be compensated by the system for example in the following situations:

- When catching up rapidly with a truck.
- When another vehicle suddenly swerves into the wrong lane.
- When stationary objects are approached at speed. ◀



Press the rocker switch up or down repeatedly until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed if the road is clear.

- Each time the rocker switch is pressed to the point of resistance, the desired speed increases or decreases by approx.
   1 mph/1 km/h.
- Each time the rocker switch is pressed past the point of resistance, the desired speed increases or decreases by a maximum of 5 mph/10 km/h.

Hold the rocker switch in position to repeat the action.

#### **Distance**

Selecting a distance

Adjust the distance according to the traffic and weather conditions; otherwise, there is the danger of an accident occurring. Maintain the prescribed safety distance.

#### Reduce distance



Press the button repeatedly until the desired distance is set.

The selected distance, refer to page 128, is displayed in the instrument cluster.

#### Increase distance



Press the button repeatedly until the desired distance is set.

The selected distance, refer to page 128, is displayed in the instrument cluster.

## **Adjust distance**



Press the button repeatedly until the desired distance is set.

# Calling up the desired speed and distance

#### While driving



Press the button with the system switched on.

In the following cases, the stored speed value is deleted and cannot be called up again:

- When the system is switched off.
- When the ignition is switched off.

#### While standing



Before leaving the vehicle, secure it against rolling

Before leaving the vehicle with the engine running, engage position P of the automatic transmission and apply the parking brake. Otherwise, the vehicle may begin to roll. ◀

The system brought the vehicle to a complete standstill.

- Green marking in the speedometer:
  - Your vehicle accelerates automatically as soon as the vehicle in the range of the radar sensor moves off.
  - Marking in the speedometer turns orange: no automatic driving away.

To accelerate to the desired speed automatically, press the accelerator briefly or press the RES or SET button.

Rolling bars in the distance display indicate that the vehicle in the radar sensor detection range has moved off.

Your vehicle was braked to a halt by pressing on the brake pedal and it is standing behind another vehicle:

- 1. Press the button to call up a stored desired speed.
- 2. Release the brake pedal.

3. Press on the accelerator briefly, or press the RES button or the rocker switch when the vehicle ahead of you drives away.

#### Displays in the instrument cluster

#### **Desired speed**



- The marking lights up green: the system is active.
- ➤ The marking lights up orange: the system has been interrupted.
- The marking does not light up: the system is switched off.



With instrument display: the symbol is displayed in the speedometer similarly to the mark for the desired speed.

#### **Brief status display**



Selected desired speed.

If --- appears briefly on the display for Check Control messages, it is possible that the system requirements for operation are currently not met.

## Distance to vehicle ahead of you

The selected distance to the vehicle driving ahead of you is shown.

#### Distance display



Distance 1



Distance 2



Distance 3

#### Distance display



Distance 4

This value is set after the system is switched on.



The system has been interrupted or distance control is deactivated because the accelerator is being pressed; a vehicle was not detected.



Distance control is deactivated because the accelerator is being pressed; a vehicle was detected.

Rolling bars: the detected vehicle has driven away.

#### **Indicator/warning lamps**

Personal responsibility

The indicator and warning lamps do not relieve the driver of the responsibility to adapt his or her desired driving speed and style to the traffic conditions.



The vehicle symbol lights up orange:

A vehicle has been detected ahead of you.



The vehicle symbol flashes orange:

The conditions are not adequate for operating the system.

The system was deactivated but applies the brakes until you actively assume control by pressing on the brake pedal or accelerator.



The vehicle symbol flashes red and an acoustic signal sounds:

You are requested to intervene by braking or making an evasive maneuver.

## **Displays in the Head-up Display**

The information from Active Cruise Control can also be displayed in the Head-up Display.

Adjusting the Head-up Display, refer to page 148.

#### System limits


#### **Speed range**

Best results are achieved when using the system on well-developed roads and highways. The desired speed can be selected between 20 mph/30 km/h to 110 mph/180 km/h.

The system can also be activated when stationary.

Comply with the legal speed limit in every situation when using the system.

#### **Detection range**



The detection capacity of the system and the automatic braking capacity are limited.

Two-wheeled vehicles for instance might not be detected.

Limited detection capacity

Because of the limits to the detection capacity of the camera and the sensor, you should be alert at all times so that you can intervene actively, if necessary; otherwise, there is the danger of an accident occurring.◄


#### **Deceleration**

The system does not decelerate for:

- Pedestrians or similar slow-moving road users.
- Red traffic lights.
- Cross traffic.

Oncoming traffic.

#### **Swerving vehicles**




A vehicle driving in front of you is not detected until it is completely within the same lane as your vehicle.

Swerving vehicles

If a vehicle driving ahead of you suddenly swerves into your lane, the system may not be able to automatically restore the selected distance. This also applies to major speed differences to vehicles driving ahead of you, e.g., when rapidly approaching a truck. When a vehicle driving ahead of you is reliably detected, the system requests that the driver intervene by braking and carrying out evasive maneuvers, if necessary. You must react yourself; otherwise, there is the danger of an accident occurring.

## **Cornering**



If the desired speed is too high for a curve, the speed is reduced slightly in the curve, although curves cannot be anticipated in advance.

Therefore, drive into a curve at an appropriate speed.

In tight curves, situations may result due to the restricted detection range of the system in which a vehicle driving ahead of you may not be detected at all, or not until after a considerable delay.



When approaching a curve, the system may react briefly to the vehicles in the next lane due to the bend of the curve. Any deceleration of the vehicle by the system can be compensated for by briefly accelerating. After the accelerator pedal is released, the system becomes active again and independently controls the speed.

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

#### Malfunction

The system cannot be activated if the radar sensor is not aligned correctly. This may be caused by damage incurred during parking, for example.

A Check Control message is displayed if the system fails.

The function for detecting and responding when approaching stationary vehicles may be limited in the following situation:

- During calibration of the camera immediately after vehicle shipment.
- If the camera is malfunctioning or dirty. A Check Control message is displayed.

## **Driving away**

In some situations, the vehicle cannot drive away automatically, e.g., on steep inclines or behind bumps in the road.

#### Radar sensor

#### For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

#### FCC ID:

OAYARS3-A

Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

# **Congestion Assistant**

## The concept

In congestion situations, the system controls the speed, steers independently and keeps the vehicle in the lane.

To the extent possible, the system automatically adjusts the speed to a slower vehicle ahead of you. The distance that the vehicle maintains to the vehicle ahead of you can be varied. For safety reasons, it depends on the speed. To maintain a certain distance, the system automatically decelerates, applies the brakes lightly, or accelerates again if the vehicle ahead begins moving faster.

When lane markings are detected, the system keeps the vehicle in the lane. For this purpose, the system steers independently as needed, for example, during cornering.

#### **General information**

The congestion assistant determines speed and distance from the vehicle in front via a radar sensor and the position of the lane marking via a camera.

Sensors on the steering wheel detect whether the steering wheel is being touched.

The system is deactivated as soon as contact with the steering wheel is no longer detected. In order to be able to use the Congestion Assistant, place your hands around the steering

When driving with gloves or with protective covers, contact with the steering wheel cannot be detected by the sensors. The system in this case cannot be used.

#### **Notes**

wheel.

Personal responsibility

The system does not relieve the driver of the responsibility to adapt his or her speed, distance and driving style to the traffic conditions. Drive attentively, and react to the current traffic events. Intervene actively when necessary, e.g., by braking, steering or making an evasive maneuver, otherwise, there is danger of an accident.

# **Functional requirements**

- ▶ Drive on approved road type. The data on this are stored in the navigation system.
- Driving on the limited access highway or divided lane roads.
- Sufficient lane width.
- Lane marking is detected.
- Vehicle driving ahead is detected.
- Speed below 25 mph/40 km/h.
- ▶ Both hands on the steering wheel rim.


#### At a glance

#### **Buttons on the steering wheel**

Press the button	Function
∠⊕∠	Congestion Assistant ON/OFF, Pause, refer to page 132.
	Rocker switch: Store, change/maintain speed, refer to page 126.
SET	Maintain, store speed, refer to page 126.
RES	Resume speed, refer to page 127.
/ <del>\$</del> \	Adjust distance, refer to page 127.

#### Radar sensor


A radar sensor is located in the front bumper for detecting vehicles on the road ahead of the vehicle.



A dirty or covered sensor may hinder the detection of vehicles.

- If necessary, clean the radar sensor. Remove layers of snow and ice carefully.
- Do not cover the view field of the radar sensor.

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rearriew mirror clean and clear.

#### Switching on/off and pausing

#### **Switching on**



Press the button.

- Prepare system: press once.
- Activate system:

The system is automatically activated below 25 mph/40 km/h.

If the ACC is not activated: press wiper. With ACC activated: system is ready.



If ACC is not activated: indicator lamp in the instrument cluster comes on.



If ACC is not activated: indicator lamp in the instrument cluster comes on.

Congestion Assistant can be used.

With Congestion Assistant switched on, the Pedestrian Warning system is active.

# **Switching off**

Deactivated or interrupted system

If the system is deactivated or interrupted, actively intervene by braking, steering and, if necessary, with evasive maneuvers; oth-

erwise, there is the danger of an accident occurring. ◀



Press the button.

The indicator goes out. Stored desired speed and distance are still kept by the ACC.

The system no longer steers independently.

#### Interrupting



When active, press the button.

The system is automatically interrupted in the following situations:

- At a speed above 25 mph/40 km/h.
- With only one detected lane marking.
- When you leave the limited access highway.
- When you leave the divided lane road.
- When the steering wheel is released.
- ▶ When steering intervention is active.
- When you leave your own lane.
- With incorrect vehicle ahead.
- When the turn signal is on.



Red flashing and signal tone:

Congestion Assistant is interrupted.
The system no longer steers independently. ACC exercises control.

If the system conditions are met, the system reactivates automatically.

#### **Distance**

Selecting a distance

Adjust the distance according to the traffic and weather conditions; otherwise, there is the danger of an accident occurring. Maintain the prescribed safety distance.

#### **Adjust distance**



Press the button repeatedly until the desired distance is set.

#### Distance to vehicle ahead of you

The selected distance to the vehicle driving ahead of you is shown.

#### Distance display



Distance 1



Distance 2



Distance 3



Distance 4

This value is set after the system is switched on.

Selecting a distance

Adjust the distance according to the traffic and weather conditions; otherwise, there is the danger of an accident occurring. Maintain the prescribed safety distance.

# Displays in the instrument cluster

#### Symbol Description



Congestion Assistant and Distance Control on standby.



Congestion Assistant on standby. Distance control controls within the set distance.



Congestion Assistant activated. The system controls the speed and assists with maintaining the lane.

#### Symbol Description



Rolling bars: at least one functional requirement is no longer satisfied. The system soon deactivates the automatic steering. ACC on standby.



Red flashing and signal tone: congestion Assistant is interrupted. The system does not steer independently. ACC exercises control.

#### **System limits**

When driving within narrow driving lanes, e.g., in construction zones or rescue lanes, the system cannot be activated or meaningfully used.

Limited detection capacity

Because of the limits to the detection capacity of the camera and the sensor, you should be alert at all times so that you can intervene actively, if necessary; otherwise, there is the danger of an accident occurring.◀

Complying with country-specific laws
When the Congestion Assistant is used,
observe specific national laws.

✓

# **Cruise control**

# The concept

The system is functional at speeds beginning at approx. 20 mph/30 km/h.

It maintains the speed that was set using the control elements on the steering wheel.

The system brakes on downhill gradients if engine braking action is insufficient.

Unfavorable conditions

Do not use the system if unfavorable conditions make it impossible to drive at a constant speed, for instance:

On curvy roads.

- In heavy traffic.
- On slippery roads, in fog, snow or rain, or on a loose road surface.

Otherwise, you could lose control of the vehicle and cause an accident. ◀

#### **General information**

When ECO PRO is activated, cruise control is also set to a driving style that saves on fuel consumption.

#### **Controls**

# At a glance

Press the button	Function	
<b>්</b> බ	Cruise control or ing, refer to page	. /
SET	Store/maintain s page 134	peed, refer to
RES	Resume speed, page 135	refer to
	Rocker switch: Change/maintair to page 135	n speed, refer

The arrangement of the buttons varies according to the how the vehicle is equipped or country-specific variants.

# Switching on



Press the button on the steering wheel.

The marking in the speedometer is set to the current speed.

The cruise control can be used.

#### **Switching off**

Deactivated or interrupted system
If the system is deactivated or interrupted, actively intervene by braking and, if necessary, with evasive maneuvers; otherwise, there is the danger of an accident occurring.



Press the button on the steering wheel.

- If active: press twice.
- If interrupted: press once.

The displays go out. The stored desired speed is deleted.

#### **Interrupting**



When active, press the button.

The system is automatically interrupted if:


- The brakes are applied.
- ▶ The transmission position D is disengaged.
- DTC Dynamic Traction Control is activated or DSC is deactivated.
- DSC is actively controlling stability.
- HDC is activated.

# Maintaining/storing the current speed



Press the button.

Or:



Press the rocker switch while the system is interrupted.

When the system is switched on, the current speed is maintained and stored as the desired speed.

It is displayed in the speedometer and briefly displayed in the instrument cluster, Displays in the speedometer, refer to page 135.


When cruise control is maintained or stored, DSC Dynamic Stability Control is switched on, if necessary.

#### **Changing/maintaining speed**

The rocker switch can be pressed while the system is interrupted in order to maintain and store the current speed.

Adapting the desired speed

Adapt the desired speed to the road conditions and be ready to brake at all times; otherwise, there is the danger of an accident occurring.



Press the rocker switch up or down repeatedly until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed if the road is clear.

- Each time the rocker switch is pressed to the point of resistance, the desired speed increases or decreases by approx.
   1 mph/1 km/h.
- ▶ Each time the rocker switch is pressed past the point of resistance, the desired speed increases or decreases by a maximum of 5 mph/10 km/h.

Max. adjustable speed: 140 mph/230 km/h.

Pressing the rocker switch to the resistance point and holding it there accelerates or decelerates the vehicle without requiring pressure on the accelerator. After the rocker switch is released, the vehicle maintains its final speed. Pressing the switch beyond the resistance point causes the vehicle to accelerate more rapidly.

#### Resuming the desired speed



Press the button.

The stored speed is reached and maintained.

## Displays in the instrument cluster

#### **Indicator lamp**



Depending on how the vehicle is equipped, the indicator lamp in the instrument cluster indicates whether the sys-

tem is switched on.

# Desired speed



The marking lights up green: the system is active.

The marking lights up orange: the system has been interrupted.

The marking does not light up: the system is switched off.



With instrument display: the symbol is displayed in the speedometer similarly to the mark for the desired speed.

# **Brief status display**



Selected desired speed.

If --- appears briefly on the display for Check Control messages, it is possible that the system requirements for operation are currently not met.

## **PDC Park Distance Control**

#### The concept

PDC supports you when parking. Objects that you are approaching slowly in front of or behind your vehicle are indicated by:

- Signal tones.
- Visual display.

#### **General information**

Measurements are made by ultrasound sensors in the bumpers.

The range is approx. 6 ft/2 m.

An acoustic warning is first given:

- ▶ By the front sensors and the two rear corner sensors at approx. 24 in/60 cm.
- By the rear middle sensors at approx. 5 ft/1.50 m.

#### **Notes**

Check the traffic situation as well PDC cannot serve as a substitute for the driver's personal judgment of the traffic situation. Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects located outside of the PDC detection range.

Loud noises from outside and inside the vehicle may prevent you from hearing the PDC's signal tone. ◀



Avoid driving quickly with PDC

Avoid approaching an object quickly.

Avoid driving away quickly while PDC is not yet active.

For technical reasons, the system may otherwise be too late in issuing a warning. ◀

#### At a glance

#### **Button in the vehicle**





PDC Park Distance Control

#### Switching on/off

#### Switching/on automatically

Select transmission position R with the engine running.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on if necessary.

# Switching on/off manually



Press the button.

On: the LED lights up.

S.Com

Off: the LED goes out.

In addition to the PDC Park Distance Control, the rearview camera, refer to page 138, can be switched on.

# Switching on the rearview camera via the iDrive

With PDC activated or Top View switched on:

Rar view camera"

The rearview camera image is displayed. The setting is stored for the remote control currently in use.

#### **Display**

#### Signal tones

When approaching an object, an intermittent tone is sounded that indicates the position of the object. For example, if an object is detected to the left rear of the vehicle, a signal tone sounds from the left rear speaker.

The shorter the distance to the object becomes, the shorter the intervals.

If the distance to a detected object is less than approx. 10 in/25 cm, a continuous tone is sounded.

If objects are located both in front of and behind the vehicle, an alternating continuous signal is sounded.

The intermittent tone is interrupted after approx. 3 seconds:

- If the vehicle stops in front of an object that is detected by only one of the corner sensors.
- If moving parallel to a wall.

The signal tone is switched off:

- When the vehicle moves away from an object by more than approx. 4 in/10 cm.
- When transmission position P is engaged.

#### Volume

The volume of the PDC signal can be adjusted, refer to user's manual for Navigation, Entertainment, Communication.

The setting is stored for the remote control currently in use.

#### Visual warning

The approach of the vehicle to an object can be shown on the Control Display. Objects that are farther away are displayed on the Control Display before a signal tone sounds.

A display appears as soon as Park Distance Control (PDC) is activated.

The range of the sensors is represented in the colors red, green and yellow.

If the rearview camera image was selected last, it again appears on the display. To switch to PDC:

- Rear view camera" Select the symbol on the Control Display.
- 2. Press the controller.

The setting is stored for the remote control currently in use.

## **System limits**

#### Limits of ultrasonic measurement

The detection of objects can reach the physical limits of ultrasonic measurement, e.g.:

- With tow bars and trailer hitches.
- With thin or wedge-shaped objects.
- With low objects.
- With objects with corners and sharp edges.

Low objects already displayed, e.g., curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

High, protruding objects such as ledges may not be detected.

#### **False warnings**

PDC may issue a warning under the following conditions even though there is no obstacle within the detection range:

- ▶ In heavy rain.
- When sensors are very dirty or covered in ice.
- When sensors are covered in snow.
- On rough road surfaces.
- In large buildings with right angles and smooth walls, e.g., in underground garages.
- In heavy exhaust.

Due to other ultrasound sources, e.g., sweeping machines, high pressure steam cleaners or neon lights.

#### Malfunction

A Check Control message is displayed.

The range of the sensors is shown as a shaded area on the Control Display.

PDC has failed. Have the system checked.

To ensure full operability:

- Keep the sensors clean and free of ice.
- When using high-pressure washers, do not spray the sensors for long periods and maintain a distance of at least 12 in/30 cm.

cated outside the picture area of the backup camera. ◀

#### At a glance

#### **Button in the vehicle**





Rearview camera

# **Surround View**

## The concept

Surround View comprises various camera assistance systems that help the driver when parking, maneuvering, and at complex exits and intersections.

- Rearview camera, refer to page 138
- Side View, refer to page 142.

#### Camera



The camera lens is located under the BMW emblem of the trunk lid. The image quality may be impaired by dirt. The camera calibrates itself regularly after the system has been switched off. This is why the emblem on the tailgate remains open after the system has been deactivated and while driving. The emblem closes automatically as soon as calibration is complete.

Clean the lens, refer to page 218.

# **Backup camera**

#### The concept

The backup camera provides assistance in parking and maneuvering backwards. The area behind the vehicle is shown on the Control Display.

#### **Hints**

Check the traffic situation as well
Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects lo-

#### Switching on/off

#### Switching on automatically

Select transmission position R with the engine running.

The backup camera image is displayed if the system was switched on via the iDrive.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on if necessary.

## Switching on/off manually



Press the button.

- ▷ On: the LED lights up.
- ▷ Off: the LED goes out.

The PDC is shown on the Control Display.

# Switching on the rearview camera via the iDrive

With PDC activated or Top View switched on:

R "Rear view camera"

The rearview camera image is displayed. The setting is stored for the remote control currently in use.

## **Display on the Control Display**

#### **Functional requirement**

- The rearview camera is switched on.
- The trunk lid is fully closed.

# **Activating the assistance functions**

More than one assistance function can be active at the same time.

Parking aid lines


"Parking aid lines"

Pathway and turning circle lines are displayed.

Obstacle marking

<sup>P</sup> "Obstacle marking"
Spatially-shaped markings are displayed.

#### **Pathway lines**



- Can be shown in the rearview camera image when in transmission position R.
- Help you to estimate the space required when parking and maneuvering on level roads.
- Are dependent on the current steering angle and are continuously adjusted to the steering wheel movements.


## Turning circle lines



- Can be shown in the rearview camera image.
- Show the course of the smallest possible turning circle on a level road.
- Only one turning circle line is displayed when the steering wheel is turned.

#### **Obstacle marking**

#### **General information**




 Spatially-shaped markings can be shown in the rearview camera image.


Their colored steps match the markings of the PDC. This simplifies estimation of the distance to the object shown.

# Parking using pathway and turning circle lines

Position the vehicle so that the turning circle lines lead to within the limits of the parking space.



2. Turn the steering wheel to the point where the pathway line covers the corresponding turning circle line.



#### **Display settings**

#### **Brightness**

With the rearview camera switched on:

- 1. Select the symbol.
- 2. Turn the controller until the desired setting is reached, and press the controller.

#### **Contrast**

With the rearview camera switched on:

- 2. Turn the controller until the desired setting is reached, and press the controller.

# **System limits**

# **Detection of objects**

High, protruding objects such as ledges may not be detected by the rearview camera.

# **Top View**

## The concept

Top View assists you in parking and maneuvering. The area around the doors and the road area around the vehicle are shown on the Control Display for this purpose.

#### **General information**

The image is captured by two cameras integrated in the exterior mirrors and by the backup camera.

The range is at least 7 ft/2 m to the side and rear.

In this way, obstacles up to the height of the exterior mirrors are detected early.

#### Notes

Check the traffic situation as well
Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects located outside the picture area of the cameras.

#### At a glance


#### **Button in the vehicle**





Top View

#### **Cameras**



The lenses of the Top View cameras are located at the bottom of the exterior mirror housings. The image quality may be impaired by dirt.

Clean the lens, refer to page 218.

## Switching on/off

#### Switching on automatically

Select transmission position R with the engine running.

The Top View and PDC images are displayed if the system is switched on via iDrive.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on if necessary.

# Switching on/off manually



Press the button.

- On: the LED lights up.
- Off: the LED goes out.

Top View is displayed.

# Switching on the backup camera via the iDrive

With Top View switched on:

R¬ы "Rear view camera"


The backup camera image is displayed. The setting is stored for the remote control currently in use.

#### **Display**

#### Visual warning

The approach of the vehicle to an object can be shown on the Control Display.

When the distance to an object is small, a red bar is shown in front of the vehicle, as it is in the PDC display.



The display appears as soon as Top View is activated.

If the rearview camera image was selected last, it again appears on the display when reverse gear is selected. To switch to Top View:

"Rear view camera" Select the symbol on the Control Display.

The setting is stored for the remote control currently in use.

## **Brightness**

With Top View switched on:

- 1. Select the symbol.
- Turn the controller until the desired setting is reached, and press the controller.

#### **Contrast**

With Top View switched on:

- Select the symbol.
- 2. Turn the controller until the desired setting is reached, and press the controller.

# Displaying the turning circle and pathway lines

- The static, red turning circle line shows the space needed to the side of the vehicle when the steering wheel is turned all the way.
- The variable, green pathway line assists you in assessing the amount of space actually needed to the side of the vehicle.
  - The pathway line is dependent on the current steering angle and is continuously adjusted with the steering wheel movement.

"Parking aid lines"

Turning circle and pathway lines are displayed.

#### **System limits**

Top View cannot be used in the following situations:

- With a door open.
- With the trunk lid open.
- With an exterior mirror folded in.

A Check Control message is displayed in some of these situations.

# **Side View**

5.com

# The concept

Side View provides an early look at cross traffic at blind driveways and intersections. Road users concealed by obstacles to the left and right of the vehicle can only be detected relatively late from the driver's seat. To improve visibility, two cameras in the front of the vehicle record the traffic situation on each side.

#### **Notes**

The images from both cameras are shown simultaneously on the Control Display.

Check the traffic situation as well
Check the traffic situation around the vehicle on blind driveways and intersections with your own eyes. Otherwise, an accident could result from road users or objects located outside the picture area of the Side View cameras.

#### At a glance

#### **Button in the vehicle**





Side View

#### **Cameras**



Two cameras integrated in the bumpers capture the image.

The two camera lenses are located on the sides of the bumper.

The image quality may be impaired by dirt. Clean the lens, refer to page 218.

#### Switching on/off

#### Switching on/off manually



Press the button.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on if necessary.

#### **Display**

The traffic area to the left and right is displayed on the Control Display.



Guidelines at the bottom of the image show the position of the front of the vehicle.

## **Brightness**

With the Side View switched on:

- 1. 🔅 "Brightness"
- Turn the controller until the desired setting is reached, and press the controller.

#### Contrast

With the Side View switched on:

- 1. 


  "Contrast"
- Turn the controller until the desired setting is reached, and press the controller.

#### **System limits**

The cameras capture a maximum range of 330 ft/100 m.

# **Parking assistant**

#### The concept



This system assists the driver in parking parallel to the road.

Ultrasound sensors measure parking spaces on both sides of the vehicle.

The parking assistant calculates the best possible parking line and takes control of steering during the parking procedure.

When parking, also take note of the visual and acoustic information issued by the PDC and the parking assistant and react accordingly.

A component of the parking assistant is the PDC Park Distance Control, refer to page 136.

#### **Hints**

Personal responsibility
The parking assistant does not relieve
the driver of responsibility for the vehicle during the parking procedure.

Watch the parking space and parking procedure closely and intervene if necessary; otherwise, there is the danger of an accident. ◄

Changes to the parking space
Changes to the parking space after it was measured are not taken into account by the system.

Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◀

Transporting loads

Loads that extend beyond the perimeter of the vehicle are not taken into account by the system during the parking procedure.

Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◀

**↑** Curbs

The parking assistant may steer the vehicle over or onto curbs.

Therefore, always be alert and ready to intervene; otherwise, the wheels, tires, or the vehicle may become damaged. ◄

An engine that has been switched off by the Auto Start Stop function is restarted automatically when the parking assistant is activated.

#### Requirements

 $\Lambda \omega$  :تلفن شبانه روزی

## For measuring parking spaces

- Maximum speed while driving forward approx. 22 mph/35 km/h.
- ▶ Maximum distance to row of parked vehicles: 5 ft/1.5 m.

# Suitable parking space

- ▶ Gap between two objects with a minimum length of approx. 5 ft/1.5 m.
- Minimum length of the gap: own vehicle's length plus approx. 4 ft/1.2 m.
- ▶ Minimum depth: approx. 5 ft/1.5 m.

## For parking procedure

- Closed doors.
- Parking brake released.

### At a glance


### Button in the vehicle





Parking assistant

#### **Ultrasound sensors**



The ultrasound sensors used to measure parking spaces are located in the side turn signals.

To ensure full operability:

- Keep the sensors clean and free of ice.
- When using high-pressure washers, do not spray the sensors for long periods and maintain a distance of at least 12 in/30 cm.

### Switching on/off

### Switching on with the button



Press the button.

The LED lights up.

The current status of the parking space search is indicated on the Control Display.

Parking assistant is activated automatically.

### **Switching on with reverse gear**

Shift into reverse.

The current status of the parking space search is indicated on the Control Display.

Activate: <sup>P</sup> ⊕ "Parking Assistant" Select the symbol in the Control Display.

### Switching off

The system can be deactivated as follows:



Press the button.

Switch off the ignition.

### **Display on the Control Display**

### **Activating/deactivating the system**

### Symbol Meaning


P<sub>G</sub>

Gray: the system is not available.

White: the system is available but not activated.

The sÿstem is activated.

## Without Professional navigation system or TV: system status



The status is displayed with symbols.




Gray: parking space search.

Blue: the system is activated. A suitable parking space was found.




The parking procedure is active. Steering control has been seized.

### Status of the parking space search



- Gray, arrow 1: parking space search.
- Blue, arrow 2: parking space is suitable.
   The vehicle is parked in the parking space if the parking procedure is active.
- No display: no parking space search.

## With navigation system professional or TV: status of the system



- Colored symbols, see arrows, on the side of the vehicle representation. Parking assistant is activated and search for parking space active.
- Suitable parking spaces are displayed next to the vehicle symbol at the edge of the road as on the Control Display. When the parking assistant is active, suitable parking spaces are highlighted.



The parking procedure is active. Steering control has been seized.

Parking space search is always active whenever the vehicle is moving forwards slow and straight, even if the system is deactivated. When the system is deactivated, the displays on the Control Display are shown in gray.

### Parking using the parking assistant

Check the traffic situation as well
Loud sounds outside and within the vehicle can drown out the signal tones of the parking assistant and PDC.

Check the traffic situation around the vehicle with your own eyes, otherwise, there is the danger of an accident. ◄

- 1. Switch on the parking assistant and activate it if necessary.
- The status of the parking space search is indicated on the Control Display.
- 2. Follow the instructions on the Control Display.

To achieve the best possible parking position, wait for the automatic steering wheel movement after the gear change when the vehicle is stationary.

- The end of the parking procedure is indicated on the Control Display.
- Adjust the parking position yourself if necessary.

### Interrupting manually

The parking assistant can be interrupted at any time:

- ▶ Po "Parking Assistant" Select the symbol on the Control Display.
- P∥▲

Press the button.

### Interrupting automatically

The system is interrupted automatically in the following situations:

- If the driver grasps the steering wheel or if he takes over steering.
- ▶ If a gear is selected that does not match the instruction on the Control Display.
- If a turn signal is activated in the opposite direction to the desired side for parking.
- If the vehicle speed exceeds approx.
   6 mph/10 km/h.
- On snow-covered or slippery road surfaces if necessary.
- ▶ If doors are open.
- When there are obstacles that are hard to overcome, such as curbs.
- When there are obstacles that suddenly arise.
- If a maximum number of parking attempts or the time taken for parking is exceeded.

A Check Control message is displayed.

### Continuing

An interrupted parking procedure can be continued if necessary.

Follow the instructions on the Control Display to do this.

### **System limits**

### No parking assistance

The parking assistant does not offer assistance in the following situations:

In tight curves.

### **Functional limitations**

The system may not be fully functional in the following situations:

- When sensors are dirty or iced over.
- In heavy fog, rain or snowfall.

- On bumpy road surfaces such as gravel roads.
- On slippery ground.
- On steep uphill or downhill grades.
- When leaves or snow has collected in the parking space.

### Limits of ultrasonic measurement

The detection of objects can reach the physical limits of ultrasonic measurement, e.g., in the following circumstances:

- With tow bars and trailer hitches.
- With thin or wedge-shaped objects.
- With elevated, protruding objects such asledges or cargo.
- With objects with corners and sharp edges.
- With objects with a fine surface structure, such as fences.

Low objects already displayed, e.g., curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

High, protruding objects such as ledges may not be detected.

The parking assistant may identify parking spaces that are not suitable for parking.


#### Malfunction

A Check Control message is displayed.

The parking assistant failed. Have the system checked.

### **Head-up Display**

### The concept



This system projects important information into the driver's field of vision, e.g., the speed. In this way, the driver can get information without averting his or her eyes from the road.

### **Display visibility**

The visibility of the displays in the Head-up Display is influenced by:

- Certain sitting positions.
- Objects on the cover of the Head-up Display.
- Sunglasses with certain polarization filters.
- Wet roads.
- Unfavorable light conditions.

If the image is distorted, check the basic settings.

### Switching on/off





Press the button.

### **Display**

### **Overview**

- Speed.
- Navigation system.
- Check Control messages.
- Collision warning.
- Speed limit detection.
- Cruise control.
- Distance information.
- Congestion Assistant.
- Pedestrian warning.
- Selection list from the instrument cluster.

Some of this information is only displayed briefly as needed.

## Selecting displays in the Head-up Display

- 1. "Settings"
- "Head-Up Display"
- 3. \(\(\)"Displayed information"
- Select the desired displays in the Head-up Display.

The settings are stored for the remote control currently in use.

### **Setting the brightness**

The brightness is automatically adjusted to the ambient light.

The basic setting can be adjusted manually.

- 1. "Settings"
- 2. "Head-Up Display"
- 3. "Brightness"
- 4. Turn the controller.

When the low beams are switched on, the brightness of the Head-up Display can be additionally influenced using the instrument lighting.

The setting is stored for the remote control currently in use.

### Adjusting the height

- "Settings"
- 2. "Head-Up Display"
- 3. "Height"
- 4. Turn the controller.

The setting is stored for the remote control currently in use.

### **Setting the rotation**

- 1. "Settings"
- 2. "Head-Up Display"
- 3. "Rotation"
- 4. Turn the controller.

The setting is stored for the remote control currently in use.

### **Special windshield**

The windshield is part of the system.

The shape of the windshield makes it possible to display a precise image.

A film in the windshield prevents double images from being displayed.

Therefore, have the special windshield replaced by a service center only.

### **Distance information**

### The concept

The system displays a symbol in the Head-up Display to indicate that the distance behind the vehicle in front is not sufficient.

### **General information**

The distance is determined by the radar sensor of the Active Cruise Control.

#### Hints

A

Personal responsibility

The display does not relieve the driver of the responsibility to adapt his or her distance and driving style to the traffic conditions. Maintain the prescribed safety distance.

### At a glance

#### Radar sensor

A radar sensor is located in the front bumper for detecting vehicles on the road ahead of the vehicle.



A dirty or covered sensor may hinder the detection of vehicles.

- If necessary, clean the radar sensor. Remove layers of snow and ice carefully.
  - Do not cover the view field of the radar sensor.

### **Switching on**

- 1. Switching on Head-Up Display, refer to page 148.
- "Distance info": Select the indication in the Head-Up Display, refer to page 148.

### Display in the Head-up Display



The symbol is displayed when the distance from the vehicle traveling ahead is too short.

### **Functional requirements**

Active Cruise Control switched off.

- Display in the Head-up Display selected.
- Distance too short for longer than about 2 seconds.
- Speed greater than approx.40 mph/70 km/h.

#### Malfunction

The system cannot be activated if the radar sensor is not aligned correctly. This may be caused by damage incurred during parking, for example.

A Check Control message is displayed if the system fails.



### **Climate control**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **Automatic climate control**



- 1 Air distribution, left
- 2 Temperature, left
- 3 AUTO program, left
- 4 Air flow, AUTO intensity, left, residual heat
- 5 Remove ice and condensation
- 6 Maximum cooling
- 7 Display
- 8 Air volume, AUTO intensity, right
- 9 AUTO program, right
- 10 Temperature, right

- **11** Air distribution, right
- **12** Seat heating, right 47
- 13 Active seat ventilation, right 47
- 14 Automatic recirculated-air control/recirculated-air mode
- 15 Cooling function
- 16 Rear window defroster
- 17 SYNC program
- **18** Active seat ventilation, left 47
- **19** Seat heating, left 47

### Climate control functions in detail

#### Manual air distribution



Press the button repeatedly to select a program:

- Upper body region.
- Upper body region and footwell.
- Footwell.
- Windows and footwell.
- ▶ Windows, upper body region, and footwell.
- Windows: driver's side only.
- Windows and upper body region.

If the windows are fogged over, press the AUTO button on the driver's side to utilize the condensation sensor.

### **Temperature**



Turn the wheel to set the desired temperature.

The automatic climate control achieves this temperature as quickly as possible, if necessary with the maximum cooling or heating capacity, and then keeps it constant.

Avoid rapidly switching between different temperature settings. Otherwise, the automatic climate control will not have sufficient time to adjust the set temperature.

### **AUTO** program

Press the button.

Air volume, air distribution, and temperature are controlled automatically.

Depending on the selected temperature, the AUTO intensity, and outside influences, the air is directed to the windshield, side windows, upper body, and into the footwell.

The cooling function, refer to page 153, is switched on automatically with the AUTO program.

At the same time, a condensation sensor controls the program so as to prevent window condensation as much as possible.

### Intensity of the AUTO program

With the AUTO program switched on, automatic control of the air flow and air distribution can be adjusted.



Press the left or right side of the button: decrease or increase the inten-

sity.

The selected intensity is shown on the display of the automatic climate control.

### Air flow, manual

To be able to manually adjust the air flow, switch off the AUTO program first.



Press the left or right side of the button: decrease or increase air flow.

The selected air flow is shown on the display of the automatic climate control.

The air flow of the automatic climate control may be reduced automatically to save battery power.

## Defrosting windows and removing condensation

Press the button.

lce and condensation are quickly removed from the windshield and the front side windows.

The air volume can be adjusted when the program is active.

If the windows are fogged over, you can also switch on the cooling function or press the AUTO button to utilize the condensation sensor.

### **Maximum cooling**

Press the button.

The system is set to the lowest temperature, maximum air flow and air circulation mode.

Air flows out of the vents for the upper body region. The vents need to be open for this.

Air is cooled as quickly as possible:

- At an external temperature of approx. 32 °F/0 °C.
- ▶ When the engine is running.

The air volume can be adjusted when the program is active.

## Automatic recirculated-air control/recirculated-air mode /

You can respond to unpleasant odors or pollutants in the immediate environment by temporarily suspending the supply of outside air. The system then recirculates the air currently within the vehicle.



Press the button repeatedly to select an operating mode:

- LEDs off: outside air flows in continuously.
- Left LED on, automatic recirculated-air control: a sensor detects pollutants in the outside air and controls the shutoff automatically.
- Right LED on, recirculated-air mode: the supply of outside air into the vehicle is permanently blocked.

If the windows are fogged over, switch off the recirculated-air mode and press the AUTO button on the driver's side to utilize the condensation sensor. Make sure that air can flow onto the windshield.

Continuous recirculated-air mode
The recirculated-air mode should not be used for an extended period of time, as the air quality inside the vehicle deteriorates steadily.

### **Cooling function**

The passenger compartment can only be cooled with the engine running.

A/C Press the button.

The air is cooled and dehumidified and – depending on the temperature setting – warmed again.

Depending on the weather, the windshield may fog up briefly when the engine is started.

The cooling function is switched on automatically with the AUTO program.

When using the automatic climate control, condensation water, refer to page 170, develops that exits underneath the vehicle.

### Rear window defroster

Press the button.

The rear window defroster switches off automatically after a certain period of time.

### SYNC program

Press the button.

Current settings on the driver's side for the temperature, air volume, air distribution, and AUTO program are transferred to the front passenger side.

The program is switched off if the settings on the front passenger side are changed.

#### Residual heat

The heat stored in the engine is used to heat the interior.

### **Functional requirement**

- Up to 20 minutes after the engine has been switched off.
- Warm engine.
- The battery is sufficiently charged.
- External temperature below 77 °F/25 °C.

### Switching on

- 1. Switch off the ignition.
- 2. Press the right side of the button on the driver's side.

The symbol appears on the automatic climate Control Display.

The interior temperature, air volume and air distribution can be adjusted with the ignition switched on.

### **Switching off**


At the lowest fan speed, press the left side of the button on the driver's side.

The symbol on the display of the automatic climate control flashes.

### Switching the system on off

### **Switching off**

Complete system:



On the front passenger side:



Press and hold the left button on the front passenger side.

### **Switching on**

Press any button except:

- SYNC program.
- Rear window defroster.
- Left side of Air volume button.
- Seat heating.
- Seat ventilation.

### Microfilter/activated-charcoal filter


The microfilter removes dust and pollen from the incoming air.

The activated-charcoal filter removes gaseous pollutants from the outside air that enters the vehicle.

This combined filter should be replaced during scheduled maintenance, refer to page 202, of your vehicle.

### **Ventilation**

#### Front ventilation



Thumbwheel to vary the temperature, arrow 1.

Toward blue: colder.

Toward red: warmer.

- > Lever for changing the air flow direction,

  ↑ \( \alpha \) arrow 2. (1.4.4.4)
  - ➤ Thumbwheels for opening and closing the vents continuously, arrows 3.

## Adjusting the ventilation

Ventilation for cooling:
 Adjust the vent to direct the air in your direction, e.g., if the vehicle interior is hot from the sun.

Draft-free ventilation:Adjust the vent to let the air flow past you.

### Parked-car ventilation/ heating

### The concept

The parked-car ventilation ventilates the vehicle interior and lowers its temperature, if necessary. The parked-car heating warms the vehicle interior, making snow and ice easier to remove. With the ignition switched off, the air is automatically routed to the windshield, to the side windows, and into the footwell.

The systems can be switched on and off directly or by using two preset departure times.

The switch-on time is automatically determined based on the temperature. The systems promptly switch on before the selected departure time.

Operation takes place on the iDrive or the remote control.

#### Note

Parked-car heating in enclosed areas
Do not operate the parked-car heating in
enclosed areas, as breathing of the harmful exhaust fumes may lead to loss of consciousness
and death. The exhaust gases contain carbon
monoxide, an odorless and colorless but highly
toxic gas. Switch off the parked-car heating
when refueling.

At external temperatures below 32 °F/0 °C, water vapor occurs that emerges from below the vehicle.

### **Functional requirements**

#### Parked-car ventilation

- With remote control or when the departure time is preselected: depends on internal, external and set temperature.
- Direct operation via iDrive: any external temperature.
- ▶ In direct mode via remote control: external temperature above approx. 59 °F/15 °C.

Open the vents to allow air to flow out.

### Parked-car heating

With remote control or when the departure time is preselected: depends on internal, external and set temperature.

- Direct operation via iDrive: any external temperature.
- ▷ In direct mode via remote control: external temperature below approx. 59 °F/15 °C.
- The battery is sufficiently charged.
- ▶ The fuel tank is filled to above the reserve range.

If the parked-car heating has not been used for several months, it may be necessary to switch the system on again after several minutes.

### Switching on/off directly

- 1. "Settings"
- 2. "Climate"
- 3 "Activate ind. heating" or "Activate comf, ventilation"
- The symbol on the automatic climate control flashes if the system is switched on.

The system continues to run for some time after being switched off.

### 

- 1. "Settings"
- 2. "Climate"
- 3. "Dep. time 1:" or "Dep. time 2:"
- Set the desired time.


### Activating the departure time

- 1. "Settings"
- 2. "Climate"
- 3. "Activate depart. time 1" or "Activate depart. time 2"
- **%** The symbol on the automatic climate control lights up when the departure time is activated.
- **%** The symbol on the automatic climate control flashes when the system has been switched on.

The system will only be switched on within the next 24 hours. After that, it needs to reactivated.

### Remote control

### At a glance



- 1 LED: transmission confirmation
- 2 Switching on/off
- 3 Activate parked-car ventilation/heating
- 4 Deactivate parked-car ventilation/heating

### Remote control range

The reception-dependent average range is approx. 490 ft/150 m.

The range is best when the remote control is held upright and as high as possible. \_ \( \lambda \) \( \lambda \)

### Switching on/off directly

- 1. Press the button until the green LED lights up.
- Within approx. the next 5 seconds, press the desired button until the green or red LED lights up:



Switching on



Switching off

Correct transmission to the system is confirmed for approx. 2 seconds by rapid flashing of the green LED.

If there is a transmission error, the red LED lights up for approx. 2 seconds.

The symbol on the display of the automatic climate control flashes.

### **Frequencies**

The remote control may not function properly if it experiences local interference from other systems or devices that use the same frequency.

### Replacing the batteries

Replace the battery if a Check Control message is displayed or if the LED either no longer lights up or flashes when the remote control is activated.

No rechargeable batteries

Do not use rechargeable batteries, as damage may result from the substances in the batteries.

■



- 1. Use a suitable object to unclip the battery compartment, arrow 1.
- Remove the cover of the battery compartment; see arrow 2.
- 3. Insert batteries of the same type.
- 4. Press the cover closed.



Take the used battery to a recycling center or to your service center.

#### New remote control

A new remote control can be put into operation as a second device or if the original one was lost; it can be initialized by your service center if needed.

Two remote control devices can be used with the vehicle.

## **Interior equipment**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## Integrated universal remote control

### The concept

The integrated universal remote control can operate up to 3 functions of remote-controlled systems such as garage door drives or lighting systems. The integrated universal remote control replaces up to 3 different hand-held transmitters. To operate the remote control, the buttons on the interior rearview mirror must be programmed with the desired functions. The hand-held transmitter for the particular system is required in order to program the remote control.

During programming

During programming and before activating a device using the integrated universal remote control, ensure that there are no people, animals, or objects in the range of movement of the remote-controlled device; otherwise, there is a risk of injury or damage.

Also follow the safety instructions of the handheld transmitter. ◄

Before selling the vehicle, delete the stored functions for the sake of security.

### Compatibility



If this symbol is printed on the packaging or in the instructions of the system to be controlled, the system is gener-


ally compatible with the integrated universal remote control.

If you have any questions, please contact:

- Your service center.
- www.homelink.com on the Internet.

HomeLink is a registered trademark of Johnson Controls, Inc.

## Controls on the interior rearview



- LED, arrow 1.
- Buttons, arrow 2.
- ▶ The hand-held transmitter, arrow 3, is required for programming.

### **Programming**

#### General information

- 1. Switch on the ignition.
- 2. Initial setup:

Press and hold the left and right button on the interior rearview mirror simultaneously for approximately 20 seconds until the LED on the interior rearview mirror flashes. This erases all programming of the buttons on the interior rearriew mirror.

- 3. Hold the hand-held transmitter for the system to be controlled approx. 1 to 3 in/2.5 to 8 cm away from the buttons on the interior rearview mirror. The required distance depends on the manual transmitter.
- 4. Simultaneously press and hold the button of the desired function on the hand-held transmitter and the button to be programmed on the interior rearview mirror. The LED on the interior rearview mirror will begin flashing slowly.
- Release both buttons as soon as the LED flashes more rapidly. When the LED is flashing faster, this indicates that the button on the interior rearview mirror has been programmed.

If the LED does not flash faster after at least 60 seconds, change the distance between the interior rearview mirror and the hand-held transmitter and repeat the step. Several more attempts at different distances may be necessary. Wait at least 15 seconds between attempts.

Canada: if programming with the handheld transmitter was interrupted, hold down the interior rearview mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds.

6. To program other functions on other buttons, repeat steps 3 to 5.

The systems can be controlled using the interior rearview mirror buttons.

### Special feature of the alternatingcode wireless system

If you are unable to operate the system after repeated programming, please check if the system to be controlled features an alternating-code system.

Read the system's operating manual, or press the programmed button on the interior rearview mirror longer. If the LED on the interior rearview mirror starts flashing rapidly and then stays lit constantly for 2 seconds, the system features an alternating-code system. Flashing and continuous illumination of the LED will repeat for approximately 20 seconds.

For systems with an alternating-code system, the integrated universal remote control and the system also have to be synchronized.

Please read the operating manual of the system being set up for information on how to synchronize the system.

Synchronizing is easier with the aid of a second person.

### To synchronize:

- Park the vehicle within range of the remote-controlled system.
- 2. Program the relevant button on the interior rearview mirror as described.
- 3. Locate and press the synchronizing button on the system being programmed. You have approx. 30 seconds for the next step.
- 4. Hold down the programmed button on the interior rearview mirror for approximately 3 seconds and then release it. If necessary, repeat this work step up to three times in order to finish synchronization. Once synchronization is complete, the programmed function will be carried out.

### Reprogramming individual buttons

- 1. Switch on the ignition.
- 2. Press and hold the interior rearview mirror button to be programmed.
- As soon as the interior rearview mirror LED starts flashing slowly, hold the hand-held transmitter for the system to be controlled approx. 1 to 3 in/2.5 to 8 cm away from the buttons on the interior rearview mirror. The required distance depends on the manual transmitter.

- Likewise, press and hold the button of the desired function on the hand-held transmitter.
- Release both buttons as soon as the interior rearview mirror LED flashes more rapidly. When the LED is flashing faster, this indicates that the button on the interior rearview mirror has been programmed.
   The system can then be controlled by the button on the interior rearview mirror.

If the LED does not flash faster after at least 60 seconds, change the distance and repeat the step. Several more attempts at different distances may be necessary. Wait at least 15 seconds between attempts.

Canada: if programming with the handheld transmitter was interrupted, hold down the interior rearview mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds. proximately 20 seconds until the LED flashes rapidly. All stored functions are deleted. The functions cannot be deleted individually.

### **Ashtray/cigarette lighter**

### **Automatic transmission: open**



Press the button.

### **Emptying**

Take out the insert.

### **Controls**

Before operation

Before operating a system using the integrated universal remote control, ensure that there are no people, animals, or objects within the range of movement of the remotecontrolled system; otherwise, there is a risk of injury or damage.

Also follow the safety instructions of the handheld transmitter. ◄

The system, such as the garage door, can be operated using the button on the interior rearview mirror while the engine is running or when the ignition is started. To do this, hold down the button within receiving range of the system until the function is activated. The interior rearview mirror LED stays lit while the wireless signal is being transmitted.

### **Deleting stored functions**

Press and hold the left and right button on the interior rearview mirror simultaneously for ap-

### **\\_人人人タY +人**(Lighter)



Push in the lighter.

The lighter can be removed as soon as it pops back out.

Danger of burns

Only hold the hot lighter by its knob; otherwise, there is the danger of getting burned.

Switch off the ignition and take the remote control with you when leaving the vehicle so that children cannot use the lighter and burn themselves.◄

Replace the cover after use
Reinsert the lighter or socket cover after
use, otherwise objects may get into the lighter
socket or fixture and cause a short circuit.

## Connecting electrical devices

#### **Hints**

Do not plug chargers into the socket
Do not connect battery chargers to the
factory-installed sockets in the vehicle as this
may damage the battery.

✓

Replace the cover after use
Reinsert the lighter or socket cover after
use, otherwise objects may get into the lighter
socket or fixture and cause a short circuit.

### **Sockets**

The lighter socket can be used as a socket for electrical equipment while the engine is running or when the ignition is switched on. The total load of all sockets must not exceed 140 watts at 12 volts.

Do not damage the socket by using unsuitable connectors.

## Automatic transmission: center console



Press the button.

Remove the cover or cigarette lighter.


### In the front passenger footwell



Socket is located below the glove compartment.

To access the socket: fold open the cover.

### Center armrest



Remove the cover.

## OS.com

## Ski bag

### **Capacity**

The ski bag makes it possible to transport two pairs of skis up to a length of 6 ft/2.10 m.

### Preparing and loading the ski bag

1. Pull the release in the direction of the arrow, and remove the insert from the front. If

necessary, when pulling the release, press against the insert.



- 2. Lay out the ski bag.
- Press button in the cargo area, open tailboard and attach to the rear wall via magnetic holder.

## Stowing the ski bag

Proceed in the reverse order of loading.

When replacing the insert, place both pins into the rail at the bottom and press the insert back in place until a 'click' is heard. Ensure that the rear seat backrest upholstery is not damaged.





- Load the ski bag. If necessary, wrap the sharp edges of the skis.
- 5. Tighten the retaining strap.



Securing the ski bag
Secure the ski bag by tightening the retaining strap; otherwise, the contents could present a source of danger to the passengers, for example during braking or evasive maneuvers.

## **Storage compartments**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **Notes**



No loose objects in the passenger compartment

Do not stow any objects in the passenger compartment without securing them; otherwise, they may present a danger to occupants for instance during braking and avoidance maneuvers.



Do not place anti-slip mats on the dash-

Do not place anti-slip mats on the dashboard. The mat materials could damage the dashboard. ◀

### **Storage compartments**

The following storage compartments are available in the vehicle interior:

- Glove compartment on the front passenger side, refer to page 162.
- Storage compartment in the center armrest, refer to page 163.
- Compartments in the doors.
- Pockets on the backrests of the front seats.
- Net in the front passenger footwell.

### **Glove compartment**

#### Note



Close the glove compartment again immediately

Close the glove compartment immediately after use while driving; otherwise, injury may occur during accidents. ◄

### **Opening**



Pull the handle. تلفن

The light in the glove compartment switches on.

### Closing

Fold up the cover.


### **USB** interface for data transfer

### The concept

Connection for importing and exporting data on USB devices, e.g.:


- ▶ Personal Profile settings, refer to page 31.
- Music collection, see user's manual for Navigation, Entertainment and Communication.

## Without Professional navigation system or TV: at a glance



The USB interface is located in the center armrest.

## Without Professional navigation system or TV: at a glance



The USB interface is located in the glove compartment.

#### **Notes**

Observe the following when connecting:

- Do not use force when plugging the connector into the USB interface.
- Do not connect devices such as fans or lamps to the USB interface.
- Do not connect USB hard drives.
- Do not use the USB interface to recharge external devices.

### Front center armrest

### **Opening**

A storage compartment is located in the center armrest between the front seats.



Press the buttons next to the lock.

### Locking the storage compartment



The storage compartment in the armrest can be locked with an integrated key to separately secure the trunk lid, refer to page 37, for example.

After the storage compartment is locked, the remote control can be handed out without the integrated key, refer to page 30, for instance at a hotel.

This prevents access to the storage compartment and to the cargo area.

## Connection for an external audio device



Description, see user's manual for Navigation, Entertainment and Communication.

### **Clothes hooks**

Two folding clothes hooks are provided in the rear of the vehicle. To unfold them, press on the top edge of the clothes hooks.

A

Do not obstruct view

When suspending clothing from the hooks, ensure that it will not obstruct the driver's vision. ◄

A

No heavy objects

Do not hang heavy objects from the hooks; otherwise, they may present a danger to passengers during braking and evasive maneuvers.

## Automatic transmission: center console



To open: press on the cover.

# Storage compartments in the cargo area

### Net

Small objects can be stowed in the net on the rear cargo area trim.

### Lashing eyes

To secure the cargo, refer to page 172, there are lashing eyes in the cargo area.

### **Cupholders**

### **Notes**



Shatter-proof containers and no hot drinks

**FarmaS** 

Use light and shatter-proof containers and do not transport hot drinks. Otherwise, there is the increased danger of injury in an accident. ◄

Unsuitable containers

Do not forcefully push unsuitable containers into the cupholders. This may result in damage. ◄

## Storage compartment under the cargo floor cover



Raise the cargo floor cover using the strap.



تلفن شبانه روزى: ۱-۸۸۸۶۲ ۲۸ الفن شبانه روزى: ۱-۸۸۸۶۲ م



امداد حودرو فارما

ن شبانه روزي: ۱۵۸۰۲۰۸۵ - ۲۱

## **Driving tips**

This chapter provides you with information useful in dealing with specific driving and operating modes.

تلفن شبانه روزی: ۱-۸۸۸۶۲۰۸۵ ۲۱-۲۰

امداد حودره

Farma506.com

## Things to remember when driving

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **Breaking-in period**

#### General information

Moving parts need to be broken in to adjust to each other.

The following instructions will help achieve a long vehicle life and good economy.

### **Engine and differential**

Always obey the official speed limit.

### Up to 1,200 miles/2,000 km

Do not exceed the maximum engine and road speed:

 For gasoline engine 4,500 rpm and 100 mph/160 km/h.

Avoid full load or kickdown under all circumstances.

### From 1,200 miles/2,000 km

The engine and vehicle speed can gradually be increased.

#### **Tires**

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until after an initial breakingin period.

Drive conservatively for the first 200 miles/300 km.

### **Brake system**

Brakes require an initial break-in period of approx. 300 miles/500 km to achieve optimized contact and wear patterns between brake discs and brake pads. Drive moderately during this break-in period.

### Following part replacement

The same breaking in procedures should be observed if any of the components mentioned above have to be renewed in the course of the vehicle's operating life.

### **General driving notes**

### Closing the trunk lid

Drive with the trunk lid closed
Only drive with the tailgate closed; otherwise, in the event of an accident or braking and evasive maneuvers, passengers and other road users may be injured, and the vehicle may be damaged. In addition, exhaust fumes may enter the passenger compartment.

If driving with the tailgate open cannot be avoided:

- Close all windows and the glass sunroof.
- Greatly increase the blower speed.
- Drive moderately.

### Hot exhaust system

Hot exhaust system
High temperatures are generated in the exhaust system.

Do not remove the heat shields installed and never apply undercoating to them. Make sure that flammable materials, e. g. hay, leaves, grass, etc. do not come in contact with the hot exhaust system during driving, while in idle position mode, or when parked. Such contact could lead to a fire, and with it the risk of serious personal injury as well as property damage.

Do not touch hot exhaust pipes; otherwise, there is the danger of getting burned.◀

#### Climate control windshield



The marked area is not covered with heat reflective coating.

Use this area for garage door openers, devices for electronic toll collection, etc.

## Climate control laminated tinted safety glass

The vehicle glass provides full protection against the harmful effects of UV radiation on the skin.

## Mobile communication devices in the vehicle



Mobile communication devices in the vehicle

It is advised that you do not use mobile communication devices, e.g., mobile phones, inside the vehicle without connecting them directly to the external antenna. Otherwise, the vehicle electronics and mobile communication devices can interfere with each other. In addition, there is no assurance that the radiation generated during transmission will be discharged from the vehicle interior.◀

### **Hydroplaning**

On wet or slushy roads, a wedge of water can form between the tires and road surface.

This phenomenon is referred to as hydroplaning. It is characterized by a partial or complete loss of contact between the tires and the road surface, ultimately undermining your ability to steer and brake the vehicle.

 $\Lambda$ 

Hydroplaning

When driving on wet or slushy roads, reduce your speed to prevent hydroplaning.

### **Driving through water**

Drive though calm water only and only if it is not deeper than. 9.8 inches/25 cm and at this height, no faster than walking speed, up to 6 mph/10 km/h.



Adhere to water depth and speed limitations

Do not exceed this water depth and walking speed; otherwise, the vehicle's engine, the electrical systems and the transmission may be damaged.

### **Braking safely**

Your vehicle is equipped with ABS as a standard feature.

Applying the brakes fully is the most effective way of braking in situations when this is necessary.

The vehicle maintains steering responsiveness. You can still avoid any obstacles with a minimum of steering effort.

Pulsation of the brake pedal and sounds from the hydraulic circuits indicate that ABS is in its active mode.

### Objects in the area around the pedals

No objects in the area around the pedals Keep floor mats, carpets, and any other objects out of the area of motion of the pedals; otherwise, the function of the pedals could be impeded while driving

Do not place additional floor mats over existing mats or other objects.

Only use floor mats that have been approved for the vehicle and can be properly fixed in place.

Ensure that the floor mats are securely fastened again after they were removed for cleaning, for example. ◀

### **Driving in wet conditions**

When roads are wet coated with road salt or there is heavy rain, briefly exert gentle pressure on the brake pedal every few miles.

Ensure that this action does not endanger other road users.

The heat generated in this process helps dry the brake discs and pads.

In this way braking efficiency will be available when you need it.

#### Hills

Drive long or steep downhill gradients in the gear in which the least braking is required.

Otherwise, the brake system may overheat, resulting in a reduction in the brake system efficiency.

You can increase the engine's braking effect by shifting down, going all the way to first gear, if necessary.

Avoid load on the brakes
Avoid placing excessive load on the
brake system. Light but consistent brake pressure can lead to high temperatures, brake wear
and possibly even brake failure.

Do not drive in neutral

Do not drive in neutral or with the engine stopped, as doing so disables engine braking. In addition, steering and brake assist is unavailable with the engine stopped. ◄

#### **Brake disc corrosion**

The corrosion on the brake discs and the contamination on the brake pads are furthered by:

- Low mileage.
- Extended periods when the vehicle is not used at all.
- Infrequent use of the brakes.

Corrosion occurs when the minimum pressure that must be exerted by the pads during brake applications to clean the discs is not reached.

Should corrosion form on the brake discs, the brakes will tend to respond with a pulsating effect that generally cannot be corrected.

## Condensation under the parked vehicle

When using the automatic climate control, condensation water develops that exits underneath the vehicle.

Traces of water under the vehicle like this are normal.

## Loading

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **Hints**

Overloading the vehicle

To avoid exceeding the approved carrying capacity of the tires, never overload the vehicle. Overloading can lead to overheating and increases the rate at which damage develops inside the tires. This could result in a sudden loss of tire inflation pressure.

vehicle and unstable driving situations may result.

- Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Subtract the combined weight of the driver and passengers from XXX kilograms or YYY pounds.
- The resulting figure equals the available amount of cargo and luggage load capacity.
- For example, if the YYY amount equals 1,000 lbs and there will be four 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 400 lbs: 1,000 lbs minus 600 lbs = 400 lbs.
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.

## **Determining the load limit**



- Locate the following statement on your vehicle's placard:
  - ➤ The combined weight of occupants and cargo should never exceed XXX kg or YYY lbs. Otherwise, damage to the

## Load

The maximum load is the sum of the weight of the occupants and the cargo.

The greater the weight of the occupants, the less cargo that can be transported.

### **Stowing cargo**

- Cover sharp edges and corners on the cargo.
- Heavy cargo: stow as far forward as possible, directly behind and at the bottom of the rear passenger seat backrests.
- Very heavy cargo: when the rear seat is not occupied, secure each of the outer safety belts in the opposite buckle.

Heavy or hard objects should not be carried loose inside the car; otherwise, they could be thrown around as a result of hard braking, sudden swerves, etc., and endanger the occupants.◀

### **Securing cargo**

### Lashing eyes in the cargo area



To secure the cargo there are four lashing eyes in the cargo area.

### **Securing cargo**

## FarmaSOS.com

- Smaller and lighter items: secure with retaining straps or with a cargo net or draw straps.
- Larger and heavy objects: secure with cargo straps.

Cargo straps, cargo netting, retaining straps or draw straps on the lashing eyes in the cargo area.

Securing cargo
Always position and secure the cargo as described above; otherwise, it can endanger the car's occupants if sudden braking or swerving becomes necessary.

## **Saving fuel**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **General information**

Your vehicle contains advanced technology for the reduction of fuel consumption and emissions.

Fuel consumption depends on a number of different factors.

The implementation of certain measures, driving style and regular maintenance can have an influence on fuel consumption and on the environmental impact.

### Remove unnecessary cargo

Additional weight increases fuel consumption.

# Remove attached parts following use

Attached parts on the vehicle impair the aerodynamics and increase the fuel consumption.

## Close the windows and glass sunroof

Driving with the glass sunroof and windows open results in increased air resistance and raises fuel consumption.

### **Tires**

### **General information**

Tires can affect fuel consumption values in various ways, for instance fuel consumption can be influenced by the size of the tires.

## Check the tire inflation pressure regularly

Check and, if necessary, correct the tire inflation pressure at least twice a month and before starting on a long trip.

Low tire inflation pressure increases rolling resistance and thus raises fuel consumption and tire wear.

### **Drive away without delay**

Do not wait for the engine to warm-up while the vehicle remains stationary. Start driving right away, but at moderate engine speeds.

This is the fastest way for the cold engine to reach its operating temperature.

## Look well ahead when driving

Avoid unnecessary acceleration and braking.

By maintaining a suitable distance to the vehicle driving ahead of you.

Driving smoothly and looking ahead reduces fuel consumption.

### **Use coasting conditions**

When approaching a red light, take your foot off the accelerator and let the vehicle coast to a halt.

On a downhill gradient, take your foot off the accelerator and let the vehicle roll.

The flow of fuel is interrupted while coasting.

### Switch off the engine during longer stops

Switch off the engine during longer stops, e.g., at traffic lights, railroad crossings or in traffic congestion.

### **Automatic Engine Start/Stop Function**

The Auto Start/Stop function of your vehicle automatically switches off the engine during a stop.

If the engine is switched off and then restarted rather than leaving the engine running constantly, fuel consumption and emissions are reduced. Savings can begin within a few seconds of switching off the engine.

Using this system can cause certain components of the vehicle to become worn prematurely.

In addition, fuel consumption is also determined by other factors, such as driving style, road conditions, maintenance or environmental factors.

### Switch off any functions that are not currently needed

Functions such as seat heating and the rear window defroster require a lot of energy and consume additional fuel, especially in city and stop-and-go traffic.

Therefore, switch off these functions if they are not actually needed.

### Have maintenance carried out

Have vehicles maintained regularly to achieve optimal vehicle economy and operating life. Have the maintenance carried out by your service center.

Please also note the BMW Maintenance System, refer to page 202.

### **ECO PRO**

### The concept

ECO PRO supports a driving style that saves on fuel consumption. For this purpose, the engine control and comfort functions, e. g. the climate control output, are adjusted.

In addition, context-sensitive instructions can be displayed that assist in driving in a manner that optimizes fuel consumption.

The extension of the range that is achieved as a result can be displayed in the instrument فن شبانه روزیcluster

### At a glance

The system includes the following EfficientDynamics functions and displays:

- ECO PRO bonus range, refer to page 175.
- ECO PRO tips driving instruction, refer to page 176
- ▶ ECO PRO climate control, refer to page 175.

### Activating ECO PRO

Press button repeatedly until ECO PRO is displayed in the instrument cluster.

### **Configuring ECO PRO**

### **Via the Driving Dynamics Control**

Activate ECO PRO.

- 2. "Configure ECO PRO"
- 3. Configure the program.

#### Via the iDrive

- 1. "Settings"
- 2. "ECO PRO mode"

Or

- 1. "Settings"
- 2. "Driving mode"
- 3. "Configure ECO PRO"

Configure the program.

### **ECO PRO Tip**

▶ "Tip at:":

Set ECO Pro speed at which an ECO PRO Tip is to be displayed.

"ECO PRO speed warning":
 A reminder is displayed if the set ECO PRO speed is exceeded.

### ECO PRO climate control \ \_ 人人人 >

"ECO PRO climate control"

The climate control is adjusted to be fuel-efficient.

By making a slight change to the set temperature, or slowly adjusting the rate of heating or cooling of the passenger compartment, fuel consumption can be economized.

The outputs of the seat heater and the exterior mirror heating are also reduced.

The exterior mirror heating is made available when outside temperatures are very cold.

### **ECO PRO potential**

The percentage of potential savings that can be achieved with the current configuration is displayed.

### Display in the instrument cluster

### Display in the instrument display

When ECO PRO mode is activated, the display switches to a special configuration.

Some of the displays may differ from the display in the instrument cluster.

### **ECO PRO bonus range**



An extension of the range can be achieved by an adjusted driving style.


This may be displayed as the bonus range in the instrument

cluster.

The bonus range is shown in the range display.

The bonus range is automatically reset every time the vehicle is refueled.

### **Driving style**



In the tachometer, a mark in the bar display indicates the current efficiency of the driving style.

Mark in the CHARGE area, arrow 1: display for energy recovered by coasting or when braking.

Mark in the POWER area, arrow 2: display when accelerating.

The efficiency of the driving style is shown by the color of the bar:

- Blue display: efficient driving style as long as the mark moves within the blue range.
- ▶ Gray display: adjust driving style, e. g. by backing off the accelerator pedal.

The display switches to blue as soon as all conditions for fuel-economy-optimized driving are met.

### **ECO PRO Tip - driving instruction**



The arrow indicates that the driving style can be adjusted to be more fuel efficient by backing off the accelerator for instance.

#### Note

The driving style display and ECO PRO tips in the instrument cluster appear when the ECO PRO display is activated.

Activating driving style and ECO PRO tips:

- "Settings"
- 2. "Info display"
- "ECO PRO Info"

In the instrument display:

- "Settings"
- "Info display"
- 3. "Driving mode view"

## **ECO PRO tip - Symbols**

An additional symbol and a text instruction are displayed.

### Symbol Measure



For efficient driving style, back off the accelerator or delay accelerating to allow time to assess road conditions.



Reduce speed to the selected ECO PRO speed.



Automatic transmission: switch from M/S to D and avoid manual shift interventions.

### **Indications on the Control Display**

### **EfficientDynamics**

Information on fuel consumption and technology can be displayed during driving.

- "Vehicle Info"
- 2. "EfficientDynamics"

### Displaying fuel consumption history

The average fuel consumption can be displayed within an adjustable time frame.

Vertical bars show consumption for the selected time frame.

Trip interruptions are represented below the bar on the time axis.

IIII "Consumption history"

### djusting fuel consumption history time frame

Select the symbol.

### Resetting fuel consumption history

- 1. Open "Options".
- "Reset consumption history"

### Displaying Efficient Dynamics info

The current efficiency can be displayed.

"EfficientDynamics info"

The following systems are displayed:

- Automatic engine start-stop function.
- Energy recovery.
- Climate control output.
- Coasting.

### **Display ECO PRO tips**

i "ECO PRO Tips"

The setting is stored for the profile currently in use.

### Coasting

### The concept

The system helps to conserve fuel.

To do this, under certain conditions the engine is automatically decoupled from the transmission when transmission position D is engaged. The vehicle continues traveling with the engine idling to reduce fuel consumption. Transmission position D remains engaged.

This driving condition is referred to as coasting.

As soon as the brake or accelerator pedal is depressed, the engine is automatically coupled to the transmission again.

#### Hints

Coasting is a component of the ECO PRO, refer to page 174, driving mode.

The function is available in a certain speed range.

A forward-looking driving style helps the driver to use the function as often as possible and supports the fuel-conserving effect of coasting.

### Safety mode

The function is not available if one of the following conditions is satisfied.

- DSC OFF or TRACTION activated.
- Driving in the dynamic limit range and on steep uphill or downhill grades.
- Battery charge status temporarily too low or vehicle electrical system drawing excessive current.
- Cruise control activated.

### **Functional requirements**

In ECO PRO mode, this function is available in a speed range from approximately 30 mph, approx. 50 km/h to 100 mph, approx. 160 km/h, if the following conditions are satisfied:

- Accelerator pedal and brake pedal are not operated.
- The selector lever is in transmission position D.
- Engine and transmission are at operating temperature.

### **Display**

### Display in the instrument cluster



The mark in the bar display below the tachometer is backlit in blue and is located at the zero point. The tachometer approximately indicates idle speed.

The coasting point indicator is illuminated at the zero point during coasting.

### Indications on the Control Display

The Coasting driving condition is displayed in EfficientDynamics Info while this driving mode is active.



Color code blue, arrow 1, and symbol, arrow 2: driving condition Coasting.

### **Displaying Efficient Dynamics info**

- "Vehicle Info"
- "EfficientDynamics"
- 3. 🎞 "EfficientDynamics info"

### **Deactivating the system manually**

The function can be deactivated in the Configure ECO PRO, refer to page 174, menu, e.g., to

use the braking effect of the engine when traveling downhill.

The setting is stored for the profile currently in use.



تلفن شبانه روزى: ۱-۸۸۸۶۲ ۲۸ الفن شبانه روزى: ۱-۸۸۸۶۲ م



تلفن شبانه روزی: ۱۳۵۸/۶۲ ۲۸ ۲۱ ۲۸ تلفن شبانه



ادراد ودروفارما

تلفن شبانه روزی: ۵۸ + ۲۹۸۸۸ - ۲ +

# **Mobility**

In order to always ensure your mobility, you will find important information on operating fluids, wheels and tires, maintenance and Roadside Assistance in the following.

تلفن شبانه روزی: ۱۹۸۸۶۲۰۸۵ ۲

Farma SOS com

## Refueling

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### **General information**

Refuel promptly
Refuel no later than at a range of
30 miles/50 km, or operation of the engine is
not ensured and damage may occur.


## Fuel cap

#### **Opening**

 Briefly press the rear edge of the fuel filler flap.



2. Turn the fuel cap counterclockwise.



3. Place the fuel cap in the bracket attached to the fuel filler flap.



#### Closing

- Fit the cap and turn it clockwise until you clearly hear a click.
- 2. Close the fuel filler flap.

Do not pinch the retaining strap
Do not pinch the retaining strap attached
to the cap; otherwise, the cap cannot be
closed properly and fuel vapors can escape.

A message is displayed if the cap is loose or missing. ◀


#### Manually unlocking fuel filler flap

In the event of an electrical malfunction, for example.

1. Open the cover on the right side trim.



2. Pull the green knob with the fuel pump symbol. This releases the fuel filler flap.



# The contraction of the following when specified the following when refueling

The fuel tank is full when the filler nozzle clicks off the first time.

Do not overfill the fuel tank
Do not overfill the fuel tank; otherwise
fuel may escape, causing harm to the environment and damaging the vehicle.

✓

Handling fuels
Obey safety regulations posted at the gas station. ◀

## **Fuel**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### **Fuel recommendation**

#### Gasoline

For the best fuel economy, the gasoline should be sulfur-free or very low in sulfur content.

Fuels that are marked on the gas pump as containing metal must not be used.



Refuel only with unleaded gasoline without metallic additives.

Do not refuel with any leaded gasoline or gasoline with metallic additives, e. g. manganese or iron, or permanent damage to the catalytic converter and other components.

Fuels with a maximum ethanol content of 10 %, i. e., E10, may be used for refueling. Ethanol should satisfy the following quality standards:

US: ASTM 4806-xx CAN: CGSB-3.511-xx

xx: comply with the current standard in each case.

Do not refuel with ethanol E85 Do not refuel with E85, i.e., fuel with an ethanol content of 85 %, or with Flex Fuel, as this would damage the engine and fuel supply system.∢

#### Gasoline quality

BMW recommends AKI 91.

#### Minimum fuel grade

BMW recommends AKI 89.

Minimum fuel grade Do not use any gasoline below the minimum fuel grade as this may impair engine performance. ◀

If you use gasoline with this minimum AKI Rating, the engine may produce knocking sounds when starting at high outside temperatures. This has no effect on the engine life.

Fuel quality

The use of poor-quality fuels may result in harmful engine deposits or damage. Additionally, problems relating to drivability, starting and stalling, especially under certain environmental conditions such as high ambient temperature and high altitude, may occur.

If drivability problems are encountered, we recommend switching to a high quality gasoline brand and a higher octane grade — AKI number — for a few tank fills. To avoid harmful engine deposits, it is highly recommended to purchase gasoline from BP or Top Tier retail-

Failure to comply with these recommendations may result in the need for unscheduled maintenance. ◀

BMW recommends BP fuels \*\*



## Wheels and tires

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## Tire inflation pressure

#### **Safety information**

The tire characteristics and tire inflation pressure influence the following:

- The service life of the tires.
- Road safety.
- Driving comfort.

## Checking the pressure

Only check the tire inflation pressure when the tires are cold. This means after driving no more than 1.25 miles/2 km or when the vehicle has been parked for at least 2 hours. When the tires are warm, the tire inflation pressure is higher.

Check the tire inflation pressure regularly Regularly check the tire inflation pressure, and correct it as needed: at least twice a month and before a long trip. If you fail to observe this precaution, you may be driving on tires with incorrect tire pressures, a condition that may not only compromise your vehicle's driving stability, but also lead to tire damage and the risk of an accident.

After correcting the tire inflation pressure:

- Reinitialize the Flat Tire Monitor.
- Reinitialize the Tire Pressure Monitor.

#### **Pressure specifications**

The tire inflation pressure table, refer to page 186, contains all pressure specifications for the specified tire sizes at the ambient temperature. Pressure specifications apply to approved tire sizes and recommended tire brands. This information can be obtained from your service center.

To identify the correct tire inflation pressure, please note the following:

- ▶ Tire sizes of your vehicle.
- Maximum permitted driving speed.

# Tire inflation pressures up to 100 mph/160 km/h

For speeds of up to 100 mph/160 km/h and for optimum driving comfort, note the pressure values in the tire inflation pressure table, refer to page 186, and adjust as necessary.



These pressure values can also be found on the tire inflation pressure label on the driver's door pillar.

Maximum permissible speed

Do not exceed 100 mph/160 km/h; otherwise, tire damage and accidents may result.◀

# Tire inflation pressure values up to 100 mph/160 km/h

#### 640i

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires	* * * * / D	
245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M +S XL A/S RSC 245/45 R 18 100 V M+S XL RSC	2.2/32 2.4/35	
Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.2/32 - 2.2/32 - Y\-\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	
Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19 96 Y RSC	2.2/32 - - FarmaS	
Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.6/38 - 2.6/38	
Compact wheel: T 135/90 R 17 104 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60	

#### 640i xDrive

	Tire size	Pressure specifications in bar/PSI	
	Specifications in bar/PSI with cold tires	* * * *	
	245/45 R 18 100 V M+S XL A/S RSC 245/45 R 18 100 V M+S XL RSC	2.2 / 32	2.4/35
	245/40 R 19 98 V M +S XL A/S RSC	2.4/35	2.4 / 35
	Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.2/32	- 2.4 / 35
*	Front: 245/40 R 19 94 Y RSC تلفن شبائه Rear: 275/35 R 19 96 Y RSC	2.4/ 35	- 2.4 / 35
	Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.6 / 38	- 2.6 / 38
	Compact wheel: T 135/90 R 17 104 M	Speed up to 50 mph / 80 4.2 / 60	

#### 650i

Tire size	Pressure specifica- tions in bar/PSI
Specifications in bar/PSI with cold tires	* * * * / ©
245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M +S XL A/S RSC 245/45 R 18 100 V M+S XL RSC	2.2/32 2.4/35
Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.2/32 - 2.2/32
Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19 96 Y RSC	2.2/32 - - + \( \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.6/38

#### 650i xDrive

	Tire size	Pressure sp tions in bar/	
	Specifications in bar/PSI with cold tires	††††	
	245/45 R 18 100 V M+S XL A/S RSC 245/45 R 18 100 V M+S XL RSC	2.2 / 32	2.4/35
	245/40 R 19 98 V M +S XL A/S RSC	2.4/35	2.4/35
	Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.2/32	- 2.4/35
2	Front: 245/40 R 19 94 Y RSC تلفن ش Rear: 275/35 R 19 96 Y RSC	2.4/ 35	- 2.4 / 35
	Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.6 / 38	- 2.6 / 38

# Tire inflation pressures at max. speeds above 100 mph/160 km/h

Speeds above 100 mph/160 km/h In order to drive at maximum speeds in excess of 100 mph/160 km/h, please observe, and, if necessary, adjust tire pressures for speeds exceeding 100 mph/160 km/h from the relevant table on the following pages. Otherwise tire damage and accidents could occur. ◄

Tire size

#### Tire inflation pressure values over 100 mph/160 km/h

#### 640i

Without high-speed tuning feature				
Tire size	Pressure specifica- tions in bar/PSI			
Specifications in bar/PSI with cold tires	<b>*</b> * <b>*</b> * <b>*</b>			
245/45 R 18 100 V M+S XL A/S RSC 245/45 R 18 100 V M+S XL RSC	2.2/32	2.6 / 38		
245/40 R 19 98 V M +S XL A/S RSC	2.4/35	2.8 / 41		
Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.2/32	- 2.2/32 '\-\\\\		
Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19 96 Y RSC	2.2/32	- 2.4/35		
Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.6 / 38	- 2.6 / 38		
Compact wheel: T 135/90 R 17 104 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60			

	1116 3126	in bar/PSI	Cincation
	Specifications in bar/PSI with cold tires	***	
	245/45 R 18 100 V M+S XL RSC	2.6 / 38	2.9 /42
	Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.3 / 33	- 2.4/35
	Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19 96 Y RSC	2.4/35	- 2.6/38
	Front: 245/35 R 20 95 Y XL RSC Rear: تلفن شبانه روزی 275/30 R 20 97 Y XL RSC	2.7/39	- 2.9/42
	Compact wheel: T 135/90 R 17 104 M	Speed up to 50 mph / 80 4.2 / 60	
	640i xDrive	ıning feature	

Pressure specifications

Without high-speed tuning feature

With high-speed tuning feature

Tire size	Pressure sp			Tire size	Pressure sp in bar/PSI	ecifications
Specifications in bar/PSI with cold tires	<b>†††</b> †			Specifications in bar/PSI with cold tires	<b>†††</b> †	
245/45 R 18 100 V M+S XL A/S RSC 245/45 R 18 100 V M+S XL RSC	2.4/35	2.6 / 38		245/45 R 18 100 V M+S XL A/S RSC 245/45 R 18 100 V M+S XL RSC	2.6 / 38	3.0 / 44
245/40 R 19 98 V M +S XL A/S RSC	2.6 / 38	2.8 / 41		245/40 R 19 98 V M +S XL RSC	2.9 /42	3.1 / 45
Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.2/32	- 2.4/35		Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.4/35	- 2.6 / 38
Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19 96 Y RSC	2.4/35 - + ) \	- 2.4/35 \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Λâ	Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19 96 Y RSC	2.6 / 38	- 2.6 / 38
Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.6/38 - Far	2.6/38	0	Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.8 / 41	- 2.8 / 41
Compact wheel: T 135/90 R 17 104 M	Speed up to 50 mph / 80 4.2 / 60			Compact wheel: T 135/90 R 17 104 M	Speed up to 50 mph / 80 4.2 / 60	

With high-speed tuning feature

#### 650i

Without high-speed tuning feature

Tire size	Pressure specifica- tions in bar/PSI		
Specifications in bar/PSI with cold	<b>*</b> * *	†/0	
tires			
245/45 R 18 100 V M+S XL A/S RSC 245/45 R 18 100 V	2.2 / 32	2.6 / 38	
M+S XL RSC			
245/40 R 19 98 V M +S XL A/S RSC	2.4 / 35	2.8 / 41	
Front: 245/45 R 18 96 Y RSC	2.2/32	- 2.2/32	
Rear: 275/40 R 18 99 Y RSC		10 9	
Front: 245/40 R 19 94 Y RSC	2.2 / 32	-	
Rear: 275/35 R 19 96 Y RSC	+ 7	2.4/35 '\_\\\\\$\	
Front: 245/35 R 20 95 Y XL RSC	2.6 / 38	a <sub>2.6/38</sub> a	
Rear: 275/30 R 20 97 Y XL RSC			

Tire size	Pressure sp tions in bar/	
Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.3/33	- 2.4/35
Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19 96 Y RSC	2.5 / 36	- 2.6 / 38
Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.7/39	- 2.9 /42
650i yDriyo		

#### 650i xDrive

Front: 245/45 R 18

275/40 R 18 99 Y

96 Y RSC

Rear:

**RSC** 

Without high-speed tuning feature			
Tire sizeو تلفن شبانه رو	Pressure specifications in bar/PSI		
Specifications in bar/PSI with cold tires	* * * * *		
245/45 R 18 100 V M+S XL A/S RSC	2.4 / 35	2.6 / 38	
245/45 R 18 100 V M+S XL RSC			
245/40 R 19 98 V M +S XL A/S RSC	2.6 / 38	2.8 / 41	

2.2/32

2.4/35

#### With high-speed tuning feature

• .	•
Tire size	Pressure specifica- tions in bar/PSI
Specifications in bar/PSI with cold tires	* * * * / D
245/45 R 18 100 V M+S XL RSC	2.6 / 38 2.9 /42

Tire size	Pressure specifications in bar/PSI	
Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19 96 Y RSC	2.4/35	- 2.4/35
Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.6 / 38	- 2.6 / 38

Tire size	Pressure specifica- tions in bar/PSI	
Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19 96 Y RSC	2.6 / 38	- 2.6 / 38
Front: 245/35 R 20 95 Y XL RSC Rear: 275/30 R 20 97 Y XL RSC	2.8 / 41	- 2.8 / 41

#### With high-speed tuning feature

with high-speed turning reature		
Tire size	Pressure specifica- tions in bar/PSI	
Specifications in bar/PSI with cold tires	****	
245/45 R 18 100 V M+S XL A/S RSC 245/45 R 18 100 V M+S XL RSC	2.6138 - 3.0144 FarmaS	
245/40 R 19 98 V M +S XL A/S RSC	2.9 /42 3.1 / 45	
Front: 245/45 R 18 96 Y RSC Rear: 275/40 R 18 99 Y RSC	2.4/35 - 2.6/38	

## **Tire identification marks**

#### Tire size

245/45 R 18 96 Y

245: nominal width in mm

45: aspect ratio in %

R: radial tire code

18: rim diameter in inches

96: load rating, not for ZR tires

Y: speed rating, before the R on ZR tires

#### **Speed letter**

T = up to 118 mph, 190 km/h H = up to 131 mph, 210 km/h V = up to 150 mph, 240 km/h W = up to 167 mph, 270 km/h Y = up to 186 mph, 300 km/h

#### **Tire Identification Number**

DOT code: DOT xxxx xxx 1013

xxxx: manufacturer code for the tire brand

xxx: tire size and tire design

1013: tire age

Tires with DOT codes meet the guidelines of the U.S. Department of Transportation.

#### Tire age

DOT ... 1013: the tire was manufactured in the 10th week 2013.

#### Recommendation

Regardless of wear, replace tires at least every 6 years.

#### **Uniform Tire Quality Grading**

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200; Traction AA; Temperature A

#### **DOT Quality Grades**

Treadwear

Traction AA A B C

Temperature A B C

All passenger car tires must conform to Federal Safety Requirements in addition to these grades.

#### **Treadwear**

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half, 1 g, times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

#### **Traction**

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

#### **Temperature**

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades Band A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Temperature grade for this tire

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

If necessary, have the vehicle towed. ◀

#### **RSC - Run-flat tires**

Run-flat tires, refer to page 195, are labeled with a circular symbol containing the letters RSC marked on the sidewall.

#### M+S

Winter and all-season tires with better cold weather performance than summer tires.

#### Tire tread

#### **Summer tires**

Do not drive with a tire tread depth of less than 0.12 in/3 mm.


There is an increased danger of hydroplaning if the tread depth is less than 0.12 in/3 mm.

#### Winter tires

Do not drive with a tire tread depth of less than 0.16 in/4 mm.

Below a tread depth of 0.16 in/4 mm, tires are less suitable for winter operation.

#### Minimum tread depth



Wear indicators are distributed around the tire's circumference and have the legally required minimum height of 0.063 in/1.6 mm.

They are marked on the side of the tire with TWI, Tread Wear Indicator.

## **Tire damage**

#### General information

Inspect your tires often for damage, foreign objects lodged in the tread, and tread wear.

#### Notes

Driving over rough or damaged road surfaces, as well as debris, curbs and other obstacles can cause serious damage to wheels, tires and suspension parts. This is more likely to occur with low-profile tires, which provide less cush-

ioning between the wheel and the road. Be careful to avoid road hazards and reduce your speed, especially if your vehicle is equipped with low-profile tires.

Indications of tire damage or other vehicle defects:

- Unusual vibrations during driving.
- Unusual handling such as a strong tendency to pull to the left or right.

Damage can, e. g., be caused by driving over curbs, road damage, or similar things.

In case of tire damage

If there are indications of tire damage, reduce your speed immediately and have the wheels and tires checked right away; otherwise, there is the increased risk of an accident.

Drive carefully to the nearest service center. If necessary, have the vehicle towed.

Otherwise, tire damage can be life-threatening for vehicle occupants and other traffic participants. ◀

Repair of tire damage

For safety reasons, the manufacturer of your vehicle recommends that you do not have damaged tires repaired; they should be replaced. Otherwise, damage can occur as a result.

## **Changing wheels and tires**

#### Mounting

Information on mounting tires
Have mounting and balancing performed only by a service center.

If this work is not carried out properly, there is the danger of subsequent damage and related safety hazards. ◀

#### Wheel and tire combination

Information on the correct wheel-tire combination and rim versions for your vehicle can be obtained from your service center.

Incorrect wheel and tire combinations impair the function of a variety of systems such as ABS or DSC.

To maintain good handling and vehicle response, use only tires with a single tread configuration from a single manufacturer.

Following tire damage, have the original wheel and tire combination remounted on the vehicle as soon as possible.

Approved wheels and tires
The manufacturer of your vehicle recommends that you use only wheels and tires that have been approved for your particular vehicle model.

For example, despite having the same official size ratings, variations can lead to body contact and with it, the risk of severe accidents.

The manufacturer of your vehicle cannot evaluate non-approved wheels and tires to determine if they are suited for use, and therefore cannot ensure the operating safety of the vehicle if they are mounted. ◀

#### Recommended tire brands



For each tire size, the manufacturer of your vehicle recommends certain tire brands. These can be identified by a star on the tire sidewall.

With proper use, these tires meet the highest standards for safety and handling.

#### **New tires**

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until after an initial breakingin period.

Drive conservatively for the first 200 miles/300 km.

#### Retreaded tires

The manufacturer of your vehicle does not recommend the use of retreaded tires.

Retreaded tires

Possibly substantial variations in the design and age of the tire casing structures can limit service life and have a negative impact on road safety.

#### Winter tires

The manufacturer of your vehicle recommends winter tires for winter roads or at temperatures below +45 °F/+7 °C.

Although so-called all-season M+S tires do provide better winter traction than summer tires, they do not provide the same level of performance as winter tires.

#### Maximum speed of winter tires

If the maximum speed of the vehicle is higher than the permissible speed for the winter tires, then display a corresponding sign in the field of vision. You can obtain this sign from the tire specialist or from your service center.

Maximum speed for winter tires

Do not exceed the maximum speed for
the winter tires; otherwise, tire damage and accidents can occur.

✓

#### **Run-flat tires**

If you are already using run-flat tires, for your own safety you should replace them only with the same kind. No spare tire is available in the case of a flat tire. Your service center will be glad to advise you.

#### Rotating wheels between axles

The manufacturer of your vehicle advises against switching wheels between the front and rear axles.

This can impair the handling characteristics.

#### **Storage**


Store wheels and tires in a cool, dry place with as little exposure to light as possible.

Always protect tires against all contact with oil, grease and fuels.

Do not exceed the maximum tire inflation pressure indicated on the side wall of the tire.

#### **Run-flat tires**

#### Label



RSC label on the tire sidewall.

The wheels are composed of special rims and tires that are self-supporting, to a limited degree.

The support of the sidewall allows the tire to remain drivable to a restricted degree in the event of a pressure loss.

Continued driving with a damaged tire, refer to page 99.

Continued driving with a damaged tire, refer to page 96.

#### **Changing run-flat tires**

For your own safety, only use run-flat tires. No spare tire is available in the case of a flat tire. Your service center will be glad to advise you.

#### **Snow chains**

#### Fine-link snow chains

Only certain types of fine-link snow chains have been tested by the manufacturer of your vehicle, classified as road-safe and recommended.

Consult your service center for more information.

#### Use

Use only in pairs on the rear wheels, equipped with the tires of the following size:

- ▶ 225/55 R 17.
- > 245/45 R 18.
- ▶ 245/40 R 19.

Follow the chain manufacturer's instructions.

Make sure that the snow chains are always sufficiently tight. Retighten as needed according to the chain manufacturer's instructions.

Do not initialize the Flat Tire Monitor after mounting snow chains, as doing so may result in incorrect readings.

Do not initialize the Tire Pressure Monitor after mounting snow chains, as doing so may result in incorrect readings.

When driving with snow chains, briefly activate Dynamic Traction Control if necessary.

#### **Maximum speed with snow chains**

Do not exceed a speed of 30 mph/50 km/h when using snow chains.

#### **Snow chain detection**

#### The concept

When using snow chains, settings should be made via the iDrive for the snow chains being applied.

The snow chain detection system supports you by automatically showing the detected state on the Control Display.

When snow chains are in use, the rear axle steering of the Integral Active Steering is deactivated automatically.

At speeds above the maximum permitted speed with snow chains of 30 mph/50 km/h, the rear axle steering is activated again automatically.

# Activating/deactivating rear axle steering

If the status indicating that snow chains are in use is activated, the rear axle steering is deactivated automatically.

At speeds above 30 mph/50 km/h, the rear axle steering is activated again, even though snow chains are in use.

#### **Activating the status**

- 1. "Settings"
- 2. "Tire chains"
- 3. "Tire chains installed"



تلفن شيانه روزي: ۱۵۸۰ ۲۹۸۸۸ - ۲۱

#### **Automatic detection**

If functioning properly:

Snow chains are mounted. The setting is not activated ■.

After you drive a short distance, a Check Control message is shown and the state is activated automatically.

Confirm the automatic activation.

At speeds above 30 mph/50 km/h, a Check Control message is displayed. Deactivate the status manually.

#### If not functioning properly:

Snow chains are mounted. The setting is not activated ■ .

A Check Control message is not displayed.

The automatic detection system is malfunctioning. Activate the status manually.

## **Engine compartment**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## Important features in the engine compartment



- Vehicle identification number
- 2 Jump-starting, negative terminal
- 3 Washer fluid reservoir
- Sump-starting, negative term

#### Hood

#### **Opening the hood**

Working in the engine compartment
Never attempt to perform any service or
repair operations on your vehicle without the
necessary professional technical training.

- 4 Jump-starting, positive terminal
- 5 Oil filler neck.
- 6 Coolant reservoir, except 650i.

If you are unfamiliar with the statutory guidelines, have any work on the vehicle performed only by a service center.

If this work is not carried out properly, there is the danger of subsequent damage and related safety hazards. ◀



Never reach into the engine compartment

Never reach into the intermediate spaces or gaps in the engine compartment. Otherwise, there is risk of injury, e.g., from rotating or hot parts.◀

1. Pull the lever.



Press the release handle and open the hood.



#### Closing the hood



Let the hood drop from a height of approx. 16 in/40 cm and push down on it to lock it fully.

The hood must audibly engage on both sides.

Hood open when driving

If you see any signs that the hood is not completely closed while driving, pull over immediately and close it securely.

✓

Danger of pinching
Make sure that the closing path of the hood is clear; otherwise, injuries may result.

■

تلفن شبانه روزی: **۱۸**۰ ۲

SOS.com

3. Be careful of protruding parts on the hood.



Danger of injury when the hood is open There is a danger of injury from protruding parts when the hood is open. ◀

## **Engine oil**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### **General information**

The engine oil consumption is dependent on the driving style and driving conditions. When a sporty driving style is used, the engine oil consumption, for example, is clearly higher.

Therefore, regularly check the engine oil level after refueling.

# Checking the oil level

#### Status display

#### The concept

The oil level is monitored electronically during driving and shown on the Control Display.

If the oil level reaches the minimum level, a check control message is displayed.

#### Requirements

Depending on the previous displays, the status display is displayed when the engine is running or after the vehicle has been driven for at least 30 minutes.

#### Displaying the oil level

- "Vehicle Info"
- "Vehicle status"

#### 3. "Engine oil level"

#### Oil level display messages

Different messages appear on the display depending on the oil level. Pay attention to these messages.

If oil level is too low, immediately add 1 US quart/liter of oil.

Take care not to add too much engine oil.

Too much engine oil

Have the vehicle checked immediately; otherwise, surplus oil can lead to engine damage.

### **Detailed measurement**

#### The concept

In the detailed measurement the oil level is checked and displayed via a scale.

During the measurement, the idle speed is increased somewhat.

# FarmaSO General information A detailed measurement

A detailed measurement is only possible with certain engines.

#### Requirements

- Automatic transmission: selector lever in transmission position N or P and accelerator not depressed.
- Vehicle is on a level road and the engine is running at operating temperature.

#### Performing a detailed measurement

In order to perform a detailed measurement of the engine oil level:

- 1. "Vehicle Info"
- "Vehicle status"

- "Measure engine oil level"
- "Start measurement"

The oil level is checked and displayed via a scale.

Duration: approx. 1 minute.

## Adding engine oil

#### Filler neck



When the indicator lights up in the instrument cluster, add 1 US quart/liter of engine oil within the next 125 miles/200 km.

Protect children

Keep oil, grease, etc., out of reach of children and heed the warnings on the containers to prevent health risks.◀

## Oil types for refilling

#### **Hints**

No oil additives

Oil additives may lead to engine dam-

age.◀

Viscosity grades for engine oils

When selecting an engine oil, ensure that the engine oil belongs to one of the viscosity grades SAE 0W-40, SAE 0W-30, SAE 5W-40, and SAE 5W-30 or malfunctions or engine damage may occur.

The engine oil quality is critical for the life of the engine.

Some types of oils in some cases are not available in all countries.

#### Approved oil types

#### Gasoline engine

BMW High Performance SAE 5W-30.

BMW Longlife-01.

BMW Longlife-01 FE.

Additional information about the approved types of oils can be requested from the service center.

#### Alternative oil types

If the approved engine oils are not available, up to 1 US quart/liter of an oil with the following specification can be added:

#### Gasoline engine

API SM or superior grade specification.

An oil change should be carried out by your service center only.

#### BMW recommends (Castrol )



## **Coolant**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### **General information**

Danger of burns from hot engine
Do not open the cooling system while
the engine is hot; otherwise, escaping coolant
may cause burns. ◄

Suitable additives

Only use suitable additives; otherwise, engine damage may occur. The additives are harmful to your health.

Coolant consists of water and additives.

Not all commercially available additives are suitable for your vehicle. Ask your service center for suitable additives.

#### **Coolant level**

#### Checking

- 1. Let the engine cool.
- Turn the cap of the coolant reservoir slightly counterclockwise to allow any ex-

cess pressure to dissipate, and then open it.



 The coolant level is correct if it lies between the minimum and maximum marks in the filler neck.



- 4. If the coolant is low, slowly add coolant up to the specified level; do not overfill.
- 5. Turn the cap until there is an audible click. The arrows on the coolant reservoir and the cap must point towards one another.
- 6. Have the cause of the coolant loss eliminated as soon as possible.

## **Disposal**



Comply with the relevant environmental protection regulations when disposing of coolant and coolant additives.

## **Maintenance**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## **BMW Maintenance System**

The maintenance system directs you to required maintenance measures and thereby supports you in maintaining road safety and the operational reliability of the vehicle.

# **Condition Based Service CBS**

Sensors and special algorithms take into account the driving conditions of your vehicle.

Based on this, Condition Based Service determines the maintenance requirements.

The system makes it possible to adapt the amount of maintenance you need to your user profile.

Details on the service requirements, refer to page 79, can be displayed on the Control Display.

#### Service data in the remote control

Information on the required maintenance is continuously stored in the remote control. Your service center will read out this data and suggest the right array of service procedures for your vehicle.

Therefore, hand your service specialist the remote control with which the vehicle was driven most recently.

#### Storage periods

Storage periods during which the vehicle battery was disconnected are not taken into account.

If this occurs, have a service center update the time-dependent maintenance procedures, such as checking brake fluid and, if necessary, changing the engine oil and the microfilter/activated-charcoal filter.

#### Service booklet

Perform maintenance work at the service center, and record the work in the service booklet. The entries are proof of regular maintenance.


# Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models

Please consult your Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models for additional information on service requirements.

Maintenance and repair should be performed by your service center. Make sure to have regular maintenance procedures recorded in the vehicle's Service and Warranty Information Booklet for US models, and in the Warranty and Service Guide Booklet for Canadian models. These entries are proof of regular maintenance.

# Socket for OBD Onboard Diagnosis

#### **Position**



There is an OBD socket on the driver's side for checking the primary components in the vehicle emissions.

#### **Emissions**



The warning lamp lights up:





Canadian model: warning light indicates the engine symbol.

▶ The warning lamp flashes under certain circumstances:

This indicates that there is excessive misfiring in the engine.

Reduce the vehicle speed and have the system checked immediately; otherwise, serious engine misfiring within a brief period can seriously damage emission control components, in particular the catalytic converter.

#### Fuel cap



The indicator lamp lights up.

If the fuel cap is not properly tightened, the OBD system may conclude that fuel vapor is escaping. If the cap is then tightened, the display should go out in a short time.

## **Replacing components**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### Onboard vehicle tool kit



The onboard vehicle tool kit is stored under the cargo floor cover in the cargo area.

## Wiper blade replacement

#### **General information**



Do not fold down the wipers without wiper blades

Do not fold down the wipers if wiper blades have not been installed; this may damage the windshield.◀

#### Replacing the wiper blades

- 1. To change the wiper blades, fold up, refer to page 66, the wiper arms.
- 2. Fold up the wipers.



- 3. Position the wiper blade in a horizontal position.
- 4. Remove the wiper blade toward one side.



- Insert the new wiper blade in reverse order of removal until it locks in place.
- 6. Fold down the wipers.

## Lamp and bulb replacement

#### Hints

#### Lamps and bulbs

Lamps and bulbs make an essential contribution to vehicle safety.

The manufacturer of the vehicle recommends that you entrust corresponding procedures to

the service center if you are unfamiliar with them or they are not described here.

You can obtain a selection of replacement bulbs at the service center.

Danger of burns
Only change bulbs when they are cool;
otherwise, there is the danger of getting
burned.

Working on the lighting system
When working on the lighting system,
you should always switch off the lights affected to prevent short circuits.

To avoid possible injury or equipment damage when replacing bulbs, observe any instructions provided by the bulb manufacturer. ◀



Do not perform work/bulb replacement on xenon headlamps

Have any work on the xenon lighting system, including bulb replacement, performed only by a service center. Due to the high voltage present in the system, there is the danger of fatal injuries if work is carried out improperly. ◄

Do not touch the bulbs

Do not touch the glass of new bulbs with your bare hands, as even minute amounts of contamination will burn into the bulb's surface and reduce its service life.

Use a clean tissue, cloth or something similar, or hold the bulb by its base.◀

#### **Light-emitting diodes (LEDs)**

Light-emitting diodes installed behind a cover serve as the light source for controls, display elements and other equipment.

These light-emitting diodes, which are related to conventional lasers, are officially designated as Class 1 light-emitting diodes.

Do not remove the covers

Do not remove the covers, and never stare into the unfiltered light for several hours; otherwise, irritation of the retina could result. ◄

#### Headlamp glass

Condensation can form on the inside of the external lamps in cool or humid weather. When driving with the light switched on, the condensation evaporates after a short time. The head-lamp glasses do not need to be changed.

If the headlamps do not dim despite driving with the light switched on, increasing humidity forms, e. g. water droplets in the light, have the service center check this.

#### **Headlamp setting**

The headlamp adjustments can be affected by changing lamps and bulbs. Therefore after a change, have the headlamp setting checked and corrected by Service.

#### Xenon headlamps

#### **Hints**

Because of the long life of these bulbs, the likelihood of failure is very low. Switching the lamps on and off frequently shortens their life.

If a bulb fails, switch on the front fog lamps and continue the trip with great care. Comply with local regulations.



Do not perform work/bulb replacement on xenon headlamps

Have any work on the xenon lighting system, including bulb replacement, performed only by a service center. Due to the high voltage present in the system, there is the danger of fatal injuries if work is carried out improperly. ◀

For checking and adjusting headlamp aim, please contact your BMW center.

#### **Light-emitting diodes (LEDs)**

Follow the general instructions on Lamps and bulbs, refer to page 204.

With Xenon-headlamps, the following lamps are designed with LED technology:

- Parking lamps and roadside parking lamps.
- Turn signals, incl. side indicators
- Daytime running lights

Contact your service center in the event of a malfunction.


#### **Turning lamp on the Xenon headlamp**

Follow the general instructions on lamps and bulbs, refer to page 204.


The illustration shows the left side of the engine compartment.

55-watt bulb, H3

Turn the cap and remove it



2. Detach the wire bracket.



- Disconnect the cable at the plug-in connection and remove the bulb.
- 4. Insert the new bulb. Ensure that the bulb has the correct orientation. Because of its

- shape, the bulb can only be inserted in one direction.
- 5. Secure the bulb with the wire bracket.
- Connect the bulb.
- 7. Mount the cap.

#### **LED** headlamps

#### **Light-emitting diodes (LEDs)**

Follow the general instructions on Lamps and bulbs, refer to page 204.


With LED headlamps, all front lamps and side indicators are designed with LED technology.

If an LED fails, switch on the front fog lamps and continue the trip with great care. Comply with local regulations.

Contact your service center in the event of a malfunction.

#### Tail lamps, bulb replacement

#### At a glance



- 1 Turn signal/brake lamp
- 2 Reversing lamp
- 3 Inside brake lamp
- 4 Tail lamp
- 5 Outside brake lamp
- 6 Rear reflector

# Turn signal, outer brake, tail, and license plate lamps

Follow the general instructions on lamps and bulbs, refer to page 204.

These lights feature LED technology.

Contact your service center in the event of a malfunction.

#### Lamps in the trunk lid

#### Access to the lamps




If necessary, remove the fasteners using the screwdriver from the onboard vehicle tool kit and fold away the cover.

#### Inside brake lamp

Follow the general instructions on Lamps and bulbs, refer to page 204.

24-watt bulb, HP24W

1. Squeeze the bulb holder and pull it out.




- Pull off the connector.
- 3. Replace the bulb.
- Mount the bulb holder and the cover of the trunk lid in reverse order.

#### **Reversing lamp**

Follow the general instructions on Lamps and bulbs, refer to page 204.

#### 16-watt bulb, W16W

Unscrew the bulb holder counterclockwise.



- 2. Pull out the bulb and replace it.
- Mount the bulb holder and the cover of the trunk lid in reverse order.

## Changing wheels


#### Hints

The vehicle equipment does not include a spare tire.

When using run-flat tires or tire sealants, a tire does not need to be changed immediately in the event of pressure loss due to a flat tire.

The tools for changing wheels are available as accessories from your service center.

#### Jacking points for the vehicle jack



The jacking points for the vehicle jack are located at the positions shown.

## Vehicle battery

#### **Maintenance**

The battery is maintenance-free, i.e., the electrolyte will last for the life of the battery.

Your service center will be glad to advise you on questions regarding the battery.

#### **Battery replacement**

Use approved vehicle batteries only
Only use vehicle batteries that have been approved for your vehicle by the manufacturer; otherwise, the vehicle could be damaged and systems or functions may not be fully available.

After a battery replacement, have the battery registered on the vehicle by your service center to ensure that all comfort functions are fully available and that any Check Control messages of these comfort functions are no longer displayed.

#### Charging the battery

#### Note

Do not plug chargers into the socket

Do not connect battery chargers to the
factory-installed sockets in the vehicle as this
may damage the battery.

#### **General information**

Make sure that the battery is always sufficiently charged to guarantee that the battery remains usable for its full service life.

The battery may need to be charged in the following cases:

- When making frequent short-distance drives
- If the vehicle is not used for prolonged periods, longer than a month.

#### Starting aid terminals

In the vehicle, only charge the battery via the starting aid terminals, refer to page 212, in the engine compartment with the engine off.

#### **Power failure**

After a temporary power loss, some equipment needs to be reinitialized.

Individual settings need to be reprogrammed:

- Seat, mirror, and steering wheel memory: store the positions again.
- ▶ Time: update.
- Date: update.
- Radio station: saving new, see user's manual for Navigation, Entertainment and Communication.
- Navigation system: wait for the operability of the navigation.

#### Disposing of old batteries



+ 71-1115

Have old batteries disposed of by your service center or bring them to a recycling center.

Maintain the battery in an upright position for transport and storage. Secure the battery so that it does not tip over during transport.

#### **Fuses**


#### Notes

Replacing fuses

Never attempt to repair a blown fuse and do not replace a defective fuse with a substitute of another color or amperage rating; this could lead to a circuit overload, ultimately resulting in a fire in the vehicle. ◄


Plastic tweezers and information on the fuse types and locations are stored in the fuse box in the cargo area.

#### In the glove compartment



Push the handle up, arrow 1, and open the lid, arrow 2.

#### In the cargo area



Open the cover on the right side trim.

Information on the fuse types and locations is found on a separate sheet.

## **Breakdown assistance**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## **Hazard warning flashers**



The button is located in the center console.

## Intelligent Emergency Request

#### Requirements

- The radio ready state is switched on.
- ▶ The Assist system is functional.
- The SIM card integrated in the vehicle has been activated.
- A ConnectedDrive contract is available.

#### General information

Only press the SOS button in an emergency.

#### **Hints**

Emergency Request not guaranteed For technical reasons, the Emergency Request cannot be guaranteed under unfavorable conditions.

#### **Initiating an Emergency Request**



- 1. Press the cover briefly to open it.
- 2. Press the SOS button until the LED in the button lights up.
- ► The LED lights up: an Emergency Request was initiated

If the situation allows, wait in your vehicle until the voice connection has been established.

 The LED flashes when a connection to the BMW Response Center has been established.

When the emergency request is received at the BMW Response Center, the BMW Response Center contacts you and takes further steps to help you.

Even if you are unable to respond, the BMW Response Center can take further steps to help you under certain circumstances.

For this purpose, data that are used to determine the necessary rescue measures, such as the current position of the vehicle

- if it can be established, are transmitted to the BMW Response Center.
- If the LED is flashing, but the BMW Response Center can no longer be heard via the speaker, you can nevertheless still be heard for the BMW Response Center.

# **Initiating an Emergency Request automatically**

Under certain conditions, an Emergency Request is automatically initiated immediately after a severe accident. Automatic Collision Notification is not affected by pressing the SOS button.

## Warning triangle



The warning triangle is located on the inside of the trunk lid.

To remove, loosen the bracket.

#### First aid kit

#### Note

Some of the articles have a limited service life.

Check the expiration dates of the contents regularly and replace any expired items promptly.

#### **Storage**

The first aid kit is located in the insert in the rear seat backrest

 Pull the release in the direction of the arrow, and remove the insert from the front. If necessary, when pulling the release, press against the insert.



2. Remove the first aid kit.



When replacing the insert, place both pins into the rail at the bottom and press the insert back in place until a 'click' is heard. Ensure that the rear seat backrest upholstery is not damaged.

#### **Roadside Assistance**

#### **Service availability**

Roadside Assistance can be reached around the clock in many countries. You can obtain assistance there in the event of a vehicle breakdown.

#### Roadside Assistance

The Roadside Assistance phone number can be viewed on the iDrive or a connection to

Roadside Assistance can be established directly.

## **Jump-starting**

#### **Notes**

If the battery is discharged, an engine can be started using the battery of another vehicle and two jumper cables. Only use jumper cables with fully insulated clamp handles.

To prevent personal injury or damage to both vehicles, adhere strictly to the following procedure.

Do not touch live parts

To avoid the risk of potentially fatal injury, always avoid all contact with electrical components while the engine is running.

#### **Preparation**

- Check whether the battery of the other vehicle has a voltage of 12 volts. This information can be found on the battery.
- Switch off the engine of the assisting vehicle.
- Switch off any electronic systems/power consumers in both vehicles.

Bodywork contact between vehicles

Make sure that there is no contact between the bodywork of the two vehicles; otherwise, there is the danger of short circuits.

✓

## Starting aid terminals

Connecting order
Connect the jumper cables in the correct order; otherwise, there is the danger of injury from sparking.◄



The so-called starting aid terminal in the engine compartment acts as the battery's positive terminal.



The body ground or a special nut acts as the battery negative terminal.

#### **Connecting the cables**

- Pull off the cap of the BMW starting aid terminal.
- Attach one terminal clamp of the positive jumper cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle providing assistance.
- Attach the terminal clamp on the other end of the cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle to be started.
- Attach one terminal clamp of the negative jumper cable to the negative terminal of the battery, or to the corresponding engine or body ground of assisting vehicle.
- 5. Attach the second terminal clamp to the negative terminal of the battery, or to the

corresponding engine or body ground of the vehicle to be started.

#### Starting the engine

Never use spray fluids to start the engine.

- Start the engine of the assisting vehicle and let it run for several minutes at an increased idle speed.
- 2. Start the engine of the vehicle being started in the usual way.
  - If the first starting attempt is not successful, wait a few minutes before making another attempt in order to allow the discharged battery to recharge.
- 3. Let both engines run for several minutes.
- Disconnect the jumper cables in the reverse order.

Check the battery and recharge if necessary.

## **Tow-starting and towing**

# Automatic transmission: transporting your vehicle


#### Note

Your vehicle is not permitted to be towed. Therefore, contact a service center in the event of a breakdown.

Do not have the vehicle towed
Have your vehicle transported on a loading platform only; otherwise, damage may occur.

✓

#### Tow truck



Do not lift the vehicle

Do not lift the vehicle by the tow fitting or
body and chassis parts; otherwise, damage
may result.

✓

Use the tow fitting screwed in at the front for maneuvering the vehicle only.

#### Towing other vehicles

#### **General information**

Light towing vehicle
The towing vehicle must not be lighter than the vehicle being towed; otherwise, it will not be possible to control the vehicle response.

Attaching the tow bar/tow rope correctly
Attach the tow bar or tow rope to the tow
fitting; connecting it to other vehicle parts may
cause damage.

- Switch on the hazard warning system, depending on local regulations.
- If the electrical system has failed, clearly identify the vehicle being towed by placing a sign or a warning triangle in the rear window.

#### Tow bar

The tow fittings used should be on the same side on both vehicles.

Should it prove impossible to avoid mounting the tow bar at an offset angle, please observe the following:

- Maneuvering capability is limited during cornering.
- The tow bar will generate lateral forces if it is secured with an offset.

#### **Tow rope**

When starting to tow the vehicle, make sure that the tow rope is taut.

To avoid jerking and the associated stresses on the vehicle components when towing, always use nylon ropes or nylon straps.

Attaching the tow rope correctly

Only secure the tow rope on the tow fitting; otherwise, damage can occur when it is secured on other parts of the vehicle.

#### **Tow fitting**



The screw-in tow fitting should always be carried in the vehicle. It can be screwed in at the front or rear of the BMW. It is contained in the onboard vehicle tool kit under the cargo floor cover.



Tow fitting, information on use

- Use only the tow fitting provided with the vehicle and screw it all the way in.
- Use the tow fitting for towing on paved roads only.

Avoid lateral loading of the tow fitting, e.g., do not lift the vehicle by the tow fitting.

Otherwise, damage to the tow fitting and the vehicle can occur.◀

#### Screw thread



Push out the cover by pressing on the top edge.

## Tow-starting

#### **Automatic transmission**

Do not tow-start the vehicle.

Due to the automatic transmission, the engine cannot be started by tow-starting.

Have the cause of the starting difficulties remedied.

## Care

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### **Car washes**

#### **Hints**

Steam jets or high-pressure washers
When using steam jets or high-pressure
washers, hold them a sufficient distance away
and use a maximum temperature of
140 °F/60 °C.

If the vehicle has a glass sunroof, ensure that a distance of at least 31.5 inches/80 cm is maintained. Holding them too close or using excessively high pressures or temperatures can cause damage or preliminary damage that may then lead to long-term damage.

Follow the user's manual for the high-pressure washer.◀



Cleaning sensors/cameras with highpressure washers

When using high-pressure washers, do not spray the exterior sensors and cameras, e.g., Park Distance Control, for extended periods of time and only from a distance of at least 12 in/30 cm. ◀

Regularly remove foreign items such as leaves in the area below the windshield when the hood is raised.

Wash your vehicle frequently, particularly in winter.

Intense soiling and road salt can damage the vehicle.

#### Automatic car washes

#### **Hints**

Note the following:

- Give preference to cloth car washes or those that use soft brushes in order to avoid paint damage.
- Make sure that the wheels and tires are not damaged by the transport mechanisms.
- Fold in the exterior mirrors; otherwise, they may be damaged, depending on the width of the vehicle.
- Deactivate the rain sensor, refer to page 66, to avoid unintentional wiper activation.
- In some cases, an unintentional alarm can be triggered by the interior motion sensor of the alarm system. Follow the instructions on avoiding an unintentional alarm, refer to page 41.

Guide rails in car washes
Avoid car washes with guide rails higher
than 4 in/10 cm; otherwise, the vehicle body
could be damaged.◄

#### Before driving into a car wash

In order to ensure that the vehicle can roll in a car wash, take the following steps:

Automatic transmission:

- Drive into the car wash.
- 2. Engage transmission position N.
- Switch the engine off.
   In this way, the ignition remains switched on, and a Check-Control message is displayed.



Do not turn off the ignition in the car wash

Do not turn off the ignition in the car wash; otherwise, the transmission position P is engaged and damages can result.◀

To start the engine:

- 1. Depress the brake pedal.
- 2. Press the Start/Stop button.

Pressing the Start/Stop button without stepping on the brake turns the ignition off.

The vehicle cannot be locked from the outside when in transmission position N. A signal is sounded when an attempt is made to lock the vehicle.

#### **Transmission position**

Transmission position P is engaged automatically:

- When the ignition is switched off.
- After approx. 15 minutes.

#### **Headlamps**

- Do not rub dry and do not use abrasive or caustic cleansers.
- Soak areas that have been soiled e.g. due to insects, with shampoo and wash off with water.
- Thaw ice with deicing spray; do not use an ice scraper.

#### After washing the vehicle

After washing the vehicle, apply the brakes briefly to dry them; otherwise, braking action can be reduced and corrosion of the brake discs can occur.

Completely remove all residues on the windows, to minimize loss of visibility due to smearing and to reduce wiper noises and wiper blade wear.

## Vehicle care

#### Car care products

BMW recommends using cleaning and care products from BMW, since these have been tested and approved.



Car care and cleaning products

Follow the instructions on the container.

When cleaning the interior, open the doors or windows.

Only use products intended for cleaning vehicles.

Cleansers can contain substances that are dangerous and harmful to your health. ◀

#### Vehicle paint

Regular care contributes to driving safety and value retention. Environmental influences in areas with elevated air pollution or natural contaminants, such as tree resin or pollen can affect the vehicle's paintwork. Tailor the frequency and extent of your car care to these influences.

Aggressive substances, such as spilled fuel, oil, grease or bird droppings, must be removed immediately to prevent the finish from being altered or discolored.

#### Leather care

Remove dust from the leather often, using a cloth or vacuum cleaner.

Otherwise, particles of dust and road grime chafe in pores and folds, and lead to increased wear and premature degradation of the leather surface.

To guard against discoloration, such as from clothing, provide leather care roughly every two months.

Clean light-colored leather more frequently because soiling on such surfaces is substantially more visible. Use leather care products; otherwise, dirt and grease will gradually break down the protective layer of the leather surface.

Suitable care products are available from the service center.

## **Upholstery material care**

Vacuum regularly with a vacuum cleaner.

If they are very dirty, e.g., beverage stains, use a soft sponge or microfiber cloth with a suitable interior cleaner.

Clean the upholstery down to the seams using large sweeping motions. Avoid rubbing the material vigorously.

Damage from Velcro® fasteners

Open Velcro® fasteners on pants or other articles of clothing can damage the seat covers. Ensure that any Velcro® fasteners are closed.

## **Caring for special components**

## **Light-alloy wheels**

When cleaning the vehicle, use only neutral wheel cleaners having a pH value from 5 to 9. Do not use abrasive cleaning agents or steam jets above 140 °F/60 °C. Follow the manufacturer's instructions.

Aggressive, acidic or alkaline cleaning agents can destroy the protective layer of adjacent components, such as the brake disk.

#### **Chrome surfaces**

Carefully clean components such as the radiator grille or door handles with an ample supply of water, possibly with shampoo added, particularly when they have been exposed to road salt.

## **Rubber components**

Aside from water, treat only with rubber cleansers.

When cleaning rubber seals, do not use any silicon-containing car care products in order to avoid damage or reduced noise damping.

## Fine wood parts

Clean fine wood facing and fine wood components only with a moist rag. Then dry with a soft cloth.

## **Plastic components**

These include:

- Imitation leather surfaces.
- Headliner.
- Lamp lenses.
- Instrument cluster cover.
- Matte black spray-coated components.
- Painted parts in the interior.

Clean with a microfiber cloth.

Lightly dampen the cloth with water.

Do not soak the headliner.

Do not use cleansers that contain alcohol or solvents

Do not use cleansers that contain alcohol or solvents, such as lacquer thinners, heavy-duty grease removers, fuel, or such; this could lead to surface damage. <

## Safety belts

Dirty belt straps impede the reeling action and thus have a negative impact on safety.

lack

Chemical cleaning

Do not clean chemically; this can destroy the webbing. ◀

Use only a mild soapy solution, with the safety belts clipped into their buckles.

Do not allow the reels to retract the safety belts until they are dry.

#### Carpets and floor mats

No objects in the area around the pedals Keep floor mats, carpets, and any other objects out of the area of motion of the pedals: otherwise, the function of the pedals could be impeded while driving

Do not place additional floor mats over existing mats or other objects.

Only use floor mats that have been approved for the vehicle and can be properly fixed in place.

Ensure that the floor mats are securely fastened again after they were removed for cleaning, for example. ◀

Floor mats can be removed from the passenger compartment for cleaning.

If the floor carpets are very dirty, clean with a microfiber cloth and water or a textile cleaner. To prevent matting of the carpet, rub back and forth in the direction of travel only.

## Long-term vehicle storage

Your service center can advise you on what to consider when storing the vehicle for longer than three months.



#### Sensors/cameras

تلفن شيانه روزي: ۱۵۸۰ ۲۹۸۸۸ - ۲۱ To clean sensors and cameras, use a cloth moistened with a small amount of glass cleaner.

## Displays/screens

Clean the displays with an antistatic microfiber cloth.

Cleaning displays

Do not use chemical or household cleansers.

Keep all fluids and moisture away from the unit.

Otherwise, they could affect or damage surfaces or electrical components.

Avoid pressing too hard when cleaning and do not use abrasive materials; otherwise, damage can result.◀



تلفن شبانه روزى: ۵۸۰۲۹۸۸۸ ۲۲۰



ار را د محرد و و ار را ۰۲۱-۸۸۸۶۲۰۸۸ (وی در ۱۰۲۱-۸۸۸۶۲۰۸۸ (وی تا ۲۸۸۸۶۲۰۸۸ (وی در ۱۰۲۱-۸۸۶۲۰۸۸ (وی در ۱۰۲۱-۸۸۶۲۰۸ (وی در ۱۰۲۱-۸۸۶۲۰۸۸ (وی در ۱۰۲۱-۸۸۶۲۰۸ (وی در ۱۰۲۱-۸۸۲۰۸ (وی در ۱۰۲۱-۸۸۲ (وی در ۱۰۲۱-۸۸۲ (وی در ۱۰۲۱-۸۸۲۸ (وی در ۱۰۲۱-۸۸۲ (وی در ۱۰۲۱-۸۲ (وی در ۱۰۲۱-۸۲ (وی در ۱۰۲۱-۸۲۲ (وی در ۱۰۲۱-۸۲ (وی در ۱۰۲-۸۲ (وی

# Reference

This chapter contains the technical data and an index that will quickly take you to the information you need.

FarmaSOS com

امداد ودرو

## **Technical data**


## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.


## **Dimensions**

## Width, height



- 1 Vehicle height: 53.9 inches/1,369 mm
- 2 Vehicle width without mirrors: 74.6 inches/ 1,894 mm
- 3 Vehicle width with mirrors: 81.9 inches/ 2.081 mm

## Length, wheel base



1 Wheelbase: 112.4 inches/2,855 mm

2 Length: 192.8 inches/4,896 mm

تلفن شبانه روزی: ۱۹۸۵ کی Smallest turning circle ۲۱ کی دروزی: ۱۹۸۵ کی دروزی: ۱۹۸

Dia.: 38.4 ft/11.7 m

## Weights

640i		
Approved gross vehicle weight	lbs/kg	4,828/2,190
Load	lbs/kg	772/350
Approved front axle load	lbs/kg	2,425/1,100
Approved rear axle load	lbs/kg	2,668/1,210
Cargo area capacity	cu ft/l	16.2/460

640i xDrive		
Approved gross vehicle weight	lbs/kg	5,020/2,277
Load	lbs/kg	770/349
Approved front axle load	lbs/kg	2,600/1,179
Approved rear axle load	lbs/kg	2,700/1,225
Cargo area capacity	cu ft/l	16.2/460

650i			
Approved gross vehicle wei	ght		
Manual transmission Sport automatic transmission	on	lbs/kg lbs/kg	5,115/2,320 5,115/2,320
Load	1 1	lbs/kg	770/349
Approved front axle load	6/199	lbs/kg	2,600/1,179
Approved rear axle load		lbs/kg	2,710/1,229
Cargo area capacity		cu ft/l	16.2/460
	+71-111	روزی: ۱۰۸۵	تلفن شبائه

650i xDrive		
Approved gross vehicle weight	lbs/kg	5,245/2,379
Load	lbs/kg	770/349
Approved front axle load	lbs/kg	2,710/1,229
Approved rear axle load	lbs/kg	2,755/1,250
Cargo area capacity	cu ft/l	16.2/460

## **Capacities**

			Notes
Fuel tank	US gal/liters	approx. 18.5/70	Fuel quality, refer to page 184
Windshield and headlamp washer system	US quarts/liters	approx. 5.3/5.0	



تلفن شبانه روزی: ۱۳۵۸ ۲۹ ۱۳۸۸ - ۲۱

## **Everything from A to Z**

## Index

## A

ABS, Antilock Brake System 116 ACC, Active Cruise Control with Stop & Go 124 Activated-charcoal filter 154 Active Blind Spot Detection 112 Active Cruise Control with Stop & Go, ACC 124 Active Protection 113 Active roll stabilization, see Dynamic Drive 119 Active seat, front 47 Active seat ventilation, front 47 Active Steering, integral 119 Adaptive brake assistant 116 Adaptive brake lights, refer to Brake force display 113 Adaptive drive 119 Adaptive light control 87 Additives, oil 200 Adjusting, steering wheel 53 Adjustments, seats/head restraints 45 After washing vehicle 216 Airbags 91 Airbags, indicator/warning light 92 Air circulation, refer to Recirculated-air mode 153 Air distribution, manual 152 Air drying, refer to Cooling function 153 Air flow, automatic climate control 152

Alarm system 40 Alarm, unintentional 41 All around the center console 14 All around the interior rearview mirror 15 All around the steering wheel 12 All-season tires, refer to Winter tires 194 All-wheel-drive 118 Alternating-code hand-held transmitter 158 Alternative oil types 200 Ambient light 89 Antifreeze, washer fluid 67 Antilock Brake System, **ABS 116** Anti-slip control, refer to **DSC 116** Approved engine oils 200 Armrest, refer to Front center armrest 163 Arrival time 83 Ashtray 159 Assistance, Roadside Assistance 211 Assistance when driving off 116 Attentiveness assistant 114 AUTO H button, refer to Automatic Hold 63 **AUTO intensity 152** Automatic car wash 215 Automatic Cruise Control with Stop & Go 124 Automatic Curb Monitor 52 Automatic deactivation, front passenger airbags 93 Automatic headlamp control87

Automatic Hold 63
Automatic locking 39
Automatic recirculated-air control 153
Automatic Soft Closing, doors 36
Automatic transmission with Steptronic 67
AUTO program, automatic climate control 152
AUTO program, intensity 152
Auto Start/Stop function 60
Average fuel consumption 83
Average speed 83
Axle loads, weights 223

## В

Backrest curvature, refer to Lumbar support 46 Backrest, seats 45 Backrest, width 46 Backup camera 138 Band-aids, refer to First aid kit 211 Bar for tow-starting/ towing 213 Battery replacement, remote control for parked-car heating/ventilation 156 Battery replacement, vehicle battery 208 Battery replacement, vehicle remote control 30 Battery, vehicle 208 Belts, safety belts 48 Beverage holder, cupholder 164 Blinds, sun protection 42 BMW Assist, see user's manual for Navigation, En-

tion 154

Air pressure, tires 185

Air vents, refer to Ventila-

tertainment and Communi-	Can holder, refer to Cu-	Child restraint fixing systems
cation	pholder 164	mounting 54
BMW Homepage 6	Car battery 208	Child seat, mounting 54
BMW Internet page 6	Car care products 216	Child seats 54
BMW maintenance sys-	Care, displays 218	Chrome parts, care 217
tem 202	Care, vehicle 216	Cigarette lighter 159
Bonus range, ECO PRO 175	Cargo 171	Cleaning, displays 218
Bottle holder, refer to Cu-	Cargo area lid 36	Climate control 151
pholder 164	Cargo area, storage compart-	Climate control laminated
Brake assistant 116	ments 164	tinted safety glass 169
Brake assistant, adaptive 116	Cargo, securing 172	Climate control wind-
Brake discs, breaking in 168	Cargo straps, securing	shield 169
Brake force display 113	cargo 172	Clock 78
Brake lamps, brake force display 113	Car key, refer to Remote control 30	Closing/opening from inside 36
Brake lamps, bulb replace-	Carpet, care 218	Closing/opening via door
ment 206	Car wash 215	lock 35
Brake lights, adaptive 113	Catalytic converter, refer to	Closing/opening with remote
Brake pads, breaking in 168	Hot exhaust system 168	control 34
Braking, hints 169	CBS Condition Based Serv-	Clothes hooks 164
Breakdown assis-	ice 202	Coasting 177
tance 210, 211	CD/Multimedia, see user's	Coasting with engine decou-
Breaking in 168	manual for Navigation, En-	pled, coasting 177
Brightness of Control Dis-	tertainment and Communi-	Coasting with idling en-
play 85	فن شبانه روزي: ۸۵ • cation ۲	
Bulb replacement, front 204	Center console 14	Collision warning with brakin
Bulb replacement, rear 206	Center-Lock, see button for	function 100
Button, RES 127	central locking 33	Collision warning with City
Button, Start/Stop 58	Central locking system 33	Braking function 103
Bypassing, refer to Jump-	Central screen, refer to Con-	Combination switch, refer to
starting 212	trol Display 16	Turn signals 64
<u> </u>	Changes, technical, refer to	Combination switch, refer to
C	Safety 7	Wiper system 65
	Changing parts 204	COMFORT+ program, Drivin
California Proposition 65	Changing wheels 207	Dynamics Control 122
Warning 7	Changing wheels/tires 193	Comfort Access 37
Calling up mirror adjust-	Check Control 75	COMFORT program, Driving
ment 39	Checking the oil level elec-	Dynamics Control 122
Calling up seat adjust-	tronically 199	Computer 82
ment 39	Children, seating position 54	Condensation on win-
Calling up steering wheel ad-	Children, transporting	dows 152
justment 39	safely 54	Condensation under the vehi
Camera, backup camera 138	Child restraint fixing sys-	cle 170
Camera, care 218	tem 54	Condition Based Service
Camera, Side View 143	Child restraint fixing system	CBS 202

Configure driving mode 122

LATCH 55

Camera, Top View 141

Confirmation signal 39	Direction indicator, refer to	Dynamic Traction Control
Congestion Assistant 130	Turn signals 64	DTC 117
ConnectedDrive, see user's	Display in windshield 148	
manual for Navigation, En-	Display lighting, refer to In-	E
tertainment and Communi-	strument lighting 89	_
cation	Displays 71, 72	ECO PRO 174
ConnectedDrive Services	Displays, cleaning 218	ECO PRO, bonus range 175
Control Display 16	Disposal, coolant 201	ECO PRO display 174
Control Display, settings 84	Disposal, vehicle battery 208	ECO PRO displays 74
Controller 16	Distance control, refer to	ECO PRO driving mode 174
Control systems, driving sta-	PDC 136	ECO PRO mode 174
bility 116	Distance information 149	ECO PRO Tip - driving in-
Convenient opening 34	Distance to destination 83	struction 176
Coolant 201	Divided screen view, split	EfficientDynamics 176
Coolant temperature 78	screen 20	Electronic displays, instru-
Cooling function 153	Door lock, refer to Remote	ment cluster 72
Cooling, maximum 153	control 30	Electronic Stability Program
Cooling system 201	Doors, Automatic Soft Clos-	ESP, refer to DSC 116
Corrosion on brake discs 170	ing 36	Emergency detection, remote
Cruise control 133	Downhill control 118	control 31
Cruise control, active with	Drive-off assistant 116	Emergency release, door
Stop & Go 124	Drive-off assistant, refer to	lock 36
Cruising range 78	DSC 116	Emergency release, fuel filler
Cupholder 164	Driver assistance, see Intelli-	flap 182
Current fuel consumption 79	شبانه روزی: ۵۵ Safety 99	Emergency Request 210
·	Driving Assistant, see Intelli-	Emergency service, refer to
D	gent Safety 99	Roadside Assistance 211
	Driving Dynamics Con-	Emergency start function, en-
Damage, tires 193	atrol 120 a 3 U 5 . C O I	gine start 31
Damping Control, dy-	Driving instructions, breaking	Emergency unlocking, trunk
namic 119	in 168	lid 37
Data, technical 222	Driving mode 120	Energy Control 79
Date 78	Driving notes, general 168	Energy recovery 79
Daytime running lights 87	Driving stability control sys-	Engine, automatic Start/Stop
Defrosting, refer to Windows,	tems 116	function 60
defrosting 152	Driving tips 168	Engine, automatic switch-
Departure time, parked-car	DSC Dynamic Stability Con-	off 60
heating 155	trol 116	Engine compartment 197
Departure time, parked-car	DTC driving dynamics 117	Engine compartment, work-
ventilation 155	DTC Dynamic Traction Con-	ing in 197
Destination distance 83	trol 117	Engine coolant 201
Digital clock 78	Dynamic Damping Con-	Engine idling when driving,
Dimensions 222	trol 119	coasting 177

mirror 52

Dimmable exterior mirrors 52

Dimmable interior rearview

Dynamic Drive 119
Dynamic Stability Control

**DSC 116** 

Engine oil 199

Engine oil, adding 200

Engine oil additives 200

Engine oil change 200 Engine oil filler neck 200 Engine oil temperature 77 Engine oil types, alternative 200 Engine oil types, approved 200 Engine start during malfunction 31 Engine start, jump-starting 212 Engine start, refer to Starting the engine 59 Engine stop 59 Engine temperature 77 Entering/exiting vehicle, assistance, steering wheel 53 Entering a car wash 215 Equipment, interior 157 ESP Electronic Stability Program, refer to DSC 116 Exchanging wheels/tires 193 Exhaust system 168 Exterior mirror, automatic dimming feature 52 Exterior mirrors 51 External start 212 External temperature display 78 External temperature warning 78 Eyes for securing cargo 172

## F

Failure message, refer to Check Control 75 False alarm, refer to Unintentional alarm 41 Fan, refer to Air flow 152 Fault displays, refer to Check Control 75 Filler neck for engine oil 200 Fine wood, care 217 First aid kit 211 Fitting for towing, refer to Tow fitting 214 Flat tire, changing wheels 207 Flat Tire Monitor FTM 97 Flat tire, Tire Pressure Monitor TPM 94 Flat tire, warning lamp 95, 98 Flooding 169 Floor carpet, care 218 Floor mats, care 218 Fold-out position, windshield wipers 66 Foot brake 169 For the headliner, refer to All around the interior rearview mirror 15 Front airbags 91 Front center armrest 163 Front fog lamps 89 Front lamps 204 Front passenger airbags, automatic deactivation 93 Front passenger airbags, indi-شبانه روزی: ۵ cator lamp 93 Front seats 45 Front turn signals, refer to Light-emitting diodes, I FDs 206 FTM Flat Tire Monitor 97 **Fuel 184** Fuel cap 182 Fuel consumption, current 79 Fuel consumption, refer to Average fuel consumption 83

## G

Garage door opener, refer to Integrated universal remote control 157 Gasoline 184 Gasoline quality 184 Gear change, automatic transmission 68 Gear shift indicator 80 General driving notes 168 Glass sunroof, powered with tilt function 42 Glove compartment 162 Gross vehicle weight, approved 223 Gross weight, permissible for trailer towing 223

## Н

Handbrake, refer to Parking brake 62 Hand-held transmitter, alternating code 158 Hazard warning flashers 210 HDC Hill Descent Control 118 Head airbags 91 Headlamp control, automatic 87 Headlamp courtesy delay fea-Headlamp courtesy delay feature via remote control 34 Headlamp flasher 65 Headlamp glass 205 Headlamps 204 Headlamps, care 216 Headlamp washer system 65 Head restraints 45 Head restraints, front 49 Head-Up Display 148 Head-up Display, care 218 Heating, refer to Parked-car

heating 154

Fuel recommendation 184

Fuel, tank capacity 224

Fuel filler flap 182

Fuel gauge 77

Fuse 208

Fuel quality 184

Heavy cargo, stowing 172 Height, seats 45	Info display, refer to Computer 82	Keyless Go, refer to Comfort Access 37
Height, vehicle 222	Initialization, Integral Active	Key Memory, refer to Per-
High-beam Assistant 88	Steering 120	sonal Profile 31
High beams 65	Initialize, Tire Pressure Moni-	Kickdown, automatic trans-
High beams/low beams, refer	tor TPM 95	mission 68
to High-beam Assistant 88	Initializing, Flat Tire Monitor	Knee airbag 91
Hill Descent Control	FTM 98	Taroo an bag o r
HDC 118	Instrument cluster 71	L
Hills 170	Instrument cluster, electronic	_
Hill start assistant, refer to	displays 72	Lamp replacement, front 204
Drive-off assistant 116	Instrument display, multifunc-	Lamp replacement, rear 206
Hints 6	tional 72	Lamps 86
Holder for beverages 164	Instrument lighting 89	Lamps and bulbs 204
Homepage 6	Integral Active Steering 119	Lane departure warning 110
Hood 197	Integrated key 30	Lane margin, warning 110
Horn 12	Integrated universal remote	Language on Control Dis-
Hotel function, trunk lid 37	control 157	play 85
Hot exhaust system 168	Intelligent Emergency Re-	Lashing eyes, securing
HUD Head-Up Display 148	quest 210	cargo 172
Hydroplaning 169	Intelligent Safety 99	LATCH child restraint fixing
	Intensity, AUTO pro-	system 55
	gram 152	Leather, care 216
	Interior equipment 157	LED headlamps, Bulb re-
ce warning, refer to External	شبانه روزی: ۵۸ Interior lamps 89	placement 206
temperature warning 78	Interior lamps via remote con-	LED light 206
cy roads, refer to External	trol 34	LEDs, light-emitting di-
temperature warning 78	Interior motion sensor 41	odes 205
dentification marks, tires 191	Interior rearview mirror, auto-	Length, vehicle 223
dentification number, refer to	matic dimming feature 52	Letters and numbers, enter-
Important features in the en-	Internet page 6	ing 21
gine compartment 197	Interval display, service re-	License plate lamp, bulb re-
Drive 16	quirements 79	placement 206
gnition key, refer to Remote		Light alloy wheels, care 217
control 30	J	Light control 87
gnition off 58		Light-emitting diodes,
gnition on 58	Jacking points for the vehicle	LEDs 205
ndication of a flat tire 95, 98	jack 207	Lighting 86
ndicator and warning	Joystick, automatic transmis-	Lighting, speaker 90
lamps 75	sion 68	Lighting via remote con-
ndividual air distribution 152	Jump-starting 212	trol 34
ndividual settings, refer to	K	Light switch 86
Personal Profile 31	IV.	Load 171

FTM, tires 97

Inflation pressure, tires 185

Inflation pressure warning

Key/remote control 30

Loading 171

Lock, door 35

Locking/unlocking from inside 36 Locking/unlocking via door lock 35 Locking/unlocking with remote control 34 Locking, automatic 39 Locking, central 33 Locking, settings 39 Locking via trunk lid 37 Low beams 86 Low beams, automatic, refer to High-beam Assistant 88 Lower back support 46 Lumbar support 46

## M

Maintenance 202 Maintenance requirements 202 Maintenance, service requirements 79 Maintenance system, **BMW 202** Malfunction displays, refer to Check Control 75 Manual air distribution 152 Manual air flow 152 Manual brake, refer to Parking brake 62 Manual mode, transmission 69 Manual operation, backup camera 139 Manual operation, door lock 36 Manual operation, exterior mirrors 52 Manual operation, fuel filler flap 182 Manual operation, Park Distance Control PDC 136 Manual operation, Side View 143

Manual operation, Top View 141 Marking on approved tires 194 Marking, run-flat tires 195 Massage seat, front 47 Master key, refer to Remote control 30 Maximum cooling 153 Maximum speed, display 80 Maximum speed, winter tires 194 Measure, units of 85 Medical kit 211 Memory for seat, mirrors, steering wheel 50 Menu, EfficientDynamics 176 Menu in instrument cluster 82 Menus, operating, iDrive 16 Menus, refer to iDrive operating concept 17 Messages, refer to Check Control 75 تلفن شبانه روزی: Microfilter 154 🚨 Minimum tread, tires 193 Mirror 51 Mirror memory 50 Mobile communication devices in the vehicle 169 Modifications, technical, refer to Safety 7 Moisture in headlamp 205 Monitor, refer to Control Display 16 Mounting of child restraint fixing systems 54 Multifunctional instrument display 72 Multifunction steering wheel, buttons 12

## Ν

Navigation, see user's manual for Navigation, Entertainment and Communication Neck restraints, front, refer to Head restraints 49 Neutral cleaner, see wheel cleaner 217 New wheels and tires 193 Night Vision with pedestrian detection 107 No Passing Information 80 Nylon rope for tow-starting/ towing 214



0 OBD Onboard Diagnosis 203 OBD, see OBD Onboard Diagnosis 203 Obstacle marking, rearview camera 140 Octane rating, refer to Gasoline quality 184 Odometer 78 Office, see user's manual for Navigation, Entertainment and Communication Oil 199 Oil, adding 200 Oil additives 200 Oil change 200 Oil change interval, service requirements 79 Oil filler neck 200 Oil types, alternative 200 Oil types, approved 200 Old batteries, disposal 208 Onboard monitor, refer to Control Display 16 Onboard vehicle tool kit 204 Opening and closing 30

Opening and closing, from in-

side 36

oning and clocing via door

Opening and closing via door
lock 35
Opening and closing, with re-
mote control 34
Operating concept, iDrive 16
Optional equipment, standard
equipment 6
Outside air, refer to Auto-
matic recirculated-air con-
trol 153
Overheating of engine, refer
to Coolant temperature 78
Overtaking prohibitions 80

## P

Paint, vehicle 216 Parallel parking assistant 144 Park Distance Control PDC 136 Parked-car heating 155 Parked-car ventilation 155 Parked vehicle, condensation 170 Parking aid, refer to PDC 136 Parking assistant 144 Parking brake 62 Parking lamps 86 Parking lamps and roadside parking lamps, refer to Light-emitting diodes, **LEDs 206** Parking with Auto Hold 63 Passenger side mirror, tilting downward 52 Pathway lines, rearview camera 139 PDC Park Distance Control 136 Pedestrian detection, refer to Night Vision 107 Pedestrian warning with city braking function 105 People detection, refer to Night Vision 107

Personal Profile 31 Pinch protection system, glass sunroof 43 Pinch protection system, windows 42 Plastic, care 217 Power failure 208 Power sunroof, glass 42 Power windows 41 Pressure, tire air pressure 185 Pressure warning FTM, tires 97 Profile, refer to Personal Profile 31 Programmable memory buttons, iDrive 20 Protective function, glass sunroof 43 Protective function, windows 42 Push-and-turn switch, refer to Controller 16

Queuing Assistant, see Congestion Assistant 130

## R

Radiator fluid 201
Radio-operated key, refer to Remote control 30
Radio ready state 59
Radio, see user's manual for Navigation, Entertainment and Communication
Rain sensor 66
Rear axle steering 119
Rear lamps 206
Rearview mirror 51
Rear window defroster 153
Recirculated-air mode 153
Recommended tire brands 194

Refueling 182 Remaining range 78 Remote control/key 30 Remote control, malfunction 35 Remote control, parked-car heating/ventilation 156 Remote control, universal 157 Replacement fuse 208 Replacing bulbs, see Lamp replacement 204 Replacing parts 204 Replacing wheels/tires 193 Reporting safety defects 9 RES button 127 Reserve warning, refer to Range 78 Reset. Tire Pressure Monitor **TPM 95** Residual heat, automatic climate control 153 Retaining straps, securing cargo 172 Retreaded tires 194 Reversing lamp, bulb replacement 207 Roadside parking lamps 87 Roller sunblinds 42 Roll stabilization, refer to Adaptive Drive 119 Roll stabilization, see Dynamic Drive 119 RON gasoline quality 184 Rope for tow-starting/ towing 214 RSC Run Flat System Component, refer to Run-flat tires 195 Rubber components, care 217 Run-flat tires 195

## S

Safe braking 169

Permissible axle load 223

Safety 7
Safety belt reminder for driv-
er's seat and front passen-
ger seat 48
Safety belts 48
Safety belts, care 217
Safety Package, refer to Ac-
tive Protection 113
Safety systems, airbags 91
Saving fuel 173
Screen, refer to Control Dis-
play 16
Screwdriver 204
Screw thread for tow fit-
ting 214
Seat belts, refer to Safety
belts 48
Seat heating, front 47
Seating position for chil-
dren 54
Seat, mirror, and steering
wheel memory 50
Seats 45
Seat ventilation, front 47
Selection list in instrument
cluster 82
Selector lever, automatic
transmission 68
Sensors, care 218
Service and warranty 7
Service requirements, Condi-
tion Based Service
CBS 202
Service requirements, dis-
play 79
Service, Roadside Assis-
tance 211
Services, ConnectedDrive
Settings, locking/unlock-
ing 39
Settings on Control Dis-
play <mark>84</mark>
Settings, storing for seat, mir-
rors, steering wheel 50
Shifting, automatic transmis-
sion 67

Shift paddles on steering
wheel 69
Shoulder support 47
Side airbags 91
Side View 142
Signaling, horn 12
Signals when unlocking 39
Sitting safely 45
Size 222
Ski bag 160
Smallest turning circle 223
Smoker's package 159
Snow chains 195
Socket 160
Socket, OBD Onboard Diag-
nostics 203
SOS button 210
Spare fuse 208
Speaker lighting 90
Specified engine oil
types 200
Speed, average 83
Speed limit detection, on-
شبانه روز که board computer 83
Speed limiter, display 80
Speed Limit Information 80
Speed limit in the com-
puter 83
Split screen 20
SPORT+ - program, Dynamic
Driving Control 121
Sport automatic transmis-
sion 69
SPORT program, driving dy-
namics 122
Sport program, transmis-
sion 69
Stability control systems 116
Start/stop, automatic func-

Shift Lights 70

Status information, iDrive 19 Status of Owner's Manual 6 Steering, Integral Active Steering 119 Steering wheel, adjusting 53 Steering wheel heating 53 Steering wheel memory 50 Steptronic, automatic transmission 67 Stopping the engine 59 Storage compartments 162 Storage compartments, locations 162 Storage, tires 195 Storing the vehicle 218 Summer tires, tread 193 Supplementary text message 76 Surround View 138 Suspension settings 120 Switch for Dynamic Driving Control 120 Switch, refer to Cockpit 12 Symbols 6 -SYNC program, automatic cli تلفن mate control 153

Tachometer 77 Tail and brake lamps 206 Tailgate 36 Tailgate via remote control 34 Tail lamps 206 Tail lamps, bulb replacement 206 Technical changes, refer to Safety 7 Technical data 222 Telephone, see user's manual for Navigation, Entertainment and Communication Temperature, automatic climate control 152

tion 60

tion 31

Start/Stop button 58

Starting the engine 59

Status display, tires 94

Start function during malfunc-

Temperature display, external
temperature 78
Temperature, engine oil 77
Tempomat, refer to Active
Cruise Control 124
Terminal, starting aid 212
Text message, supplemen-
tary 76
Theft alarm system, refer to
Alarm system 40
Theft protection, refer to
Central locking system 33
Thermal camera, refer to
Night Vision 107
Thigh support 46
Tilt alarm sensor 41
Tilt glass roof 42
Tilt, seats 45
Time of arrival 83
Tire damage 193
Tire identification marks 191
Tire inflation pressure 185
Tire inflation pressure moni-
tor, refer to FTM 97
Tire Pressure Monitor
TPM 94
Tires, changing 193
Tires, everything on wheels and tires 185
Tires, run-flat tires 195
Tire tread 193
Tone, see user's manual for
Navigation, Entertainment
and Communication
Tools 204
Top View 140
Total vehicle weight 223
Tow fitting 214
Towing 213
Tow-starting 213
TPM Tire Pressure Moni-
tor 94
Traction control 117
TRACTION program, Dy-
namic Driving Control 121

Transporting children safely 54 Tread, tires 193 Trip computer 84 Triple turn signal activation 64 Trip odometer 78 Trunk lid 36 Trunk lid, emergency unlocking 37 Trunk lid, hotel function 37 Trunk lid via remote control 34 Turning circle 223 Turning circle lines, rearview camera 139 Turn signals, operation 64 Turn signals, rear, bulb replacement 206

יט

Units of measure 85
Universal remote control 157
Unlock button, automatic transmission 68
Unlocking/locking from inside 36
Unlocking/locking via door lock 35
Unlocking/locking with remote control 34
Unlocking, settings 39
Updates made after the editorial deadline 7
Upholstery care 217
USB interface 162

Unintentional alarm 41



Variable steering, Integral Active Steering 119
Vehicle battery 208
Vehicle battery, replacing 208

Vehicle, breaking in 168 Vehicle care 216 Vehicle equipment 6 Vehicle identification number, refer to Identification number in the engine compartment 197 Vehicle jack 207 Vehicle paint 216 Vehicle storage 218 Vehicle wash 215 Ventilation 154 Vertical Dynamic Control, refer to Dynamic Damping Control 119 Voice activation system 22



Warning indicators 75 Warning lamps 75 Warning messages, refer to Check Control 75 Warning triangle 211 Washer fluid 67 Washer fluid reservoir, capacity 224 Washer nozzles, windshield 66 Washer system 65 Washing, vehicle 215 Water on roads 169 Weights 223 Welcome lamps 86 Wheel base, vehicle 223 Wheel cleaner 217 Wheels, changing 193 Wheels, everything on wheels and tires 185 Wheels, Flat Tire Monitor **FTM 97** Wheels, Tire Pressure Monitor TPM 94 Width, vehicle 222 Window defroster, rear 153 Windows, powered 41

Transmission, automatic 67

Windshield, climate control 169 Windshield washer fluid 67 Windshield washer nozzles 66 Windshield washer system<sub>65</sub> Windshield wiper 65 Windshield wipers, fold-out position 66 Winter storage, care 218 Winter tires, suitable tires 194 Winter tires, tread 193 Wiper blades, replacing 204 Wiper fluid 67 Wiper system 65 Wood, care 217 Word match concept, navigation 21 Wrench 204



xDrive 118 + ۲ \ - ۱۸۸۶۲ + ۱۸۵ :روزی: Xenon headlamps, bulb replacement 205

# امداد خودرو فارما

تلفن شبانه روزى: ۱-۸۸۸۶۲ ۲۸ الفن شبانه روزى: ۱-۸۸۸۶۲ م

More about BMW

bmwusa.com



امداد خودرو فارما

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۲۰

